

Philips LCD monitor with SmartControl Lite

V Line 23.6" / 59.9 cm

243V5QHABA

Great LED images in vivid colors

with stereo speakers

Enjoy vibrant pictures on this Philips display. Equipped with HDMI and stereo speakers, it's a great choice!

Vivid pictures every time

- MVA Display for wide viewing angles and deep contrast levels
- 16:9 Full HD display for crisp detailed images
- SmartContrast for rich black details
- Easy display performance tuning with SmartControl Lite

Experience multimedia

- Built-in stereo speakers for multimedia
- HDMI-ready for Full HD entertainment

Great choice

- Compact design saves space
- Mercury Free eco-friendly display
- VESA mount allows for flexibility



LCD monitor with SmartControl Lite V Line 23.6" / 59.9 cm

243V5QHABA/00

Highlights

MVA Display Technology



Philips MVA LED display uses an advanced multi-domain vertical alignment technology which gives you super-high static contrast ratios for extra vivid and bright images. While standard office applications are handled with ease, it is especially suitable for photos, webbrowsing, movies, gaming, and demanding graphical applications. It's optimized pixel management technology gives you 178/178 degree extra wide viewing angle, resulting in crisp images.

Built-in stereo speakers



A pair of high quality stereo speakers built into a display device. It can be visible front firing, or invisible down firing, top firing, rear firing, etc depending on model and design.

SmartControl Lite

SmartControl Lite is the next generation 3D icon based GUI monitor control software. This

allows user to fine-tune most parameters of the monitor like Color, Brightness, screen calibration, Multi-media, ID management, etc with the mouse.

SmartContrast



SmartContrast is a Philips technology that analyzes the contents you are displaying, automatically adjusting colors and controlling backlight intensity to dynamically enhance contrast for the best digital images and videos or when playing games where dark hues are displayed. When Economy mode is selected, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.

16:9 Full HD display



Picture quality matters. Regular displays deliver quality, but you expect more. This display features enhanced Full HD 1920 x 1080 resolution. With Full HD for crisp detail paired with high brightness, incredible contrast and realistic colors expect a true to life picture.

HDMI Ready



An HDMI-ready device has all the required hardware to accept High-Definition Multimedia Interface (HDMI) input. A HDMI cable enables high-quality digital video and audio all transmitted over a single cable from a PC or any number of AV sources (including set-top boxes, DVD players, A/V receivers and video cameras).

Mercury Free

Philips monitors with LED backlighting are free of Mercury content, one of the most toxic natural substances, which affects humans and animals. This reduces the environmental impact of the display throughout its life-cycle, from manufacturing to disposal.

















Specifications

Picture/Display

- LCD panel type: MVA
- Backlight type: W-LED system
- Panel Size: 23.6 inch / 59.9 cm
- Effective viewing area: 521.28 (H) x 293.22 (V)
 Aspect ratio: 16:9
- Optimum resolution: 1920 x 1080 @ 60 Hz
- Response time (typical): 8 ms (Gray to Gray)*
- Brightness: 250 cd/m²
- SmartContrast: 10,000,000:1
- Contrast ratio (typical): 3000:1
- Pixel pitch: 0.272 x 0.272 mm
- Viewing angle: 178° (H) / 178° (V), @ C/R > 20
- Display colors: 16.7 M
- Scanning Frequency: 30 -83 kHz (H) / 56 -76 Hz (V) • sRGB

Connectivity

- Signal Input: VGA (Analog), DVI-D (digital, HDCP), HDMI (digital, HDCP)
- Sync Input: Separate Sync, Sync on Green
- Audio (In/Out): PC audio-in, Headphone out

Convenience

• Built-in Audio: 2.0W x 2

- User convenience: Auto/Down, Brightness/Back, Menu/OK, Power On/Off, Volume/Up
- OSD Languages: Brazil Portuguese, Czech, Dutch, English, Finnish, French, German, Greek, Hungarian, Italian, Japanese, Korean, Polish, Portuguese, Russian, Spanish, Simplified Chinese, Swedish, Turkish, Traditional Chinese, Ukrainian
- Other convenience: Kensington lock, VESA mount (100x100mm)
- Plug & Play Compatibility: DDC/Cl, Mac OS X, sRGB, Windows 7, Windows 8

Stand

• Tilt: -5/20 degree

Power

- On mode: 21.51 W (typ.) (EnergyStar test method)
- Standby mode: 0.5 W (typ.)

- Off mode: 0.3 W (typ.)
- Energy Label Class: E
- Power LED indicator: Operation White, Standby mode- White (blinking)
- Power supply: Built-in, 100-240VAC, 50-60Hz

Dimensions

- Product with stand (mm): 551 x 420 x 220 mm
- Product without stand (mm): $551 \times 344 \times 52 \text{ mm}$
- Packaging in mm (WxHxD): 600 x 415 x 118 mm

Weight

- Product with stand (kg): 3.66 kg
- Product without stand (kg): 3.22 kg
- Product with packaging (kg): 4.76 kg

Operating conditions

- Temperature range (operation): 0°C to 40 °C
- Temperature range (storage): -20°C to 60 °C
- Relative humidity: 20%-80 %
- Altitude: Operation: +12,000ft (3,658m), Non-
- operation: +40,000ft (12,192m)
- MTBF: 30,000 hour(s)

Sustainability

- Environmental and energy: EnergyStar 6.0, RoHS, Mercury Free
- Recyclable packaging material: 100 %

Compliance and standards

 Regulatory Approvals: CE Mark, FCC Class B, TCO Certified, cETLus, TUV/ISO9241-307, BSMI, PSB, C-Tick, UKRAINIAN, WEEE

• Color: Black

• Finish: Hairline (front bezel) / Texture (rear cover)

What's in the box?

- · Monitor with stand
- · Cables: VGA, Audio, Power
- User Documentation



 Issue date 2023-03-26
 © 2023 Koninklijke Philips N.V.

 All Rights reserved.

 Version: 8.0.1
 Specifications are subject to change without notice.

 Trademarks are the property of Koninklijke Philips N.V.

 or their respective owners.

 12 NC: 8670 001 24686

www.philips.com

12 NC: 8670 001 24686 EAN: 87 12581 73154 0 * HDMI cables vary depending on region and models. * Response time value equal to SmartResponse