

PHILIPS

LED monitor

V Line

23" (58.4 cm)

236V3LSB



Enjoy great LED pictures in vivid colours

This attractive, slim display is a delight to use. Essential features like SmartContrast that ensure rich, bright images make it a great choice!

Great picture quality

- LED technology for natural colours
- SmartContrast 10,000,000:1 for incredibly rich black details
- 16:9 Full HD display for the best viewing experience

Design that complements any interior

- Attractive slim, glossy design
- Small footprint to blend into any lifestyle

Greener every day

- Mercury Free eco-friendly display
- Energy Star for energy efficiency and low power consumption

Great convenience

- Easy display performance tuning with SmartControl Lite

Highlights

LED technology

White LED's are solid state devices which light up to full, consistent brightness faster saving startup time. LED's are free from mercury content, which allows for eco-friendly recycling and disposal process. LED's allow for better dimming control of the LCD backlight, resulting in a super high contrast ratio. It also gives superior colour reproduction thanks to consistent brightness across the screen.

SmartContrast ratio 10,000,000:1



You want the LCD flat display with the highest contrast and most vibrant images. Philips advanced video processing combined with unique extreme dimming and backlight-boosting technology results in vibrant images. SmartContrast will increase the contrast with excellent black level and accurate rendition of

dark shades and colours. It gives a bright, lifelike picture with high contrast and vibrant colours.

16:9 Full HD



The Full HD screen has the widescreen resolution of 1920 x 1080p. This is the highest resolution of HD sources for the best possible picture quality. It is fully future-proof as it supports 1080p signals from all sources, including the most recent sources such as Blu-ray and advanced HD game consoles. The signal processing is extensively upgraded to support this much higher signal quality and resolution. It produces brilliant flicker-free progressive scan pictures with superb brightness and colours.

SmartControl Lite

SmartControl Lite is the next generation 3D icon-based GUI monitor control software. This allows the user to fine-tune most parameters

of the monitor like Colour, Brightness, screen calibration, Multimedia, ID management etc. with the mouse.

Mercury Free

Philips monitors with LED backlighting are free from Mercury, one of the most toxic natural substances, which affects humans and animals. This reduces the environmental impact of the display throughout its lifecycle, from manufacturing to disposal.

Energy Star 5.0

Energy Star is a US EPA sponsored energy efficiency programme also adopted by many other countries. Energy Star certification ensures that you are buying a product which meets the latest power efficiency standards and which operates with maximum power efficiency at all operational levels. New Philips monitors are certified for Energy Star 5.0 specifications and meet or exceed the standard. For example, in sleep mode Energy Star 5.0 requires less than 1 Watt power consumption, whereas Philips monitors consume less than 0.5 Watts. Further details can be obtained from www.energystar.gov



Specifications

Picture/Display

LCD panel type: TFT-LCD
Backlight type: W-LED system
Panel Size: 23 inch/58.4 cm
Effective viewing area: 509.18 (H) x 286.42 (V)
Aspect ratio: 16:9
Optimum resolution: 1920 x 1080 @ 60 Hz
Response time (typical): 5 ms
Brightness: 250 cd/m²
SmartContrast: 10,000,000:1
Contrast ratio (typical): 1000:1
Pixel pitch: 0.265 x 0.265 mm
Viewing angle: 170° (H)/160° (V), @ C/R > 10
Display colours: 16.7 M
Scanning Frequency: 30–83 kHz (H)/56–75 Hz (V)
sRGB

Connectivity

Signal Input: VGA (Analogue), DVI-D (digital, HDCP)
Sync Input: Separate Sync, Sync on Green

Convenience

User convenience: Auto, 4:3/Wide, Brightness, Menu, Power On/Off
OSD Languages: English, French, German,

Spanish, Italian, Russian, Simplified Chinese, Portuguese, Turkish
Other convenience: Kensington lock
Plug and Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 7

Stand

Tilt: -5/+20 degree

Power

On mode: 18.5 W (EnergyStar 5.0 test method)
Standby mode: 0.5 W
Off mode: 0.5 W
Power LED indicator: Operation - White, Standby mode - White (flashing)
Power supply: Built-in, 100–240 VAC, 50/60 Hz

Dimensions

Product with stand (mm): 566 x 426 x 219 mm
Product without stand (mm): 566 x 355 x 44 mm
Packaging in mm (W x H x D): 614 x 440 x 112 mm

Weight

Product with stand (kg): 3.19 kg
Product without stand (kg): 2.22 kg
Product with packaging (kg): 4.54 kg

Operating conditions

Temperature range (operation): 0°C to 40°C °C
Temperature range (storage): -20°C to 60°C °C
Relative humidity: 20%–80% %
MTBF: 30,000 hour(s)

Sustainability

Environmental and energy: EnergyStar 5.0, EPEAT Silver, RoHS, Lead-free, Mercury Free
Recyclable packaging material: 100 %

Compliance and standards

Regulatory Approvals: BSMI, CE Mark, FCC Class B, GOST, PSB, SASO, SEMKO, TUV Ergo, TUV/GS, UL/cUL, WEEE

Cabinet

Colour: Black
Finish: Glossy (front bezel)/Textured (rear cover)

