



Philips
LCD monitor

43 cm (17")

SXGA

170V7FB

Performance and convenience maximize your budget

This slim, compact 170V7 pumps up productivity with great performance and convenience while business-friendly features like lower power consumption deliver the best total cost of ownership.

Best total cost of ownership solution

- Empowered for Windows Vista
- Power consumption below the industry average
- TCO'03 guarantees the highest safety and ergonomic standards
- Environmentally responsible Energy Star partner

Outstanding front of screen performance

- SXGA 1280 x 1024 resolution for sharper display
- sRGB ensures color matching between display and printouts

Great convenience

- Embedded power supply eliminates external power adaptors
- Convenient, built in holder for notes, cards or photos

PHILIPS
sense and simplicity

Specifications

Picture/Display

- LCD panel type: 1280 x 1024 pixels, Anti-glare polarizer, RGB vertical stripe
- Panel Size: 17"/ 43 cm
- Effective viewing area: 13.3 x 10.6 inch
- Pixel pitch: 0.264 x 0.264 mm
- Brightness: 270 cd/m²
- Contrast ratio (typical): 500:1
- Display colors: 16.2 M
- Viewing angle: 160° (H) / 145° (V), @ C/R > 5
- Response time (typical): 8 ms
- White Chromaticity, 6500K: x = 0.313 / y = 0.329
- White Chromaticity, 9300K: x = 0.283 / y = 0.297
- Maximum Resolution: 1280 x 1024 @ 75 Hz (analog input)
- Optimum resolution: 1280 x 1024 @ 60 Hz (analog input)
- Video Dot Rate: 140 MHz
- Horizontal Scanning Frequency: 30 - 83 kHz
- Vertical Scanning Frequency: 56 - 76 Hz
- sRGB

Connectivity

- Signal Input: VGA (Analog)
- Sync Input: Composite Sync, Separate Sync, Sync on Green
- Video input impedance: 75 ohm
- Sync input impedance: 2.2k ohm
- Video input signal levels: 0.7 Vpp

Convenience

- User convenience: On-screen Display
- Monitor Controls: Auto, Brightness Control (Up/Down), Left/Right, Menu (OK), Power On/Off
- OSD Languages: English, French, Portuguese, Simplified Chinese, Spanish
- Other convenience: Kensington lock compatible, FlexiHolder
- Plug & Play Compatibility: DDC/CI, sRGB, Windows 98/ME/2000/XP/Vista

- Regulatory approvals: CE Mark, EMC, Energy Star, FCC-B, UL, CSA, SEMKO, TCO '03, TÜV/GS, TÜV Ergo
- Tilt: -5° to 25°
- VESA Mount: 100 x 100 mm

Accessories

- Included accessories: AC Power Cord, VGA cable
- Optional accessories: Super Ergo Base
- User Manual

Dimensions

- Box dimensions (W x H x D): 449 x 182 x 489 mm
- Box dimensions in inch (W x H x D): 17.7 x 7.2 x 19.3 inch
- Set dimensions (W x H x D): 380 x 327 x 57.5 mm
- Set dimensions in inch (W x H x D): 15 x 12.9 x 2.3 inch
- Set dimensions with stand (W x H x D): 380 x 387 x 200 mm
- Set dimensions with stand in inch (W x H x D): 15 x 15.2 x 7.9 inch
- MTBF: 50,000 hrs
- Relative humidity: 20% - 80%
- Temperature range (operation): 5°C to 40°C
- Temperature range (storage): -20°C to 60°C
- Product weight (+stand): 4.7 kg
- Product weight (lb): 10.4 lb
- Weight incl. Packaging: 6.1 kg
- Weight incl. Packaging (lb): 13.4 lb

Power

- Complies with: Energy Star
- Consumption (On mode): 30 W (Typical)
- Consumption (Off Mode): < 1 W
- Power LED indicator: Operation - green, Stand by/ sleep - Amber
- Power supply: Built-in, 100-240VAC, 50/60Hz

Highlights

Windows Vista ready

Philips Vista-ready monitors are empowered for vibrant, exciting display of this new, visually sophisticated and demanding Windows operating system, designed to enhance your entertainment experience, make you more productive and help you control your computing experience at home and in the office, making viewing, finding and organizing information for work or play quick, efficient and easy.

Lower power consumption

Reduction of the electrical power required to operate a device.

TCO '03 compliance

A TCO (Swedish Confederation of Professional Employees) standard even more stringent than MPR-II for safety and ergonomics, especially concerning alternating electric fields (AEF).

Energy Star partner

A manufacturer in compliance with power conservation requirements set forth by the Environmental Protection Agency of the U.S. government.

SXGA, 1280 x 1024 resolution

For graphics monitors, the screen resolution signifies the number of dots (pixels) on the entire screen. For example, a 1280-by-1024 pixel screen is capable of displaying 1280 distinct dots on each of 1024 lines, or about 1.3 million pixels.

sRGB ready

sRGB is an industry standard that ensures the best possible match between the colors displayed on your screen and those in your printouts.

Embedded power supply

An embedded power supply is a power adaptor built into the body of a display device that replaces a bulky external power adaptor.

FlexiHolder

FlexiHolder is a slim groove on the top of monitor that neatly and conveniently stores favorite photos, reminders, to-do lists or phone numbers in your line of sight.



Issue date 2011-06-07

Version: 4.0.5

12 NC: 8639 000 16928
UPC: 6 09585 11272 8

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com