



Philips  
LCD monitor with LED  
backlight

V Line  
19" (48.3 cm)

190V4LSB

## Enjoy great LED pictures in vivid colours

Enjoy vivid LED pictures with this attractive, glossy design display. Equipped with SmartControl lite, it's a great choice!

### **Vivid pictures every time**

- Easy display performance tuning with SmartControl Lite
- LED technology for vivid colours
- SmartContrast for rich black details
- Bigger viewing area with 16:10 format

### **Modern design**

- Attractive glossy design
- Small footprint saves space
- VESA mount allows for flexibility

### **Greener every day**

- Mercury Free eco-friendly display
- Low power consumption saves energy bills
- Energy Star for energy efficiency and low power consumption

# PHILIPS

LCD monitor with LED backlight  
V Line 19" (48.3 cm)

190V4LSB/00

# Highlights

## LED technology

White LED's are solid state devices which light up to full, consistent brightness faster saving startup time. LED's are free from mercury content, which allows for eco-friendly recycling and disposal process. LED's allow for better dimming control of the LCD backlight, resulting in a super high contrast ratio. It also gives superior colour reproduction thanks to consistent brightness across the screen.

## SmartControl Lite

SmartControl Lite is the next generation 3D icon-based GUI monitor control software. This allows the user to fine-tune most parameters of the monitor like Colour, Brightness, screen calibration, Multimedia, ID management etc. with the mouse.

## SmartContrast



SmartContrast is a Philips technology that analyses the contents you are displaying, automatically adjusting colours and controlling backlight intensity to dynamically enhance contrast for the best digital images and videos or when playing games where dark hues are displayed. When Economy mode is selected, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.

## Mercury Free

Philips monitors with LED backlighting are free from Mercury, one of the most toxic natural

substances, which affects humans and animals. This reduces the environmental impact of the display throughout its lifecycle, from manufacturing to disposal.

## 16:10 bigger viewing area

Bigger viewing area with 16:10 format

## Low power consumption

Low power consumption saves energy bills

## Attractive glossy design

Attractive glossy design

## Small footprint saves space


Small footprint saves space

## VESA mount

VESA mount allows for flexibility

## Energy Star

Energy Star for energy efficiency and low power consumption



# Specifications

## Connectivity

- Signal Input: VGA (Analogue), DVI-D (digital, HDCP)
- Sync Input: Separate Sync, Sync on Green

## Picture/Display

- Panel Size: 19 inch/48.3 cm
- Aspect ratio: 16:10
- LCD panel type: TFT-LCD
- Backlight type: W-LED system
- Pixel pitch: 0.2835 x 0.2835 mm
- Optimum resolution: 1440 x 900 @ 60 Hz
- Brightness: 250 cd/m<sup>2</sup>
- Display colours: 16.7 M
- Contrast ratio (typical): 1000:1
- SmartContrast: 10,000,000:1
- Response time (typical): 5 ms
- Viewing angle: 170° (H)/160° (V), @ C/R &gt; 10
- Effective viewing area: 408.24 (H) x 255.15 (V)
- Scanning Frequency: 30–83 kHz (H)/56–75 Hz (V)
- sRGB

## Convenience

- Plug and Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 7, Windows XP
- User convenience: Auto/Down, 4:3 Wide/Up, Brightness/Back, Menu/OK, Power On/Off
- OSD Languages: English, French, German, Italian, Portuguese, Russian, Simplified Chinese, Spanish, Turkish
- Other convenience: Kensington lock, VESA mount (100 x 100 mm)

## Stand

- Tilt: -5/20 degree

## Power

- Power supply: Built-in, 100–240 VAC, 50–60 Hz

- Off mode: 0.5 W (typ.)
- On mode: 12.01 W (typ.) (EnergyStar 6.0 test method)
- Standby mode: 0.5 W (typ.)
- Power LED indicator: Operation - White, Standby mode - White (flashing)

## Dimensions

- Product with stand (mm): 442 x 373 x 201 mm
- Packaging in mm (W x H x D): 490 x 378 x 124 mm
- Product without stand (mm): 442 x 305 x 48 mm

## Weight

- Product with packaging (kg): 4.03 kg
- Product with stand (kg): 2.98 kg
- Product without stand (kg): 2.65 kg

## Operating conditions

- Temperature range (operation): 0°C to 40°C °C
- MTBF: 30,000 hour(s)
- Relative humidity: 20%–80% %
- Temperature range (storage): -20°C to 60°C °C

## Sustainability

- Environmental and energy: EnergyStar 6.0, RoHS, Mercury Free
- Recyclable packaging material: 100 %

## Compliance and standards

- Regulatory Approvals: BSMI, CE Mark, FCC Class B, GOST, PSB, SASO, SEMKO, TCO Certified, TUV/ISO9241-307, UL/cUL, WEEE

## Cabinet

- Colour: Black
- Finish: Glossy (front bezel)/Textured (rear cover)



Issue date 2024-04-01

Version: 2.0.1

EAN: 87 12581 65339 2

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)