



4K HDR display with Ambiglow

- Momentum
- 43 (42.51" / 108 cm diag.)
- 3840 x 2160 (4K UHD)

436M6VBRAB/01

Get in the moment

The Momentum display with HDR and immersive Ambiglow lighting brings you to experience a new level of entertainment immersion. HDR technology with an expansive UHD display gives impeccable picture quality to reveal fine details.

Benefits

Expand your viewing experience

- UltraClear 4K UHD (3840x2160) resolution for precision
- MultiView 4K for 4 systems on one screen

Superb Picture Quality

- High Dynamic Range (HDR) for more lifelike colorful visuals
- Ultra Wide-Color wider range of colors for a vivid picture

Brilliant performance

- Ambiglow intensifies entertainment with halo of light

- Enhanced audio with DTS Sound™
- Low input lag reduces time delay between devices to monitor
- Effortlessly smooth action with Adaptive-Sync technology


Designed for the way you work

- All your connections through one USB-C cable
- USB 3.0 Hub for convenient access and fast charging

PHILIPS


Features

UltraClear 4K UHD Resolution



These Philips displays utilize high performance panels to deliver UltraClear, 4K UHD (3840 x 2160) resolution images. Whether you are demanding professional requiring extremely detailed images for CAD solutions, using 3D graphics applications or a financial wizard working on huge spreadsheets, Philips displays will make your images and graphics come alive.

MultiView technology for 4K



Philips MultiView feature on this expansive 4K UHD display enables you to have up to four systems each shown in Full HD on one screen. You can use the Picture-by-Picture (PbP) for monitoring four systems on one screen for control rooms or security. Or for multiple devices like two notebooks side-by-side simultaneously, making collaboration more productive. Or Picture-in-Picture mode (PiP) watching a live football feed from your set-top box, while working on your PC.

High Dynamic Range (HDR)




High Dynamic Range delivers a dramatically different visual experience. With astonishing brightness, incomparable contrast and captivating color, images come to life with much greater brightness while also featuring much deeper, more nuanced darks. It renders a fuller palette of rich new colors never before seen on display, giving you a visual experience that engages your senses and inspires emotions.

Ultra Wide-Color Technology



Ultra Wide-Color Technology delivers a wider spectrum of colors for a more brilliant picture. Ultra Wide-Color wider "color gamut" produces more natural-looking greens, vivid reds and deeper blues. Bring media entertainment, images, and even productivity more alive and vivid colors from Ultra Wide-Color Technology.

Ambiglow Technology




Ambiglow adds a new dimension to your viewing experience. The innovative Ambiglow technology enlarges the screen by creating an immersive halo of light. Its fast processor analyses the incoming image content and continuously adapts the color and brightness of the emitted light to match the image. User friendly options allow you to adjust the ambiance to your liking. Especially suited for watching movies, sports or playing games, Philips Ambiglow offers you a unique and immersive viewing experience.

DTS Sound™

DTS Sound is an audio processing solution designed to optimize the playback of music, movies, streaming and games on the PC regardless of form factors. DTS Sound enables an immersive virtual surround sound experience, complete with rich bass and dialog enhancement and maximized volume levels free of any clipping or distortion.

Low Input Lag



Input lag is the amount of time that elapses between performing an action with connected devices and seeing the result on screen. Low input lag reduces the time delay between entering a command from your devices to monitor, greatly improve on playing twitch-sensitive video games, particularly important to whom plays fast-paced, competitive games.

Adaptive-Sync technology



Gaming shouldn't be a choice between choppy gameplay or broken frames. Get fluid, artifact-free performance at virtually any framerate with Adaptive-Sync technology, smooth quick refresh and ultra-fast response time.

USB-C cable

The new USB 3.1 Type-C cable with a slim and reversible connector, offers easy one-cable-docking. Simplify by connecting all your peripherals to your monitor as a dock with one cable to the notebook, including high resolution video output from your PC to monitor. With USB 3.1 you also get fast data transfer, up-to 20-times as fast as USB 2.0, allowing you to transfer a 4K movie faster than ever. All your connections through one simple cable.

USB 3.0 Hub with FastCharge

Super Speed USB 3.0 deploys 5.0 gbit/s transfer rate, which is about 10 times faster than USB 2.0 standard significantly reducing data transfer time saving you time and money. With more bandwidth, super speed transfer rates, better power management and superior overall performance, USB 3.0 sets the latest global standard allowing you to use the large capacity storage devices. Now you don't have to wait so long for devices to charge. New FastCharge enables quick charging to charge and go. USB 3.0 is also backward compatible with USB 2.0 devices.

Specifications

[field not found 'disclaimer_text']

Picture/Display

LCD panel type	MVA
Adaptive sync	Yes
Backlight type	W-LED system
Panel Size	42.51 inch / 108 cm
Display Screen Coating	Anti-Glare, 3H, Haze 2%

Color gamut (min.)	BT. 709 Coverage: 100%*; DCI-P3 Coverage: 97.6%*
HDR	DisplayHDR400 certified
Effective viewing area	941.18 (H) x 529.42 (V)
Aspect ratio	16:9
Optimum resolution	3840 x 2160 @ 60 Hz
Pixel Density	103.64 PPI

Response time (typical)	4 ms (Gray to Gray)*
Brightness	450 cd/m ²
Contrast ratio (typical)	4000:1
SmartContrast	50,000,000:1
Pixel pitch	0.245 x 0.245 mm
Viewing angle	178° (H) / 178° (V) @ C/R > 10
Flicker-free	Yes
Picture enhancement	SmartImage
Display colors	1.07 billion colors (10 bit*)
Scanning Frequency	23 - 80 Hz (V) / 30 - 160 kHz (H)
sRGB	Yes
LowBlue Mode	Yes

Connectivity

Signal Input	VGA (Analog) DisplayPort 1.4 x 1 HDMI 2.0 x 2 USB-C (DP Alt mode)
USB Sync Input	USB 3.0x3 (1 w/fast charging)* Separate Sync Sync on Green
Audio (In/Out)	PC audio-in Headphone out

Convenience

Remote control type	Philips RC6 remote control
Built-in Speakers	7 W x 2 with DTS sound
MultiView	PIP/PBP mode 4x devices
User convenience	Menu/OK Input/Up SmartImage Game/Return Volume/Down Power On/Off
Control software	SmartControl
OSD Languages	Brazil Portuguese Czech Dutch English Finnish French German Greek Hungarian Italian Japanese Korean Polish Portuguese Russian Simplified Chinese Spanish Swedish Traditional Chinese Turkish Ukrainian
Other convenience	Ambiglow Low Input Lag Kensington lock VESA mount (200x200mm)
Plug & Play Compatibility	DDC/CI Mac OS X sRGB Windows 10 / 8.1 / 8 / 7

Stand

Tilt	-5/10 degree
------	--------------

Power

On mode	120 W (typ.)
Standby mode	0.5 W (typ.)

Off mode	0.3 W (typ.)
Energy Label Class	C
Power LED indicator	Operation - White Standby mode- White (blinking)
Power supply	Internal 100-240VAC, 50-60Hz

Dimensions

Product with stand (mm)	976 x 661 x 264 mm
Product without stand (mm)	976 x 574 x 63 mm
Packaging in mm (WxHxD)	1090 x 764 x 338 mm

Weight

Product with stand (kg)	12.72 kg
Product without stand (kg)	11.97 kg
Product with packaging (kg)	18.84 kg

Operating conditions

Temperature range (operation)	0 to 40 °C
Temperature range (storage)	-20 to 60 °C
Relative humidity	20%-80 %
Altitude	Operation: +12,000ft (3,658m), Non-operation: +40,000ft (12,192m)
MTBF	50,000 hrs (excluding backlight) hour(s)

Sustainability

Environmental and energy	RoHS Mercury Free WEEE
Recyclable packaging material	100 %

Compliance and standards

Regulatory Approvals	CCC CECP KC KCC PSE VCCI J-MOSS BSMI SEMKO RCM CE Mark FCC Class B EAC cETLus TUV/ISO9241-307 PSB E-standby SASO CB China RoHS UKRAINIAN Kuwait KUCAS ICES-003
----------------------	---

Cabinet

Color	Black
Finish	Glossy / Textured

- * Response time value equal to SmartResponse
- * Fast charging complies with USB BC 1.2 standard
- * For Video transmission via USB-C, your Notebook/device must support USB-C DP Alt mode
- * The monitor may look different from feature images.
- * BT. 709 / DCI-P3 Coverage based on CIE1976
- * 10 bit is dithered by 8 bit with FRC



data subject to change
2021, March 1

Version: 8.0.1
EAN: 8712581748852

© 2021 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com