



Philips
LCD monitor

43 cm (17")
SXGA

170C5BS

elegance matters

Designed for you! Matching superb front-of-screen performance and convenience with elegant design, the 170C5 delivers great value for the money while adding style to any room with sleek lines and cool colors.

Outstanding front of screen performance

- 12ms On/off response time: Superior text and graphics display
- SXGA 1280 x 1024 resolution for sharper display
- sRGB ensures color matching between display and printouts

Design that complements any interior

- Sleek, elegant design complements your home decor
- Compact and slim design that fits in every room

Best Value for Money

- TCO'03 guarantees the highest safety and ergonomic standards
- Power consumption below the industry average

Great convenience

- Embedded power supply eliminates external power adaptors
- Auto adjustment for perfect picture display with one touch
- Easy to adjust display settings with Philips SmartControl

PHILIPS

Highlights

12ms response time (On-Off)

On-Off response time is the period required for a liquid crystal cell to go from active (black) to inactive (white) and back to active (black) again. It is measured in milliseconds. Faster is better: Lower response time means faster transitions and, therefore, results in fewer visible image artifacts in the display of transition of text and graphics. On-Off response time is a more important measure in the display of business content like documents, graphs and photos.

SXGA, 1280 x 1024 resolution

For graphics monitors, the screen resolution signifies the number of dots (pixels) on the entire screen. For example, a 1280-by-1024 pixel screen is capable of displaying 1280 distinct dots on each of 1024 lines, or about 1.3 million pixels.

sRGB ready

sRGB is an industry standard that ensures the best possible match between the colors

displayed on your screen and those in your printouts.

Sleek, elegant design

A sleek, elegant design look that complements home furnishings in any room.

Compact and slim design

This design style emphasizes a slim, compact look that saves space and fits in anywhere.

TCO '03 compliance

A TCO (Swedish Confederation of Professional Employees) standard even more stringent than MPR-II for safety and ergonomics, especially concerning alternating electric fields (AEF).

Lower power consumption

Reduction of the electrical power required to operate a device.

Embedded power supply

An embedded power supply is a power adaptor built into the body of a display device that replaces a bulky external power adaptor.

One-touch auto adjustment

The auto adjustment key restores optimal screen position, phase and clock settings with the press of a single button - without navigation through OSD menus and control keys.

SmartControl

PC software for fine tuning display performance and settings. Philips offers users two choices for display setting adjustment. Either navigate the multilevel On Screen Display menu through buttons on the display itself or use the Philips SmartControl software to easily adjust the various display settings in a familiar way.



Specifications

Picture/Display

- LCD panel type: 1280 x 1024 pixels, Anti-glare polarizer, RGB vertical stripe
- Panel Size: 17" / 43 cm
- Effective viewing area: 337.9 x 270.3 mm
- Pixel pitch: 0.264 x 0.264 mm
- Brightness (nits): 250 nit
- Contrast ratio (typical): 500:1
- Display colors: 16.2 M
- Viewing angle: @ C/R > 5
- Viewing angle (H / V): 160 / 160 degree
- Response time (typical): 12 ms
- White Chromaticity, 6500K: $x = 0.313$ / $y = 0.329$
- White Chromaticity, 9300K: $x = 0.283$ / $y = 0.297$
- Maximum Resolution: 1280 x 1024 @ 75Hz
- Optimum resolution: 1280 x 1024 @ 60Hz
- Factory Preset Modes: 15 modes
- User definable modes: 16 modes
- Video Dot Rate: 140 MHz
- Horizontal Scanning Frequency: 30 - 83 kHz
- Vertical Scanning Frequency: 56 - 76 Hz
- sRGB

Connectivity

- Signal Input: VGA (Analog)
- Sync Input: Composite Sync, Separate Sync, Sync on Green

Convenience

- Buttons and controls: Customized hot key, Side keys
- User convenience: On-screen Display, SmartControl

- Monitor Controls: Auto, Brightness Control, Left/Right, Menu (OK), Power On/Off, Up/Down
- OSD Languages: English, French, German, Italian, Simplified Chinese, Spanish
- Other convenience: Kensington lock compatible
- Plug & Play Compatibility: DDC/CI, sRGB, Windows 98/ME/2000/XP
- Regulatory approvals: CE Mark, E2000, EMC, Energy Star, FCC-B, UL, CSA, SEMKO, TCO '03, TÜV/GS, TÜV Ergo
- Tilt: -5° to 25°
- VESA Mount: 100 x 100 mm

Accessories

- Included accessories: AC Power Cord, VGA cable
- User Manual

Dimensions

- Dimensions (with base) (W x H x D): 399 x 390 x 174 mm
- MTBF: 50,000 hrs
- Relative humidity: 20% - 80%
- Temperature range (operation): 5°C to 35°C
- Temperature range (storage): -20°C to 60°C
- Weight: 4.5 kg

Power

- Complies with: E2000, Energy Star, NUTEK
- Consumption (On mode): 30W (Typical)
- Consumption (Off Mode): < 1 W
- Power LED indicator: Operation - green, Stand by/sleep - Amber
- Power supply: Built-in, 90-264 VAC, 50/60 Hz



Issue date 2022-05-11

Version: 3.0.4

12 NC: 8639 000 15723
EAN: 87 10895 85776 5

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com