

Philips
Professional LCD TV

81 cm (32")

LCD
Pro:Idiom™ with MPEG-4

32HFL5860D



The Optimal Hospitality TV

SmartCard, MPEG-4 and Pro:Idiom™ Plus

Top performance for guests and bottom line savings for you. SmartPower² and Five Star Service increase your bottom line and SmartCard allows integration with all major PPV providers. MPEG-4 compatibility with the latest satellite systems.

Best total cost of ownership

- SmartPower² and ESP for energy savings
- Five Star Service - two-year advanced exchange warranty
- On-shore 24/7 help desk

Sustainable and safe

- Lead-free/RoHS compliant with flame retardant housing

Designed for hotel use

- SmartClone for substantial time savings
- MPEG-4 for the latest HD signals
- HD content protection with Pro:Idiom™ Plus
- VTrack™ forensic watermark
- SmartStand

Differentiating guest experience

- USB media autoplay
- SmartWindow for simultaneous TV viewing and PC use

PHILIPS

Highlights

SmartClone

Philips remains on the forefront of making installation as simple as possible. SmartClone offers USB cloning, or on select models, revolutionary RF cloning, which allows all TV's on property to be programmed in as little as five minutes. Additional hardware is required to take advantage of RF cloning.

Pro:Idiom™ Plus

Pro:Idiom™ was created for the hospitality industry to protect first run movies and other HD premium content from piracy. Philips Pro:Idiom™ Plus televisions offer secure HD content protection not only for PPV hotels, but now also for stand alone properties. (Additional fees may apply for stand alone use) (Pro:Idiom™ is a trademark of the Zenith Corp.)

VTrack™ forensic watermark

Philips VTrack™ watermarking embeds an invisible forensic watermark in the signal, which can be detected via software to trace pirated content back to the source of recording. Philips VTrack™ is the first solution that protects first run movies and other premium content from optical piracy, helping preserve the early release window that hotels have always enjoyed.

MPEG-4 for HD

MPEG-4 (Moving Picture Experts Group H.264) compression technology allows more

HD content to be delivered than ever before. Satellite providers are already using MPEG-4 to offer the choice of up to 150 national HD channels and 1,500 local broadcast HD and digital channels. Cable, broadcast, and telecommunications providers are expected to also migrate to the format, but with these Philips TVs you are ready today!

SmartStand

This TV comes with a swivel stand that allows your guests to adjust the TV up to 180 degrees so that they can watch TV from any position in the room. Equipped with built-in security, this stand can be secured to a table or furniture to deter theft.

Five Star Service

Philips offers unmatched commitment to keeping your guest rooms in working order. Our products are so reliable that we offer a two-year advanced exchange warranty. In the event that something does go wrong, we guarantee to ship a replacement set to you, within 72 hours during the first year.

SmartPower² and ESP

Our second generation power saving technology allows the backlight intensity to be dynamically adjusted by the system to reduce the power consumption by up to 60%, saving substantially on energy costs. In addition, Philips' Energy Savings Programmability (ESP) allows the set to turn itself off when not in use

to save even more energy when guests or maids leave televisions on for long periods while the room is vacant.

On-shore 24/7 help desk

Your hotel never closes, and neither do we. We offer a 24/7 Help Desk staffed by knowledgeable and friendly personnel to help you with any aspect of your Philips TV install or use.

RoHS & Flame retardant housing

In addition to being lead-free and RoHS compliant, Philips TVs have a special housing of eco-friendly, non-brominated flame-retardant materials. Independent tests carried out by emergency fire services have shown that whereas TVs can sometimes intensify fires caused by external sources, Philips TVs will not contribute to the fire.

USB media autoplay

Philips TVs feature a USB connector that allows the guest to connect USB memory sticks to play music or photos right on the TV.

SmartWindow

SmartWindow allows your guests the added convenience of working on their laptop PC's on one half of the screen while enjoying the TV content of their choice on the other half. The perfect balance of work and leisure.

Specifications

Picture/Display

- Aspect ratio: 16:9, Widescreen
- Diagonal screen size (inch): 32 inch
- Diagonal screen size (metric): 80 cm
- Color cabinet: Black w/gloss black bezel
- Panel resolution: 1366 x 768p
- Brightness: 500 cd/m²
- Picture enhancement: Pixel Plus 3 HD, Progressive scan, 3/2 - 2/2 motion pull down, Active Control, 3D Combfilter, Dynamic contrast enhancement, Contrast Plus, Digital Noise Reduction, Jagged Line Suppression, Luminance Transient Improver, Color Transient Improvement, Automatic skin tone correction, Color Enhancement, Motion adaptive de-interlacing, Picture in Picture
- Contrast ratio (typical): 1200:1
- Display screen type: LCD WXGA Active Matrix TFT
- Dynamic screen contrast: 9600:1
- Response time (typical): 8 ms
- Viewing angle (horizontal): 178 degree
- Viewing angle (vertical): 178 degree
- Screen enhancement: Anti-Reflection coated screen

Supported Display Resolution

- Computer formats: 640 x 480, 60Hz, 800 x 600, 60Hz, 1024 x 768, 60Hz, 1366 x 768, 60Hz
- Video formats: 480i, 60Hz, 480p, 60Hz, 720p, 60Hz, 1080i, 60Hz, 1080p, 24, 25, 30Hz, 1080p, 24, 50, 60Hz

Tuner/Reception/Transmission

- Aerial Input: 75 ohm F-type
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: ATSC, NTSC
- Cable: Unscrambled Digital Cable QAM
- Number of Preset Channels: 250
- Video Playback: NTSC, PAL
- Terrestrial: ATSC (8VSB)

Multimedia Applications

- Multimedia connections: USB
- Playback Formats: JPEG Still pictures, MP3, Slideshow files (.alb)

Convenience

- Ease of Installation: Fine Tuning, PLL Digital Tuning, Program Name, Advanced Hotel Mode, Cloning of TV settings via USB, Keyboard lock-out, Security menu access
- Ease of Use: Auto Volume Leveller (AVL), Smart Picture, Smart Sound
- User convenience: Closed captioning (digital), Vchip and parental lock
- Comfort: Hotel Guest features, Sleep timer, Switch on channel, Volume limitation, Welcome message
- Screen Format Adjustments: 4:3, 7 Widescreen

Modes

- Interactive hotel features: Smoovie Pay TV
- Other convenience: Kensington lock

Sound

- Output power (RMS): 2 x 10W
- Sound System: Stereo, Dolby Digital (AC-3)
- Sound Enhancement: Auto Volume Leveler, Incredible Surround

Loudspeakers

- Built-in speakers: 2

Connectivity

- AV 1: AV In, S-Video Y/C
- Connectivity Enhancements: SmartCard Expansion Slot, HM-Link, Extra Power supply 12V/1W, External Loudspeaker connector, USB2.0, RJ12 SmartPlug connector
- AV 2: Audio L/R in, YPbPr
- Audio Output - Digital: Coaxial (cinch)
- AV 3: VGA PC-in, Audio-in mini jack 3.5mm
- AV 4: HDMI
- AV 5: HDMI
- Other connections: Antenna F-type, RS232 Serial

Power

- Mains power: 110 - 240V, 50/60Hz
- Ambient temperature: 5 °C to 40 °C
- Standby power consumption: 1.16
- Power use SmartPower² = off: < 135 W
- Power use SmartPower² = high: < 58 W

Green Specifications

- Safety: Flame retardant housing
- Eco Designed
- SmartPower²

Accessories

- Included accessories: Warranty Leaflet, Swivel stand with anti-theft, Quick start guide, Power cord (2m)
- Optional accessories: Set up Remote RC2573GR, Mounting brackets/ stands, Guest remote control

Dimensions

- Wall mount compatible: 200 x 100 mm
- Set Width (inch): 31.7 inch
- Set Height (inch): 21.5 inch
- Set Depth (inch): 4.4 inch
- Product weight (lb): 34.1 (with stand), 25.7 (without stand) lb
- Set width (with stand) (inch): 31.7 inch
- Set depth (with stand) (inch): 10.4 inch
- Set height (with stand) (inch): 24 inch
- Box depth (inch): 13.6 inch
- Weight incl. Packaging (lb): 44.5
- Box height (inch): 24.8 inch
- Box width (inch): 34.2 inch



Issue date 2023-10-05

Version: 7.1.9

UPC: 6 09585 15019 5

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Five Star Advanced Exchange warranty is valid in the United States only. Local warranties govern sales in other countries.