

Philips
Professional LCD TV

81 cm (32")

LCD
HD Ready

32HF5335D



Advanced design and outstanding value

Philips HD LCD TV for Hospitality

This professional LCD TV with Smart Hotel Mode offers convenient setup and advanced programming features not found on retail televisions backed by our unique Five Star Service advanced exchange warranty. Ideal for hotels with no PPV system.

Best total cost of ownership

- USB cloning of all settings for quick installation
- Low power consumption
- Five Star Service - two-year advanced exchange warranty

Sustainable and safe

- Eco-friendly Design
- Flame retardant housing

Advanced hotel features and future proof

- 2 HDMI inputs for full digital HD connection in one cable
- Smart Hotel Mode

Great viewing experience and guest comfort

- HDTV for Hospitality
- Pixel Plus 3 HD image enhancement

PHILIPS

Highlights

Smart Hotel Mode

Allows configuration of the TV for limited access, ideal for hotel use. Access to the user menu can be blocked, which enables you to specify channel, picture, and sound settings which your guest will be unable to modify. Picture and sound preferences may be selected from presets on the remote, offering guest selection, but never overwriting your defined settings. Switch on and maximum volume can also be specified so the set always turns on and operates at a comfortable volume. Channels can be blanked to prevent access to premium or adult content. Includes a forced power on mode.

2 HDMI inputs

HDMI makes an uncompressed digital RGB connection from the source to the screen. By eliminating conversion to an analog signal, it delivers an unblemished image. The non-degraded signal reduces flicker and leads to a clearer picture. HDMI intelligently communicates the highest output resolution with the source device. The HDMI input is fully backward compatible with DVI sources but includes digital audio. HDMI uses HDCP copy protection. With 2 HDMI inputs you can connect multiple HD sources, for instance an HD settop box, and a Blu-ray player. Your TV is fully prepared for the HD future.

HDTV for Hospitality

There are many ways you may choose to offer HDTV to your guests, but regardless of the

source, Philips Hospitality televisions will always deliver the best viewing experience possible to your guests by utilizing the most advanced FlatTV displays and award winning technologies such as Pixel Plus 3 HD.

Pixel Plus 3 HD

Pixel Plus 3 HD offers an optimal combination of sharpness, natural detail, vivid colors, and smooth natural motion on any video source, including high definition.

Five Star Service

Philips offers unmatched commitment to keeping your guest rooms in working order. Our products are so reliable that we offer a two-year advanced exchange warranty. In the event that something does go wrong, we guarantee to ship a replacement set to you, within 72 hours during the first year.

USB Cloning



Provides the ability to easily copy all programming and channel programming settings from one TV into other TV sets in less than a

minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

Low power consumption

Philips TVs are designed to minimize power consumption. This will not only reduce environmental impact but also lower operating costs.

Eco-friendly Design

Philips TVs are designed and produced according to our EcoDesign principles aimed at minimizing overall environmental impact, through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability.

Flame retardant housing

Philips TVs have a special housing of flame retardant material. Independent tests carried out by emergency fire services have shown that whereas TVs can sometimes intensify fires caused by external sources, Philips TVs will not contribute to the fire.

Specifications

Picture/Display

- Aspect ratio: 16:9, Widescreen
- Diagonal screen size (inch): 32 inch
- Diagonal screen size (metric): 80 cm
- Panel resolution: 1366 x 768p
- Brightness: 500 cd/m²
- Picture enhancement: Pixel Plus 3 HD, Progressive scan, 3/2 - 2/2 motion pull down, Active Control, 3D Combfiter, Dynamic contrast enhancement
- Display screen type: LCD WXGA Active Matrix TFT
- Dynamic screen contrast: 3200:1
- Response time (typical): 8 ms
- Viewing angle (horizontal): 176 degree
- Viewing angle (vertical): 176 degree
- Screen enhancement: Anti-Reflection coated screen

Supported Display Resolution

- Video formats: 480i, 60Hz, 480p, 60Hz, 720p, 60Hz, 1080i, 60Hz

Tuner/Reception/Transmission

- Aerial Input: 75 ohm F-type
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: ATSC, NTSC
- Cable: Unscrambled Digital Cable QAM
- Video Playback: NTSC

Multimedia Applications

- Digital Content Management: Digital Media Reader
- Multimedia connections: USB memory class device
- Playback Formats: JPEG Still pictures, MP3, Slideshow files (.alb)

Convenience

- Child Protection: Child Lock+Parental Control
- Ease of Installation: Autostore, PLL Digital Tuning, Plug & Play
- Ease of Use: On Screen Display, Side Control
- Screen Format Adjustments: 7 Widescreen Modes, Auto Format
- Remote control type: RC2033601

Sound

- Equalizer: 5-bands
- Output power (RMS): 2 x 10W
- Sound System: Dolby Digital (AC-3), Virtual Dolby Surround

Loudspeakers

- Built-in speakers: 2

Connectivity

- AV 1: Audio L/R in, CVBS in, YPbPr
- AV 2: Audio L/R in, YPbPr
- Audio Output - Digital: Coaxial (cinch)
- AV 3: HDMI
- Front / Side connections: Audio L/R in, CVBS in, Headphone Out, S-video in, USB
- Other connections: HDMI

Power

- Mains power: 100-250V, 50-60Hz
- Ambient temperature: 5 °C to 40 °C
- Power consumption: 140 W
- Standby power consumption: < 1 W

Accessories

- Included accessories: User Manual, Remote Control, Quick start guide, Power cord, Tabletop swivel stand, Warranty Leaflet

Dimensions

- Wall mount compatible: 200 x 100 mm
- Set Width (inch): 31.6 inch
- Set Height (inch): 21.5 inch
- Set Depth (inch): 4.6 inch
- Product weight (lb): 38.5 (with stand), 32.1 (without stand) lb
- Set width (with stand) (inch): 31.7 inch
- Set depth (with stand) (inch): 8.3 inch
- Set height (with stand) (inch): 24 inch
- Box depth (inch): 11.4 inch
- Weight incl. Packaging (lb): 51.8
- Box height (inch): 24.8 inch
- Box width (inch): 34.2 inch



Issue date 2023-10-05

Version: 3.0.17

UPC: 6 09585 13373 0

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Five Star Advanced Exchange warranty is valid in the United States only. Local warranties govern sales in other countries.