

PHILIPS

Professional LCD TV

32" PrimeSuite

LCD

DVB-T/C MPEG 2/4

32HFL4372D



Versatile and outstanding in every way

Philips Hospitality LCD TV

This modern Hospitality TV brings more guest convenience to the room. It also allows you to show HD channels to your guests in both standalone and interactive set-up.

Sustainable and safe

- Low power consumption
- Eco-friendly design and flame-retardant housing

Differentiating guest experience

- Volume limitation
- Integrated clock display with wake-up and message alarm
- Advanced EPG and channel list
- USB for fantastic multimedia playback

Advanced hotel features and future proof

- MyChoice compatibility for recurring revenues
- Theme TV for easy location of guests' own national channels
- Programmable Switch On Channel
- VSecure for digital content protection in hotels
- Integrated Connectivity Panel
- One combined channel list for Analogue and Digital channels

Highlights

MyChoice compatible




MyChoice offers a simple and low-cost way to offer your guests premium TV channels. At the same time it delivers an additional revenue stream which allows you to recover your initial TV investment.

Integrated Connectivity Panel

The Integrated Connectivity Panel allows your guests to seamlessly connect their personal devices to your TV without the need for an external Connectivity Panel.

Theme TV



Theme TV offers an advanced user interface that enables your guests to navigate the guest menu to find their own country's channels, news and hotel information easily without the need of an interactive entertainment system.

VSecure

To show HD premium content to the guest there is a need for strict content security precautions from the content industry. Philips

has developed a total solution for HD content security in hotels, consisting of VSecure for HD content protection and NexGuard for HD forensic watermarking.

Integrated clock display

The built-in clock display, which is also a wake-up alarm, eliminates the need to invest in an additional clock with cables and connections in the room.

Installation menu locking

Prevents unauthorised access to installation and configuration settings, to ensure maximum guest convenience and avoid unnecessary reprogramming costs.

USB (multimedia)



The USB connector allows access to jpeg photos, MP3 music and video files on most USB sticks (USB memory-class device). Plug the USB into the slot on the side of the TV and access the multimedia content using the easy on-screen content browser. You can now view and share your videos, photos and music.

Volume limitation

This feature predefines the volume range within which the TV set is allowed to operate, preventing excessive volume adjustments and disturbance of neighbouring guests.

Low power consumption

Philips TVs are designed to minimise power consumption. This will not only reduce environmental impact but also lower operating costs.

Eco-friendly design

Sustainability is integral to the way Philips does business. Philips TVs are designed and produced according to our EcoDesign principles aimed at minimising overall environmental impact, through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability. Philips TVs also have a special housing of flame-retardant material. Independent tests carried out by emergency fire services have shown that whereas TVs can sometimes intensify fires caused by external sources, Philips TVs will not contribute to a fire.

Advanced EPG and channel list

The attractive EPG and channel list include intuitive buttons with clear guiding graphics to easily locate your favourite channels.

Programmable Switch On Channel

Perfect for in-house advertising or information channels as it allows a predefined channel to be shown when the TV is turned on.

One combined channel list

One integrated channel list for digital and analogue channels. This allows the guest to flick seamlessly between Analogue and Digital channels.

Specifications

Picture/Display

Aspect ratio: Widescreen

Diagonal screen size (inch): 32 inch

Diagonal screen size (metric): 81 cm

Colour cabinet: High gloss black deco front with black cabinet

Brightness: 450 cd/m²

Picture enhancement: 3/2 - 2/2 motion pull down, 3D Combfilter, Active Control, Colour Enhancement, Colour Transient Improvement, Digital Noise Reduction, Luminance Transient Improver, Progressive scan, Sharpness Adjustment, 3D MA deinterlacing, Automatic skin tone correction, Dynamic contrast enhancement, 1080p 24/25/30 Hz processing, 1080p 50/60 Hz processing, Pixel Plus HD

Display screen type: LCD WXGA+ Active Matrix TFT

Panel resolution: 1366 x 768p

Dynamic screen contrast: 150,000:1

Response time (typical): 8 ms

Viewing angle: 178° (H)/178° (V)

Peak Luminance ratio: 74 %

Screen enhancement: Anti-Reflection coated screen

Supported Display Resolution

Computer formats: 640 x 480, 60 Hz, 800 x 600, 60 Hz, 1024 x 768, 60 Hz, 1280 x 1024, 60 Hz, 1280 x 720, 60 Hz, 1280 x 768, 60 Hz, 1360 x 768, 60 Hz

Video formats: 480i, 60 Hz, 480p, 60 Hz, 576i, 50 Hz, 576p, 50 Hz, 1080i, 50, 60 Hz, 720p, 50, 60 Hz, 1080p, 24, 50, 60 Hz, 1080p, 24, 25, 30, 50, 60 Hz

Tuner/Reception/Transmission

Aerial input: 75 ohm coaxial (IEC75)

Tuner bands: Hyperband, S-Channel, UHF, VHF

TV system: PAL I, PAL B/G, SECAM B/G, SECAM L/L', DVB COFDM 2K/8K

Digital TV: DVB-C MPEG4, DVB-T MPEG4

Number of Pre-set Channels: 999

Video Playback: PAL, SECAM, NTSC

Multimedia Applications

Multimedia connections: USB

Playback Formats: MP3, JPEG Still pictures, Slideshow files (alb)

Video Playback Formats: H264/MPEG-4 AVC

Convenience

Ease of Installation: Plug and Play, Advanced Hotel Mode, Automatic Tuning System (ATS), Fine Tuning, PLL Digital Tuning, Automatic Channel Install (ACI), Programme Name, Auto Programme Naming, Autostore, Cloning of TV settings via USB, Installation menu locking, Security menu access, Keyboard lock-out

Ease of Use: Auto Volume Leveller (AVL), 1 channel list analogue/digital, On-Screen Display, Programme List, Side Control, Graphical User Interface

Clock: Dimmable, Integrated LCD Clock Display, Sleep Timer, Wake-up Clock

Clock Enhancements: Synchro Time via TXT/DVB

Comfort: Hotel Guest features, Auto power on, Green/Fast startup, Welcome message, Message indicator, Switch on channel, Volume limitation, Sleep timer

Screen Format Adjustments: 4:3, Movie expand 14:9, Movie expand 16:9, Widescreen, Subtitle Zoom, Super Zoom, Auto Format

Electronic Programme Guide: 8-day Electronic Programme Guide, Now + Next EPG

Remote Control: low battery detection, battery anti-theft protection

Interactive hotel features: Connectivity panel compatible, Block automatic channel update, Block over-the-air SW download

Remote control type: 22AV1104A/10 (RC6)

Prison mode: Txt, MHEG, USB, EPG, Sub block

Teletext: 1000-page Hypertext

Other convenience: Kensington lock

Firmware upgradeable: Firmware upgradeable via USB, Firmware upgradeable via RF

Teletext enhancements: Fast text, Programme information Line

Healthcare

Control: Multi remote control, Pendant control via IR-link

Safety: Double isolation Class II

Convenience: Headphone out, Independent main speaker mute

Sound

Output power (RMS): 2 x 5 W

Sound Enhancement: Auto Volume Leveller, Incredible Surround, Smart Sound

Sound System: Nicam Stereo

Loudspeakers

Built-in speakers: 2

Connectivity

Connectivity Enhancements: Serial Xpress interface, Fast Infrared loop through, Power on scart, USB2.0

Number of HDMI connections: 3

Audio Output - Digital: Coaxial (cinch)

Number of Scarts: 1

EasyLink (HDMI-CEC): One touch play, System standby

Front/Side connections: Audio L/R in, USB 2.0, HDMI v1.3

Ext 1 Scart: Audio L/R, RGB, CVBS in/out

HDMI 1: HDMI v1.3

Other connections: S/PDIF out (coaxial), PC-in VGA + Audio L/R in, Bathroom speaker out, Common Interface Plus (CI+)

Power

Mains power: 220-240 V, 50/60 Hz

Ambient temperature: 5°C to 40°C

Standby power consumption: 0.22 W

Power consumption (typical): 82 W

Annual energy consumption: 77 kW·h

Presence of lead: Yes*

Mercury content: 35 mg

Green Specifications

Safety: Flame-retardant housing

Low Power Standby

SmartPower Eco

