



Philips  
commercial flat HDTV

**66 cm (26")**

LCD  
HDTV monitor

**26HF7955H**

## Enjoy Full Interactivity

with the Philips Flat LCD HDTV

This Pro:Idiom HealthCare LCD TV delivers a superior picture. Philips' advanced LCD technologies produce razor sharp images and brilliant colors. The SmartCard slot interface provides seamless pay-per-view system connectivity.

### **Best total cost of ownership**

- Installation menu locking
- External loudspeaker connector
- Smart Cloning

### **System ready and future proof**

- Compatible with all major PPV systems
- Tamper proof SmartCard slot
- SmartPlug Xpress interface
- HD content protection - Pro:Idiom™

### **Maximum guest comfort**

- Volume limitation
- Switch On Channel Programming
- Welcome message on screen display

### **Great viewing experience and guest comfort**

- HDTV for Hospitality

# PHILIPS

# Highlights

## **HDTV for Hospitality**

There are many ways you may choose to offer HDTV to your guests, but regardless of the source, Philips Hospitality televisions will always deliver the best viewing experience possible to your guests by utilizing the most advanced FlatTV displays and award winning technologies such as Pixel Plus 3 HD.

## **HD content protection**

Content protection technology specially created for the hospitality industry which allows guest to enjoy first run movies and other premium content in true HD quality. (Pro:Idiom™ is a trademark of Zenith Corp.)

## **Smart Cloning**

Philips offers the most flexible and easiest cloning options for hospitality applications. Take advantage of wireless or wired cloning convenience to quickly and easily copy all TV settings from one set to all others in a system configuration.

## **PPV system compatible**

Philips Hospitality sets are designed to be compatible with all major Pay Per View systems,

including, but not limited to, LodgeNet, OnCommand, NxTV, GuesTek, nStreams, Hospitality Network, and KoolConnect. This guarantees seamless integration in almost any system configuration.

## **External loudspeaker connector**

Amplified audio connector for easy installation of external speakers (like for bathrooms), eliminating the need for investments in external equipment

## **Installation menu locking**

Prevents unauthorized access to installation and configuration settings, to ensure maximum guest convenience and avoid unnecessary reprogramming costs.

## **Welcome message**

A welcome greeting is displayed each time the TV set is switched on.

## **Volume limitation**

This feature predefines the volume range with which the TV set is allowed to operate,

preventing excessive volume adjustments and avoiding disturbance of next door guests.

## **Switch On Channel Programming**

Perfect for in-house advertising or information channels as it allows to show a predefined channel when the TV is turned on.

## **Integrated SmartCard Slot**

The integrated SmartCard slot allows third parties to add new functionality to the TV through application cards, without the need for additional boxes and external connections. The TV can also be connected to external decoders and set-top boxes of all major interactive system providers, through the SerialXpress Control Interface (supporting UART and RS232 protocols) and the SmartPlug Control interface.

## **SmartPlug Xpress**

The SmartPlug Xpress communication port (RJ-12) is compatible with major premium entertainment services. The protocol enables the TV connection with external decoders, set-top boxes and PC based solutions.

# Specifications

## Picture/Display

- Aspect ratio: 16:9, Widescreen
- Diagonal screen size (inch): 26 inch
- Diagonal screen size (metric): 66 cm
- Color cabinet: Black
- Panel resolution: 1366 x 768p
- Brightness: 500 cd/m<sup>2</sup>
- Picture enhancement: Progressive scan, 3/2 - 2/2 motion pull down, Active Control, 3D Combfilter, Dynamic contrast enhancement, Contrast Plus, Digital Noise Reduction, Jagged Line Suppression
- Contrast ratio (typical): 700:1
- Display screen type: LCD WXGA Active Matrix TFT
- Dynamic screen contrast: 3500:1
- Response time (typical): 8 ms
- Viewing angle (horizontal): 160 degree
- Viewing angle (vertical): 160 degree
- Screen enhancement: Anti-Reflection coated screen

## Supported Display Resolution

- Computer formats: 1024 x 768, 60, 70, 75, 85Hz, 800 x 600, 60, 72, 75, 85Hz, 640 x 480, 60, 72, 75, 85Hz
- Video formats: 480i, 60Hz, 480p, 60Hz, 720p, 60Hz, 1080i, 60Hz

## Tuner/Reception/Transmission

- Aerial Input: 75 ohm F-type
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: NTSC, ATSC
- Cable: Unscrambled Digital Cable QAM
- Number of Preset Channels: 125
- Video Playback: NTSC, PAL
- Terrestrial: ATSC (8VSB)

## Convenience

- Ease of Installation: Fine Tuning, PLL Digital Tuning, Wireless Smart Loading, Program Name, Advanced Hotel Mode
- Ease of Use: Auto Volume Leveller (AVL), Smart Picture, Smart Sound
- Comfort: Hotel Guest features, Sleep timer
- Screen Format Adjustments: 4:3, 7 Widescreen

- Modes
- Other convenience: Kensington lock

## Sound

- Output power (RMS): 2 x 10W
- Sound System: Stereo, Dolby Digital (AC-3)
- Sound Enhancement: Auto Volume Leveler, Incredible Surround

## Loudspeakers

- Built-in speakers: 2

## Connectivity

- AV 1: Audio L/R in, CVBS in, S-Video Y/C
- Connectivity Enhancements: SmartCard Expansion Slot, RJ12 connector, RJ45 connector, HM-Link, Extra Power supply 12V/1W, External Loudspeaker connector
- AV 2: Audio L/R in, YPbPr
- Audio Output - Digital: Coaxial (cinch)
- AV 3: HDMI
- Other connections: Antenna F-type, PC-In VGA

## Power

- Mains power: 110 - 240V, 50/60Hz
- Ambient temperature: 5 °C to 40 °C
- Power consumption: 125 W

## Accessories

- Included accessories: Power cord, Warranty Leaflet
- Optional accessories: Set up Remote RC2573GR, Mounting brackets/ stands, Wireless SmartLoader 22AV1135

## Dimensions

- Wall mount compatible: 200 x 100 mm
- Set Width (inch): 26.8 inch
- Set Height (inch): 18.6 inch
- Set Depth (inch): 4.4 inch
- Product weight (lb): 24.3 lb
- Box depth (inch): 8.03 inch
- Weight incl. Packaging (lb): 31.1
- Box height (inch): 22.5 inch
- Box width (inch): 33.1 inch



Issue date 2023-10-05

Version: 2.1.8

UPC: 6 09585 13371 6

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)