

Philips  
Professional LCD TV

66 cm (26")

LCD  
Pro:Idiom™

26HFL5830D



## The Essential in Hospitality TV

LCD with SmartCard and Pro:Idiom™ Plus

Exceptional performance for guests and bottom line savings for you. SmartPower<sup>2</sup> can save significantly on energy costs and Five Star Service keeps rooms saleable. SmartCard allows integration with PPV providers today and IP TV tomorrow.

### Best total cost of ownership

- SmartPower<sup>2</sup> and ESP for energy savings
- Five Star Service - two-year advanced exchange warranty
- On-shore 24/7 help desk

### Sustainable and safe

- Eco-sensitive materials and packaging
- Lead-free/RoHS compliant with flame retardant housing

### Designed for hotel use

- Integrated SmartCard Slot for PPV & IPTV
- SmartClone for substantial time savings
- HD content protection with Pro:Idiom™ Plus
- SmartStand

### Differentiating guest experience

- USB media autoplay

**PHILIPS**

# Highlights

## SmartClone

Philips remains on the forefront of making installation as simple as possible. SmartClone offers USB cloning, or on select models, revolutionary RF cloning, which allows all TV's on property to be programmed in as little as five minutes. Additional hardware is required to take advantage of RF cloning.

## Pro:Idiom™ Plus

Pro:Idiom™ was created for the hospitality industry to protect first run movies and other HD premium content from piracy. Philips Pro:Idiom™ Plus televisions offer secure HD content protection not only for PPV hotels, but now also for stand alone properties. (Additional fees may apply for stand alone use) (Pro:Idiom™ is a trademark of the Zenith Corp.)

## SmartStand

This TV comes with a swivel stand that allows your guests to adjust the TV up to 180 degrees so that they can watch TV from any position in the room. Equipped with built-in security, this stand can be secured to a table or furniture to deter theft.

## Integrated SmartCard Slot

Allows third party decoders and application cards to interface with the TV, adding functionality to the set without the need for external boxes or cables. In addition, IPTV functionality can be added to this TV by simply slotting in a new card!

## Five Star Service

Philips offers unmatched commitment to keeping your guest rooms in working order. Our products are so reliable that we offer a two-year advanced exchange warranty. In the event that something does go wrong, we guarantee to ship a replacement set to you, within 72 hours during the first year.

## SmartPower<sup>2</sup> and ESP

Our second generation power saving technology allows the backlight intensity to be dynamically adjusted by the system to reduce the power consumption by up to 60%, saving substantially on energy costs. In addition, Philips' Energy Savings Programmability (ESP) allows the set to turn itself off when not in use to save even more energy when guests or maids leave televisions on for long periods while the room is vacant.

## On-shore 24/7 help desk

Your hotel never closes, and neither do we. We offer a 24/7 Help Desk staffed by knowledgeable and friendly personnel to help you with any aspect of your Philips TV install or use.

## RoHS & Flame retardant housing

In addition to being lead-free and RoHS compliant, Philips TVs have a special housing of eco-friendly, non-brominated flame-retardant materials. Independent tests carried out by emergency fire services have shown that whereas TVs can sometimes intensify fires caused by external sources, Philips TVs will not contribute to the fire.

## Eco-sensitive materials

Philips TVs are designed and produced according to our EcoDesign principles aimed at minimizing overall environmental impact, through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability.

## USB media autoplay

Philips TVs feature a USB connector that allows the guest to connect USB memory sticks to play music or photos right on the TV.

# Specifications

## Picture/Display

- Aspect ratio: 16:9, Widescreen
- Diagonal screen size (inch): 26 inch
- Diagonal screen size (metric): 66 cm
- Color cabinet: Black w/gloss black bezel
- Panel resolution: 1366 x 768p
- Brightness: 500 cd/m<sup>2</sup>
- Picture enhancement: Pixel Plus 3 HD, Progressive scan, 3/2 - 2/2 motion pull down, Active Control, 3D Combfiter, Dynamic contrast enhancement, Contrast Plus, Digital Noise Reduction, Jagged Line Suppression, Luminance Transient Improver, Color Transient Improvement, Automatic skin tone correction, Color Enhancement, Motion adaptive de-interlacing, Picture in Picture
- Contrast ratio (typical): 800:1
- Display screen type: LCD WXGA Active Matrix TFT
- Dynamic screen contrast: 6400:1
- Response time (typical): 8 ms
- Viewing angle (horizontal): 160 degree
- Viewing angle (vertical): 160 degree
- Screen enhancement: Anti-Reflection coated screen

## Supported Display Resolution

- Computer formats: 640 x 480, 60Hz, 800 x 600, 60Hz, 1024 x 768, 60Hz, 1366 x 768, 60Hz
- Video formats: 480i, 60Hz, 480p, 60Hz, 720p, 60Hz, 1080i, 60Hz, 1080p, 24, 25, 30Hz, 1080p, 24, 50, 60Hz

## Tuner/Reception/Transmission

- Aerial Input: 75 ohm F-type
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: ATSC, NTSC
- Cable: Unscrambled Digital Cable QAM
- Number of Preset Channels: 250
- Video Playback: NTSC, PAL
- Terrestrial: ATSC (8VSB)

## Multimedia Applications

- Multimedia connections: USB
- Playback Formats: JPEG Still pictures, MP3, Slideshow files (.alb)

## Convenience

- Ease of Installation: Cloning of TV settings via USB, Advanced Hotel Mode, Fine Tuning, PLL Digital Tuning, Program Name, Keyboard lock-out, Security menu access
- Ease of Use: Auto Volume Leveller (AVL), Smart Picture, Smart Sound
- User convenience: Closed captioning (digital), Vchip and parental lock
- Comfort: Hotel Guest features, Sleep timer, Switch on channel, Volume limitation, Welcome message
- Screen Format Adjustments: 4:3, 7 Widescreen Modes

- Interactive hotel features: Smoovie Pay TV
- Other convenience: Kensington lock

## Sound

- Output power (RMS): 2 x 10W
- Sound System: Stereo, Dolby Digital (AC-3)
- Sound Enhancement: Auto Volume Leveler, Incredible Surround

## Loudspeakers

- Built-in speakers: 2

## Connectivity

- AV 1: AV In, S-Video Y/C
- Connectivity Enhancements: SmartCard Expansion Slot, HM-Link, Extra Power supply 12V/1W, External Loudspeaker connector, USB2.0, RJ12 SmartPlug connector
- AV 2: Audio L/R in, YPbPr
- Audio Output - Digital: Coaxial (cinch)
- AV 3: VGA PC-in, Audio-in mini jack 3.5mm
- AV 4: HDMI
- AV 5: HDMI
- Other connections: Antenna F-type, RS232 Serial

## Power

- Mains power: 110 - 240V, 50/60Hz
- Ambient temperature: 5 °C to 40 °C
- Standby power consumption: 1.15 W
- Power use SmartPower<sup>2</sup> = off: <math>115\text{ W}</math>
- Power use SmartPower<sup>2</sup> = high: <math>52\text{ W}</math>

## Green Specifications

- Safety: Flame retardant housing
- Eco Designed
- SmartPower<sup>2</sup>

## Accessories

- Included accessories: Swivel stand with anti-theft, Warranty Leaflet, Quick start guide, Power cord (2m)
- Optional accessories: Set up Remote RC2573GR, Mounting brackets/ stands, Guest remote control

## Dimensions

- Wall mount compatible: 200 x 100 mm
- Set Width (inch): 26.7 inch
- Set Height (inch): 18.6 inch
- Set Depth (inch): 4.5 inch
- Product weight (lb): 25.3 (with stand), 16.9 (without stand) lb
- Set width (with stand) (inch): 26.7 inch
- Set depth (with stand) (inch): 10.4 inch
- Set height (with stand) (inch): 21 inch
- Box depth (inch): 35.3 inch
- Weight incl. Packaging (lb): 38.6
- Box height (inch): 8 inch
- Box width (inch): 22.6 inch



Issue date 2023-10-05

Version: 6.1.12

UPC: 6 09585 15024 9

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Five Star Advanced Exchange warranty is valid in the United States only. Local warranties govern sales in other countries.