



Philips Signage Solutions  
LED Display

27"

Direct View LED

## Infinite versatility

Take possibilities beyond boundaries

Create any size 16:9 unique display or even a crisp 32:9 panoramic view, which defies traditional conformation by assembling an intriguing modular pattern. Perfect viewing experience for presentations and corporate branding content.



27BDL6119L

### Take possibilities beyond any boundary

- Audience can focus on presentations and office applications
- Engage, inspire and impact with vivid content
- Powerful statements in any lobby, auditorium, meeting room

### Effortless setup. Reliable performance.

- Easy setup and maintenance with reliable standard cables
- Perfect view ensured through wide viewing angles
- Philips Dynamic and Black screen power-saving features

### Spectacular picture quality. Endless possibilities

- Deep contrast and great brightness performance
- Highest colour accuracy and brightness uniformity
- Smooth and judder-free images by high refresh rate

**PHILIPS**

# Specifications

## Picture/Display

- Aspect ratio: 16:9
- Brightness uniformity:  $\geq 97\%$
- Brightness after calibration: 650 nits
- Brightness before calibration: 750 nits
- Calibration (brightness/colour): Supported
- Colour temperature adjust range: 4000~9500 K (by software)
- Colour temperature default:  $6500 \pm 500$  K
- Contrast ratio (typical): 3200:1
- Viewing angle (horizontal): 160 degree
- Viewing angle (vertical): 160 degree
- Picture enhancement: Dynamic contrast enhancement, Wide colour gamut display
- Placement: Landscape
- Frame frequency (Hz): 50 & 60
- Refresh rate (Hz): 1920~3840
- Usage: 24/7 hrs, Indoor

## Convenience

- Ease of installation: Guide pins, Light weight
- Power loop through: For 230 V environments: 8 cabinets or less, for 110 V environments: 4 cabinets or less
- Signal control loop through: RJ45

## Power

- Input voltage: AC100~240 V (50 and 60 Hz)
- Black screen power cons. (W):  $\leq 12$
- Max. power cons. AC (W):  $\leq 65$
- Max. power cons. BC (W):  $\leq 76$
- Typical power cons. (W):  $\leq 21.7$

## Operating conditions

- Temperature range (operation): -20~45 °C
- Temperature range (storage): -20~50 °C
- Humidity range (operation)[RH]: 10~80%
- Humidity range (storage) [RH]: 10~85%

## Cabinet

- Cabinet area (m<sup>2</sup>): 0.208
- Cabinet pixels (Dot): 57,600
- Cabinet resolution (W x H): 320x180
- Cabinet size (mm): 608x342x59
- Data connector: RJ45
- Power connector: In/Out(C14/C13)
- Receiving card quantity: 1 pcs
- Receiving card spec.: A5S plus
- Receiving card brand: Novastar
- Weight (kg): 5.81
- Cabinet diagonal (inch): 27.5
- Cabinet construction: Die-Casting Aluminium

## Module

- LED type: SMD 1515 Copper wire
- Pixel constitution: 1R1G1B
- LED lifetime(Hrs): 100 000
- Module resolution (WxH pixels): 160x90
- Pixel pitch (mm): 1.9
- Module size (W x H in mm): 303.9x170.9

## Accessories

- LAN cable (RJ45, CAT-5): 1 piece
- Power cable: 1 piece
- QSG: 1 piece

## Miscellaneous

- Warranty: 2 years
- Regulatory approvals: RoHS, EN61000-3-2, EN61000-3-3, IEC/UL60950, IEC/UL62368, IEC62471, EN55032, EN55035, EMC, FCC SDOC, Part 15, Class A
- Fire retardancy certification: BS 476 Part7:1997

## Packaging Data

- Dimension of packaging (mm): 780x471x224
- Gross weight (KG): 8.52

# Highlights

## Audience can focus on presentations

Audience can focus on presentations and office applications

## Deep contrast and great bright

Deep contrast and great brightness performance

## Create bezel-free video walls

Simply connect multiple LED display cabinets to create the resolution you want, whether it's 4K, 8K or even higher. Compared to LCD screens, LED displays boast higher refresh rates that enable smoother images. Whatever the application, you'll thrill them with crystal-clear picture quality.

## Engage, inspire and impact

Create bezel-free video walls of any shape, size or resolution. The modular design of Philips Professional LED cabinets means you can adapt to any space. Build vast, immersive installations or assemble intriguing patterns. Easily create video walls that flow seamlessly around doorways and other openings.

## Colour accuracy and brightness

The LED panels provide very accurate colour accuracy and a brightness uniformity of about 97%. This ensures a near-perfect picture quality.

## Front-access maintenance

Internal electronics are easy to access and replace for service and maintenance. The modules in the cabinet can be easily and safely removed with the dedicated removal tool.

## Philips Dynamic and Black screen

Philips Dynamic and Black screen power-saving features

## Powerful statements in any lobby

Powerful statements in any lobby, auditorium, meeting room

## Smooth and judder-free images

Smooth and judder-free images by high refresh rate



Issue date 2024-03-24

Version: 2.0.2

EAN: 87 12581 79507 8

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)