



Philips  
LCD monitor

58 cm (23") w E-line  
1920x1080 Full HD

231E1SB

## Big Full-HD display for great viewing experience

Enjoy more with this attractive 16:9 Full HD 1080p quality display ! With DVI and VGA inputs, Auto format, SmartContrast and Glossy finish, the 231E1 is a great choice for all your needs

### Great picture quality

- Full HD LCD display, 1920x1080p resolution
- 16:9 display for best widescreen gaming and video
- 5ms fast response time
- SmartContrast 25000:1 for incredible rich black details
- DVI signal input for full HD performance with HDCP

### Design that complements any interior

- Glossy finish to enhance your decor
- Cable management reduces cable clutter for neat workspace

### Environmentally friendly green design

- Energy Star for energy efficiency and low power consumption
- Eco-friendly materials that meets international standards

### Great convenience

- Dual input accepts both analog VGA and digital DVI signals
- Easy picture format control switching in wide and 4:3 format

# PHILIPS

# Specifications

## Picture/Display

- LCD panel type: TFT-LCD
- Panel Size: 23 inch/58.42 cm
- Aspect ratio: 16:9
- Pixel pitch: 0.265 x 0.265 mm
- Viewing angle: 176° (H) / 170° (V), @ C/R > 5
- Brightness: 300 cd/m<sup>2</sup>
- SmartContrast: 25000:1
- Response time (typical): 5 ms
- Optimum resolution: 1920 x 1080 @ 60Hz
- Display colors: 16.7 M
- Scanning Frequency: 30 - 83 kHz (H) / 56 - 76 Hz (V)
- sRGB

## Connectivity

- Signal Input: VGA (Analog), DVI-D (digital, HDCP)
- Sync Input: Separate Sync, Sync on Green

## Convenience

- User convenience: SmartImage, Menu, Volume, Input, Auto, Power On/Off
- OSD Languages: English, French, German, Spanish, Italian, Russian, Simplified Chinese, Portuguese, Turkish
- Other convenience: Kensington lock
- Plug & Play Compatibility: DDC/CI, Windows 7/ Vista/XP/2000/98, sRGB

## Stand

- Tilt: -5/20 degree

## Power

- Power LED indicator: Operation - Blue, Stand by/

- sleep -blue(blinking)
- Power supply: Built-in, 100-240VAC, 50/60Hz
- On mode: <29.7W (EnergyStar 5.0 test method)
- Standby mode: <0.5W
- Off mode: < 0.5 W

## Dimensions

- Product with stand (mm): 547 x 433 x 201 mm
- Product without stand (mm): 547 x 351 x 68 mm
- Packaging in mm (WxHxD): 596 x 495 x 134 mm

## Weight

- Product with stand (kg): 5.6 kg
- Product without stand (kg): 5.18 kg
- Product with packaging (kg): 7.3 kg

## Operating conditions

- Temperature range (operation): 0 - 40 °C
- Temperature range (storage): -20 - 60 °C
- Relative humidity: 20 - 80 %
- MTBF: 50,000 hour(s)

## Sustainability

- Environmental and energy: EPEAT Silver, RoHS, EnergyStar 5.0

## Compliance and standards

- Regulatory Approvals: CE Mark, FCC, Class B, UL/cUL

## Cabinet

- Color: Black
- Finish: Glossy



# Highlights

## Full HD 1920x1080p LCD display

Enjoy crisp and crystal clear picture quality to give your audience a truly memorable visual experience. Your viewers will be treated to unsurpassed video, with an amazing color gamut and the sharpest pictures around.

## 16:9 widescreen aspect ratio

An aspect ratio is an expression of a video image's width compared to its height. The 16:9 widescreen aspect ratio is standard for universal to high-definition television and European digital television. A native 16:9 aspect ratio means outstanding game and video display without bars at top and bottom of the picture and without the quality loss that comes from scaling, altering an image to fit on a different screen size.

## 5ms on/off response time

On-Off response time is the period required for a liquid crystal cell to go from active (black) to inactive (white) and back to active (black) again. It is measured in milliseconds. Faster is better: Lower response time means faster transitions and, therefore, results in fewer visible image artifacts in the display of transition of texts and graphics. On-Off response time is a more important measure in the display of business content like documents, graphs and photos.

## SmartContrast ratio 25000:1

You want the LCD flat display with the highest contrast and most vibrant images. Philips advanced video processing combined with unique extreme dimming and backlight boosting technology results in vibrant images. SmartContrast will increase the contrast with excellent blacklevel and accurate rendition of dark shades and colors. It gives a bright, lifelike picture with high contrast and vibrant colors.

## Energy Star 5.0

Energy Star is a US EPA sponsored energy efficiency program also adopted by many other countries. Energy Star certification ensures that you are buying a product which meets the latest power efficiency standards which operates with maximum power efficiency at all operational levels. New Philips monitors are certified for Energy Star 5.0 specifications and meet or exceed the standard. For example, in sleep mode Energy Star 5.0 requires less than 1watt power consumption, whereas Philips monitors consume less than 0.5watts. Further details can be obtained from [www.energystar.gov](http://www.energystar.gov)

## DVI signal with HDCP

High-Bandwidth Digital Content Protection (HDCP) is a copyright protection system that is incorporated into the DVI connector. It helps stop unauthorized duplication of copyrighted content. HDCP allows you to play protected content media such as movies and concerts. It checks the signal to prevent piracy, allowing only legal copies of content to display.

## Dual input

Dual input provides connectors to accommodate input of both analog VGA and digital DVI signals.

## Easy picture format control

Philips easy picture format control on OSD is to switch from the 4:3 aspect ratio to the widescreen mode and back again to match the display's aspect ratio with your content for working with wide documents without scrolling or viewing widescreen media in the widescreen mode and distortion-free, native mode display of 4:3 ratio content.



Issue date 2022-05-10

Version: 4.0.5

12 NC: 8670 000 54197  
EAN: 87 12581 49137 6

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)