



Philips
LCD monitor

30"
WXGA

300WN5BS



excellent and robust display solution

Excellent and robust, the network-controlled Philips 300WN5 LCD monitor provides a reliable and multi-function solution with Philips leading display technology.

Less management effort for maximum productivity

- Monitor is network controllable for remote management
- Brightness automatically adjusts with ambient conditions
- Automatic alert provides advance warning of overheating

Lower total cost of ownership

- Lifecycle is longer than plasma displays
- Intelligent power management for lower consumption
- Hidden control buttons prevent tampering with settings

Better screen experience

- Easy plug-and-play DVI for a true digital experience
- WXGA, wide format, 1280x768 resolution for sharper display

PHILIPS
sense and simplicity

Specifications

Picture/Display

- **LCD panel type:** 1280 x 768 pixels, Anti-glare polarizer
- **Panel Size:** 29.53" / 75cm
- **Pixel pitch:** 0.5025 x 0.5025 mm
- **Brightness:** 600 cd/m²
- **Contrast ratio (typical):** 800:1
- **Display colours:** 16.7 M
- **Viewing angle: @ C/R > 10**
- **Viewing Angle (H / V):** 170 / 170 degree
- **Response time (typical):** 16 ms
- **White Chromaticity, 5300K:** x = 0.328 / y = 0.344
- **White Chromaticity, 6500K:** x = 0.313 / y = 0.329
- **White Chromaticity, 9300K:** x = 0.283 / y = 0.297
- **Maximum Resolution:** 1280 x 768 @ 60Hz
- **Recommended Resolution:** 1280 x 768 @ 60Hz
- **Factory Preset Modes:** 4 modes
- **Horizontal Scanning Frequency:** 31 - 49 kHz
- **Refresh rate (V):** 60 Hz
- **sRGB**
- **Aspect ratio:** 15:9

Connectivity

- **AV output:** 3.5 mm jack (L/R) x1, Ext 3.5 mm jack x1
- **PC:** D-Sub x1, DVI-D x1, 3.5 mm PC audio input x1, RS232 x1

Convenience

- **Convenience Enhancements:** On-screen Display, Automatic Brightness Control, Automatic Overheat Warning
- **Monitor Controls:** Left / right, Menu (OK), Power On/Off, Up / down, Input select
- **OSD Languages:** English, French, German, Italian, Spanish, Simplified Chinese
- **Plug & Play Compatibility:** sRGB, Windows 98/ME/

2000/XP

- **Regulatory Approvals:** CE Mark, FCC-B, UL, CSA, NUTEK, Energy Star
- **VESA Mount:** 100 x 100 mm

Accessories

- **Included Accessories:** AC Power Cord, Remote control, VGA cable, DVI-D cable
- **Optional accessories:** Base, Detachable Speakers
- **User Manual**

Dimensions

- **Dimensions (with speakers) (W x H x D):** 867.7 x 505 x 183 mm
- **Dimensions (w/o base & speakers) (W x H x D):** 726.7 x 469.3 x 115 mm
- **MTBF:** 50,000 hrs
- **Relative Humidity:** 20% - 80%
- **Temperature range (operation):** 5°C to 35°C
- **Temperature range (storage):** -20°C to 60°C
- **Weight:** 14 kg

Power

- **Complies with:** Energy Star, NUTEK
- **Consumption:** 130W
- **Off Mode:** < 2 W
- **Power LED indicator:** Operation - Blue, Stand by/ sleep - Amber
- **Power supply:** Built-in

Supported Display Resolution

- **Computer formats**

Resolution	Refresh rate
640 x 480	60Hz
800 x 600	60Hz
1024 x 768	60Hz
1280 x 768	60Hz

Product highlights

Network controllability: RS232

Network controllability allows user to control and adjust monitors remotely through RS232 protocol.

Automatic brightness control

The adjustment of display settings to correspond with ambient light without user intervention.

Automatic overheat warning

Automatic overheat warning generates an alert and delivers it to the designated system manager when a display device's operating temperature exceeds designated levels.

Long lifecycle

A longer lifecycle means a lower total cost of ownership and adds up to long-term savings.

Intelligent power management

Intelligent power management employs energy-efficient technologies in product design to reduce power consumption and significantly lower the total cost of ownership.

Hidden control buttons

Control buttons placed at the rear of a monitor used for public display to prevent tampering with display settings.

In box DVI cable

A DVI cable is shipped with the product to provide high quality digital display.

WXGA, 1280 x 768 resolution

For graphics monitors, the screen resolution signifies the number of dots (pixels) on the entire screen. WXGA provides the resolutions 1280 by 768 pixels. In addition, WXGA allows monitors to be non-interlaced. This ensures a better display performance and accurate colour display effect.



Issue date 2007-11-09

Version: 2.0

12 NC: 8639 000 15124
EAN: 87 10895 82550 4

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com