

Philips
LCD monitor

V Line
20 (19.5"/49.5 cm diag.)

203V5LSB2



Great LED images in vivid colours

Enjoy vivid LED pictures on this Philips display. Essential features like SmartContrast ensure rich bright images, making it a great choice!

Great choice

- Compact design saves space
- Mercury Free eco-friendly display
- VESA mount allows for flexibility

Vivid pictures every time

- LED technology for vivid colours

PHILIPS

Highlights

LED technology

White LED's are solid state devices which light up to full, consistent brightness faster saving startup time. LED's are free from mercury content, which allows for eco-friendly recycling and disposal process. LED's allow for better dimming control of the LCD backlight, resulting in a super high contrast ratio. It also

gives superior colour reproduction thanks to consistent brightness across the screen.

Mercury Free

Philips monitors with LED backlighting are free from Mercury, one of the most toxic natural substances, which affects humans and animals. This reduces the environmental impact of the

display throughout its lifecycle, from manufacturing to disposal.

Compact design saves space

Compact design saves space

VESA mount

VESA mount allows for flexibility



Hg Free



VESA Mount



Low Power



LED

Specifications

Connectivity

- Signal Input: VGA (Analogue)
- Sync Input: Separate Sync

Picture/Display

- Panel Size: 19.5 inch / 49.5 cm
- Aspect ratio: 16:9
- LCD panel type: TFT-LCD
- Backlight type: W-LED system
- Pixel pitch: 0.26 x 0.26 mm
- Optimum resolution: 1600 x 900 @ 60 Hz
- Brightness: 200 cd/m²
- Display colours: 16.7 M
- Contrast ratio (typical): 600:1
- Response time (typical): 5 ms
- Viewing angle: 90° (H)/65° (V), @ C/R > 10
- Effective viewing area: 433.9 (H) x 236.3 (V)
- Scanning Frequency: 30–83 kHz (H)/56–75 Hz (V)
- sRGB

Convenience

- Plug and Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 7, Windows 8
- User convenience: Power On/Off
- OSD Languages: Brazil Portuguese, Czech, Dutch, English, Finnish, French, German, Greek, Hungarian, Italian, Japanese, Korean, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish, Ukrainian
- Other convenience: Kensington lock, VESA mount (100 x 100 mm)

Stand

- Tilt: -3/10 degree

Power

- Power supply: Built-in, 100–240 VAC, 50–60 Hz

- Off mode: 0.5 W (typ.)
- On mode: 16.18 W (typ.)
- Standby mode: 0.5 W (typ.)
- Power LED indicator: Operation - White, Standby mode - White (flashing)

Dimensions

- Product with stand (mm): 465 x 345 x 170 mm
- Packaging in mm (W x H x D): 503 x 350 x 109 mm
- Product without stand (mm): 465 x 285 x 48 mm

Weight

- Product with packaging (kg): 3.23 kg
- Product with stand (kg): 2.33 kg
- Product without stand (kg): 2.03 kg

Operating conditions

- Altitude: Operation: +12,000 ft (3658 m), Non-operation: +40,000 ft (12,192 m)
- Temperature range (operation): 0°C to 40°C °C
- MTBF: 30,000 hour(s)
- Relative humidity: 20–80% %
- Temperature range (storage): -20°C to 60°C °C

Sustainability

- Environmental and energy: RoHS, Mercury Free
- Recyclable packaging material: 100 %

Compliance and standards

- Regulatory Approvals: BSMI, CE Mark, FCC Class B, GOST, SEMKO, TUV/ISO9241-307, cETLus, WEEE

Cabinet

- Colour: Black
- Finish: Hairline (front bezel)/Texture (rear cover)



Issue date 2024-03-24

Version: 7.0.1

EAN: 87 12581 72506 8

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com