

Philips Momentum Curved LCD monitor with Ultra Wide-Color

Momentum

27" (68.6 cm) 1920 x 1080 (Full HD)

278M6QJEB



Get in the moment

The new curved Momentum monitor gets you in the moment. Fast action looks great on-screen with Full HD resolution, AMD FreeSync™ technology and 144Hz fast refresh. Scenes look more real with Ultra Wide-Color.

Design to enhance the senses

- · Curved display design for more immersive experience
- Crafted with premium materials for a sophisticated look

Superb Picture Quality

- MVA Display for wide viewing angles and deep contrast levels
- Ultra Wide-Color wider range of colors for a vivid picture

Built for fast action

- AMD FreeSync™ Premium; tear free, stutter free, fluid gaming
- 144Hz refresh rates for ultra-smooth, brilliant images
- SmartImage game mode optimized for gamers

Get comfortable

- LowBlue Mode for easy on-the-eyes productivity
- · Less eye fatigue with Flicker-free technology
- Height-adjustable for better ergonomic comfort



Highlights

Curved display design



Desktop monitors offer a personal user experience, which suits a curve design very well. The curved screen provides a pleasant yet subtle immersion effect, which focuses on you at the center of your desk.

Ultra Wide-Color Technology





Ultra Wide-Color Technology delivers a wider spectrum of colors for a more brilliant picture. Ultra Wide-Color wider "color gamut" produces more natural-looking greens, vivid reds and deeper blues. Bring, media entertainment, images, and even productivity more alive and vivid colors from Ultra Wide-Color Technology.

AMD FreeSync™ Premium





reeSync™ OFF

Gaming shouldn't be a choice between choppy gameplay or broken frames. AMD FreeSync $^{\text{TM}}$

Premium equips serious gamers with a fluid, tear-free gameplay experience at peak performance. There are no compromises, game confidently with a high refresh rate, low framerate compensation, and low latency.

144Hz Gaming



You play intense, competitive gaming. You demand display with lag free, ultra-smooth images. This Philips display redraws the screen image up-to 144 times per second, effectively 2.4x faster than a standard display. A lower frame rate can make enemies appear to jump from spot to spot on the screen, making them difficult targets to hit. With 144Hz frame rate, you get those critical missing images on the screen which shows enemy movement in ultrasmooth motion so you can easily target them. With ultra-low input lag and no screen tearing, this Philips display is your perfect gaming partner

SmartImage Game mode



The new Philips gaming display has quick access OSD fine tuned for gamers, offering you multiple options. "FPS" mode (First person shooting) improves dark themes in games, allowing you to see hidden objects in dark areas. "Racing" mode adapts display with

fastest response time, high color, along with image adjustments. "RTS" mode (Real time strategy) has a special SmartFrame mode which enables highlighting of specific area and allows for size and image adjustments. Gamer 1 and Gamer 2 enable you to save personal customized settings based on different games, ensuring best performance.

LowBlue Mode



Studies have shown that just as ultra-violet rays can cause eye damage, shortwave length blue light rays from LED displays can cause eye damage and affect vision over time. Developed for wellbeing, Philips LowBlue Mode setting uses a smart software technology to reduce harmful shortwave blue light.

Flicker-free technology



Due to the way brightness is controlled on LED-backlit screens, some users experience flicker on their screen which causes eye fatigue. Philips Flicker-free Technology applies a new solution to regulate brightness and reduce flicker for more comfortable viewing.





















Specifications

Picture/Display

- LCD panel type: MVA
- · Backlight type: W-LED system
- Panel Size: 27 inch / 68.6 cm
- Display Screen Coating: Anti-Glare, 3H, Haze 25%
- Effective viewing area: 597.89 (H) x 336.31 (V) at
- a 1800R curvature*
- Aspect ratio: 16:9 • Optimum resolution: 1920 x 1080 @ 144 Hz
- Response time (typical): 4 ms (Gray to Gray)*
- Pixel Density: 82 PPI
- Brightness: 250 cd/m²
- Contrast ratio (typical): 3000:1
- SmartContrast: 80,000,000:1
- Pixel pitch: 0.311 x 0.311 mm
- Viewing angle: 178° (H) / 178° (V), @ C/R > 10
- Flicker-free
- · Picture enhancement: SmartImage game
- Color gamut (typical): NTSC 101%*, sRGB 128%*
- Display colors: 16.7 M
- Scanning Frequency: 30 160 kHz (H) / 48 144 Hz
- sRGB
- · LowBlue Mode
- AMD FreeSync™ technology: Premium

Connectivity

- Signal Input: VGA (Analog), DisplayPort 1.2, HDMI
- Sync Input: Separate Sync, Sync on Green
- Audio (In/Out): Audio out

Convenience

- User convenience: Menu/OK, Input/Up, SmartImage Game/Return, SmartSize/Down, Power On/Off
- Control software: SmartControl
- OSD Languages: Brazil Portuguese, Czech, Dutch, English, Finnish, French, German, Greek, Hungarian, Italian, Japanese, Korean, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish, Ukrainian
- · Other convenience: Kensington lock, VESA mount (100x100mm)
- Plug & Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 10 / 8.1 / 8 / 7

Stand

- · Height adjustment: 130 mm
- Tilt: -5/20 degree

Power

- On mode: 36.2 W (typ.)
- Standby mode: < 0.5 W (typ.)
- Off mode: < 0.3 W (typ.)
- Power LED indicator: Operation White, Standby mode- White (blinking)
- Power supply: External, 100-240VAC, 50-60Hz

Dimensions

- Product with stand(max height): 612 x 416 x 286 mm
- Product without stand (mm): $612 \times 369 \times 52 \text{ mm}$
- Packaging in mm (WxHxD): $694 \times 520 \times 358$ mm

Weight

- Product with stand (kg): 6.24 kg
- Product without stand (kg): 4.47 kg
- Product with packaging (kg): 9.48 kg

Operating conditions

- Temperature range (operation): 0 to 40 °C
- Temperature range (storage): -20 to 60 °C
- Relative humidity: 20%-80 %
- Altitude: Operation: +12,000ft (3,658m), Nonoperation: +40,000ft (12,192m)
- MTBF: 50,000 hrs (excluding backlight) hour(s)

Sustainability

- · Environmental and energy: RoHS, WEEE
- Recyclable packaging material: 100 %
- Specific Substances: Mercury free, PVC / BFR free housing

Compliance and standards

• Regulatory Approvals: CB, CE Mark, CCC, CECP,

Cabinet

- Color: Black
- · Finish: Glossy



Issue date 2022-07-08

Version: 4.0.1

12 NC: 8670 001 60039 EAN: 87 12581 75942 1 © 2022 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com

- * Radius of the arc of the display curvature in mm * Response time value equal to SmartResponse
- * NTSC Area based on CIE1976 * sRGB Area based on CIE1931
- * This Philips display is capable of achieving upto 144Hz refresh rates thru its HDMI 2.0 and DisplayPort connector. Please ensure your graphics card is capable of 144Hz refresh rates and updated with the latest driver.
- * For any questions related to 144Hz performance please refer to your card vendor directly.
- 2020 Advanced Micro Devices, Inc. All rights reserved. AMD, the AMD Arrow logo, AMD FreeSync™ and combinations thereof are trademarks of Advanced Micro Devices, Inc. Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies
- * The monitor may look different from feature images.