Philips Signage Solutions H-Line Display

55" 2500cd/m<sup>2</sup> Full HD



55BDL6002H



# Turn heads

# High-brightness 24/7 display.

Stay visible day and night with Philips H Line Full HD Panel. Astonishing clarity and contrast make this a perfect solution for busy areas that are subject to high ambient light. From airports to shopping centres.

# Brilliant picture. High brightness.

- Full HD. Clear images. Crisp contrast
- High brightness (2500 cd/m2). Suited to semi-outdoor use
- Automated light output with optional external light sensor

# Effortless setup. Total control.

- Add Android processing power with an optional CRD50 module
- Remote system management through CMND
- Operate, monitor and maintain with CMND & Control
- CMND & Create. Develop and launch your own content

# Versatile system solution

- Energy-saving automatic backlight control
- FailOver ensures content is always playing
- OPS slot allows for PC embedding without cabling



# Highlights

### **Optional CRD50 module**

Embed an Android System-on-Chip (SoC) in your Philips Professional Display. The optional CRD50 module is an OPS device that enables Android processing power without the need for cables. Simply slide into the OPS slot, which contains all the connections needed to run the module (including power supply).

### **CMND**

Take control of your Philips Professional Display network. CMND lets you manage, update, maintain, and play via one easy-to-use interface. From installation to daily operation.

### CMND & Control



Run your display network over a local (LAN) connection. CMND & Control allows you to perform vital functions like controlling inputs

and monitoring display status. Whether you're in charge of one screen or 100.

#### **CMND & Create**



Take control of your content with CMND & Create. A drag-and-drop interface makes it simple to publish your own content-whether it's a daily specials board or branded corporate information. Preloaded templates and integrated widgets ensure your stills, text, and video will be up and running in no time.

# FailOver



From waiting room to meeting room, never show a blank screen. FailOver lets your Philips Professional Display switch automatically between primary and secondary inputs ensuring content keeps playing even if the primary source goes down. Simply set a list of alternate inputs to be sure your business is always on.

#### **OPS** slot



Integrate a full-power PC or Android-powered CRD50 module directly into your Philips Professional Display. The OPS slot contains all the connections you need to run your slot-in solution, including a power supply.

## High brightness (2,500 cd/m2)

Make a big impact in bright or semi-outdoor locations. This ultra-high-brightness 2500 cd/ m2 display is perfect for attracting attention in large, busy areas that are subject to high ambient light.

🚭 Smart**Player** 

# Specifications

## **Picture/Display**

- Diagonal screen size: 54.6 inch / 138.7 cm
- Optimum resolution: 1920 x 1080 @ 60Hz
- Brightness: 2500 cd/m<sup>2</sup>
- Contrast ratio (typical): 4000 : 1
- Dynamic contrast ratio: 500,000 : 1
- Aspect ratio: 16:9
- Response time (typical): 8 ms
- Pixel pitch: 0.63 x 0.63 mm
- Display colors: 1.07 B
- Viewing angle (H / V): 178 / 178 degree Panel resolution: 1920x1080p

#### Connectivity

- Video input: Composite (Share component Y), Display Port1.2 (x1), DVI-D (x1), HDMI 1.4 (x2), VGA (Analog D-Sub) (x1), Component (BNC x3)
- Video output: DisplayPort 1.2 (x1), DVI-I (x1)
- Audio input: 3.5 mm jack, Audio Left/Right (RCA) • Audio output: 3.5mm jack, External speaker
- connector • External control: RS232C (in/out) 2.5 mm jack,
- RJ45, IR (in/out) 3.5 mm jack
- Other connections: OPS, USB 2.0 (x1)

#### Dimensions

- Bezel width: 13.6 mm(Even bezel)
- Set dimensions (W x H x D): 1243.2 x 714 x 137.7 mm
- Set dimensions in inch (W x H x D): 48.9 x 28.1 x 5.42 inch
- Wall Mount: 400 x 400 mm, M6
- Product weight: 31.84 kg
- Product weight (lb): 70.20 lb
- Smart insert height: 200 mm
- Smart Insert mount: 100mm x 100mm pitch, 6xM4L6

#### Convenience

- Placement: Landscape, Portrait
- Network controllable: RS232, RJ45
- Signal loop through: RS232, IR Loopthrough, DisplayPort, IR, R|45
- Energy saving functions: Smart Power
- Remote control signal: Lockable
- · Keyboard control: Hidden, Lockable
- · Ease of installation: Carrying Handles, Smart Insert

Philips 55BDL6002H

- Other convenience: Carrying handles
- · Screen saving functions: Pixel Shift, Low Brightness
- · Picture performance: Advanced color control

#### Power

- Mains power: 100 ~ 240 VA
- Consumption (Typical): 295 W
- Standby power consumption: <0.5W
- Consumption (Max): 420 W

#### Sound

Built-in speakers: 2 x 10W RMS

#### **Operating conditions**

- MTBF: 50,000 hour(s)
- Altitude: 0 ~ 3000 m
- Humidity range (operation)[RH]: 20 ~ 80% RH (No condensation)
- Humidity range (storage) [RH]: 5 ~ 95% RH (No condensation)

- guide, RS232 cable, Remote Control & AAA Batteries
- Edge Alignment Kit (1) -1 pcs, Edge Alignment Kit (2) - 2 pcs, Philips logo (x1), Thumbscrew (8pcs)
- German, Italian, Polish, Russian, Spanish, Turkish, Simplified Chinese, Traditional Chinese, Arabic,
- Regulatory approvals: CB, CE, UL/cUL, EAC, EMF,

## **Multimedia Applications**

- USB Playback Audio: AAC, AIF, AIFF, ASF, M3U, M4A, MP3, MP4, PLS, WAV, WMA
- USB Playback Picture: BMP, GIF, JPEG, JPG, PNG
- USB Playback Video: ISM, M2TS, M4V, Manifest, MK3D, MKV, MP4, MPD, MPEG, MPG, MT2, MTS, TS, VOB

Supported Display Resolution Computer formats Resolution 1024 x 768

1280 x 1024

1280 x 768

1280 x 800

1280 × 960

1360 x 768

1366 x 768

1600 x 1200

1920 x 1080

640 x 480

720 x 400

800 x 600

Resolution

1080i

1080p

720p

Video formats

C, 50 ~ 60 Hz	
\A/	

## • Temperature range (operation): 0 ~ 40 °C

# • Temperature range (storage): -20 ~ 60 °C

## Accessories

- Included accessories: AC Power Cord, Quick start
- Included Accessories: RS232 daisy-chain cable,

- **Miscellaneous** • On-Screen Display Languages: English, French,
  - Japanese, Portuguese
  - FCC, Class A, PSB, PSE, VCCI
  - Warranty: 3 year warranty



© 2023 Koninklijke Philips N.V. All Rights reserved.

www.philips.com

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 68694 EAN: 87 12581 76871 3

# 55BDL6002H/00

Refresh rate

60, 75Hz

60Hz

60H7

60Hz

60Hz

60Hz

60Hz

60H7

60Hz

70Hz

60, 75Hz

Refresh rate

25, 30Hz

50, 60Hz

50. 60Hz

60, 72, 75Hz