

# PHILIPS

Curved LCD monitor  
with Ultra Wide-Color

E Line

32 (31.5" / 80 cm diag.)

2560 x 1440 (QHD)

328E9FJAB



## Stunning color, ultimate immersion with Crystal-clear details

Experience real immersion with Philips Curved Monitors. The 32" curved E line monitor offers a truly immersive experience with stunning crystal-clear QHD image quality. Ultra wide-color gives color quality that brings your images alive!

### Features designed for you

- DisplayPort connection for maximum visuals
- HDMI ensures universal digital connectivity
- Built-in stereo speakers for multimedia
- Less eye fatigue with Flicker-free technology
- LowBlue Mode for easy on-the-eyes productivity
- Narrow border display for a seamless appearance

### Curved design inspired by the world around us


- Curved display design for more immersive experience

### Superb Picture Quality

- VA display delivers awesome images with wide viewing angles
- Crystalclear images with Quad HD 2560 x 1440 pixels
- Ultra Wide-Color wider range of colors for a vivid picture
- Effortlessly smooth gameplay with AMD FreeSync™ technology

# Highlights

## Curved display design




Desktop monitors offer a personal user experience, which suits a curve design very well. The curved screen provides a pleasant yet subtle immersion effect, which focuses on you at the center of your desk.

## Ultra Wide-Color Technology



Ultra Wide-Color Technology delivers a wider spectrum of colors for a more brilliant picture. Ultra Wide-Color wider "color gamut" produces more natural-looking greens, vivid reds and deeper blues. Bring, media entertainment, images, and even productivity more alive and vivid colors from Ultra Wide-Color Technology.

## VA display



Philips VA LED display uses an advanced multi-domain vertical alignment technology which gives you super-high static contrast ratios for extra vivid and bright images. While standard office applications are handled with ease, it is especially suitable for photos, web-browsing, movies, gaming, and demanding graphical

applications. It's optimized pixel management technology gives you 178/178 degree extra wide viewing angle, resulting in crisp images.

## Crystalclear images




These Philips screens deliver Crystalclear, Quad HD 2560x1440 or 2560x1080 pixel images. Utilizing high performance panels with high density pixel count, enabled by high bandwidth sources like USB-C, Displayport, HDMI, these new displays will make your images and graphics come alive. Whether you are demanding professional requiring extremely detailed information for CAD-CAM solutions, using 3D graphic applications or a financial wizard working on huge spreadsheets, Philips displays will give you Crystalclear images.

## Ultra-smooth gaming



Gaming shouldn't be a choice between choppy gameplay or broken frames. With the new Philips monitor it doesn't have to be. Get fluid, artifact-free performance at virtually any framerate with AMD FreeSync™ technology, smooth quick refresh and ultra-fast response time.

## UltraNarrow Border




The new Philips displays feature ultra-narrow borders which allow for minimal distractions and maximum viewing size. Especially suited for multi-display or tiling setup like gaming, graphic design and professional applications, the ultra-narrow border display gives you the feeling of using one large display.

## Flicker-free technology



Due to the way brightness is controlled on LED-backlit screens, some users experience flicker on their screen which causes eye fatigue. Philips Flicker-free Technology applies a new solution to regulate brightness and reduce flicker for more comfortable viewing.

## LowBlue Mode



Studies have shown that just as ultra-violet rays can cause eye damage, shortwave length blue light rays from LED displays can cause eye damage and affect vision over time. Developed for wellbeing, Philips LowBlue Mode setting uses a smart software technology to reduce harmful shortwave blue light.



# Highlights

## Built-in stereo speakers



A pair of high quality stereo speakers built into a display device. It can be visible front firing, or invisible down firing, top firing, rear firing, etc depending on model and design.

## HDMI Ready



An HDMI-ready device has all the required hardware to accept High-Definition Multimedia Interface (HDMI) input. A HDMI cable enables high-quality digital video and audio all transmitted over a single cable from a PC or any number of AV sources (including set-top boxes, DVD players, A/V receivers and video cameras).

## DisplayPort connection



DisplayPort is a digital link from PC to Monitor without any conversion. With higher capabilities than DVI standard, it is fully capable to support up to 15meter cables and 10.8 Gbps/sec data transfer. With this high performance and zero latency, you get the fastest imaging and refresh rates - making DisplayPort the best choice for not only general office or home use, but also for the demanding gaming and movies, video editing and more. It also keeps interoperability in mind via use of various adapters.



Built-in Speaker

# Specifications

## Picture/Display

Panel Size: 31.5 inch / 80 cm  
 Aspect ratio: 16:9  
 LCD panel type: VA LCD  
 Backlight type: W-LED system  
 Pixel pitch: 0.272 x 0.272 mm  
 Brightness: 250 cd/m<sup>2</sup>  
 Display colors: 16.7 M  
 Color gamut (typical): NTSC 102%\*, sRGB 122.6%\*  
 Contrast ratio (typical): 3000:1  
 SmartContrast: 20,000,000:1  
 Response time (typical): 4 ms (Gray to Gray)\*  
 Viewing angle: 178° (H) / 178° (V), @ C/R &gt; 10  
 Picture enhancement: SmartImage game  
 Maximum resolution: 2560 x 1440 @ 75 Hz\*  
 Effective viewing area: 697.3 (H) x 392.3 (V) - at a 1800R curvature\*  
 Scanning Frequency: 70 - 115 kHz (H) / 48 - 75 Hz (V)  
 sRGB  
 Flicker-free  
 Pixel Density: 93 PPI  
 LowBlue Mode  
 Display Screen Coating: Anti-Glare, Haze 25%  
 AMD FreeSync™ technology

## Connectivity

Signal Input: VGA (Analog), DisplayPort x 1, HDMI (digital, HDCP)  
 Sync Input: Separate Sync, Sync on Green  
 Audio (In/Out): PC audio-in, Headphone out

## Convenience

Built-in Speakers: 3 W x 2  
 Plug & Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 10 / 8.1 / 8 / 7  
 User convenience: Power On/Off, Menu, Brightness, Input, SmartImage Game  
 OSD Languages: Brazil Portuguese, Czech, Dutch, English, Finnish, French, German, Greek, Hungarian, Italian, Japanese, Korean, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish, Ukrainian  
 Other convenience: Kensington lock, VESA mount (100x100mm)

## Stand

Tilt: -5/20 degree

## Power

Power supply: Internal, 100-240VAC, 50-60Hz  
 Off mode: < 0.3 W (typ.)  
 On mode: 60.35 W (typ.)  
 Standby mode: < 0.5 W (typ.)  
 Power LED indicator: Operation - White, Standby mode- White (blinking)  
 Energy Label Class: C

## Dimensions

Product with stand (mm): 713 x 525 x 236 mm  
 Packaging in mm (WxHxD): 827 x 626 x 233 mm  
 Product without stand (mm): 713 x 425 x 52 mm

## Weight

Product with packaging (kg): 10.45 kg  
 Product with stand (kg): 6.78 kg  
 Product without stand (kg): 6.40 kg

## Operating conditions

Altitude: Operation: +12,000ft (3,658m), Non-operation: +40,000ft (12,192m)  
 Temperature range (operation): 0°C to 40°C °C  
 MTBF: 50,000 hrs (excluding backlight) hour(s)  
 Relative humidity: 20%-80 %  
 Temperature range (storage): -20°C to 60°C °C

## Sustainability

Environmental and energy: RoHS, Mercury Free, WEEE  
 Recyclable packaging material: 100 %

## Compliance and standards

Regulatory Approvals: CE Mark, FCC Class B, CU-EAC, TUV/ISO9241-307, RCM, BSMI, PSB, MEPS, CB, cETLus

## Cabinet

Color: Black / Silver  
 Finish: Glossy

## What's in the box?

Cables: HDMI cable, Power cable  
 Monitor with stand  
 User Documentation

