



Philips
LCD monitor

43 cm (17")
SXGA

170C8FS

The very best in LCD display

An all new viewing experience! With SmartImage and SmartContrast for crystal clear pictures plus PerfectTune for quality-assured display, the 170C8 delivers the ultimate in display performance.

Outstanding front of screen performance

- SmartImage: Optimized user-friendly display experience
- SmartContrast: For incredible rich black details
- 5ms fast response time
- DVI-D input and HDCP support
- PerfectTune ensures top quality LCD display delivered to you
- Empowered for Windows Vista

Green design

- For your safety: Aerospace composite fire retardant case

Great convenience

- Hassle-free display performance tuning with SmartControl II
- Dual input accepts both analog VGA and digital DVI signals
- Cable clip manages cables for a tidy work space

PHILIPS

Highlights

SmartImage

SmartImage is an exclusive leading edge Philips technology that analyzes the content displayed on your screen and gives you optimized display performance. This user friendly interface allows you to select various modes like Office, Image, Entertainment, Economy etc., to fit the application in use. Based on the selection, SmartImage dynamically optimizes the contrast, color saturation and sharpness of images and videos for ultimate display performance. The Economy mode option offers you major power savings. All in real time with the press of a single button!

SmartContrast

SmartContrast is a Philips technology that analyzes the contents you are displaying, automatically adjusting colors and controlling backlight intensity to dynamically enhance contrast for the best digital images and videos or when playing games where dark hues are displayed. When Economy mode is selected, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.

5ms on/off response time

On-Off response time is the period required for a liquid crystal cell to go from active (black) to inactive (white) and back to active (black) again. It is measured in milliseconds. Faster is better: Lower response time means faster transitions and, therefore, results in fewer visible image artifacts in the display of

transition of texts and graphics. On-Off response time is a more important measure in the display of business content like documents, graphs and photos.

HDCP ready

High-Bandwidth Digital Content Protection (HDCP) is a copyright protection system that is incorporated into the DVI connector. It helps stop unauthorized duplication of copyrighted content. HDCP allows you to play protected content media such as movies and concerts. It checks the signal to prevent piracy, allowing only legal copies of content to display.

PerfectTune

PerfectTune is industry-leading, proprietary Philips testing and algorithm technology for monitor adjustment and fine tuning, an extensive process that ensures ultimate display performance in compliance with a standard four-times more stringent than Microsoft's Vista requirements from each and every monitor that leaves the factory - not just a few review samples. Only Philips goes to these lengths to deliver this exacting level of color accuracy and display quality in every new monitor.

Windows Vista ready

Philips Vista-ready monitors are empowered for vibrant, exciting display of this new, visually sophisticated and demanding Windows operating system, designed to enhance your entertainment experience, make you more

productive and help you control your computing experience at home and in the office, making viewing, finding and organizing information for work or play quick, efficient and easy.

Flame retardant cabinet

PC/ABS plastic composite is the industry's best and toughest flame-retardant casing material; and is a space-age compound deployed in the aerospace and automotive industries as well as in fire detectors that is compliant with most stringent fire safety standards.

SmartControl II

SmartControl II is monitor-based software with an easy-to-use on-screen graphic interface that guides you through fine-tuning resolution, color calibration and other display settings including brightness, contrast, clock & phase, position, RGB, white point and - on models with onboard speakers - volume adjustments.

Dual input

Dual input provides connectors to accommodate input of both analog VGA and digital DVI signals.

Cable clip

A clip shipped with monitors that manages cables by clipping them together for a tidy work space.



Specifications

Picture/Display

- LCD panel type: 1280 x 1024 pixels, Anti-glare polarizer, RGB vertical stripe
- Panel Size: 17"/ 43.3 cm
- Effective viewing area: 337.9 x 270.3 mm
- Pixel pitch: 0.264 x 0.264 mm
- Brightness: 300 cd/m²
- Contrast ratio (typical): 800:1
- SmartContrast ratio (dynamic): 3000:1
- Display colors: 16.7 M
- Viewing angle: 160° (H) / 160° (V), @ C/R > 10
- Response time (typical): 5 ms
- Maximum Resolution: 1280 x 1024 @ 75 Hz
- Optimum resolution: 1280 x 1024 @ 60 Hz
- Video Dot Rate: 140 MHz
- Horizontal Scanning Frequency: 30 - 83 kHz
- Vertical Scanning Frequency: 56 - 76 Hz
- Picture enhancement: SmartImage
- sRGB

Connectivity

- Signal Input: VGA (Analog), DVI-D
- Sync Input: Composite Sync, Separate Sync, Sync on Green

Convenience

- User convenience: On-screen Display, SmartControl II
- Monitor Controls: SmartImage, Input, Auto (Back), Brightness Control (Up/Down), Menu (OK), Power On/Off
- OSD Languages: English, French, German, Italian, Portuguese, Russian, Simplified Chinese, Spanish
- Other convenience: Kensington lock compatible
- Plug & Play Compatibility: DDC/CI, sRGB,

- Windows 98/ME/2000/XP/Vista
- Regulatory approvals: CE Mark, EMC, Energy Star, FCC-B, UL, CSA, SEMKO, TCO '99, TÜV/GS, TÜV Ergo
- Tilt: -2° to 20°

Accessories

- Included accessories: AC Power Cord, VGA cable
- User Manual

Dimensions

- Box dimensions (W x H x D): 488 x 482 x 189 mm
- Box dimensions in inch (W x H x D): 19.2 x 19 x 7.4 inch
- Set dimensions with stand (W x H x D): 403 x 392 x 171 mm
- Set dimensions with stand in inch (W x H x D): 15.9 x 15.5 x 6.7 inch
- MTBF: 50,000 hrs
- Relative humidity: 20% - 80%
- Temperature range (operation): 5°C to 35°C
- Temperature range (storage): -20°C to 60°C
- Product weight (+stand): 4.63 kg
- Product weight (+stand) (lb): 10.2 lb
- Weight incl. Packaging: 6 kg
- Weight incl. Packaging (lb): 13.2

Power

- Complies with: Energy Star
- Consumption (On mode): < 36W (Typical)
- Consumption (Off Mode): < 1 W
- Power LED indicator: Operation - green, Stand by/ sleep - Amber
- Power supply: Built-in, 100-240VAC, 50/60Hz



Issue date 2022-05-10

Version: 1.0.4

12 NC: 8670 000 36645
EAN: 87 12581 39183 6

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com