



Philips
LCD monitor

17"

SXGA

170S6FG



performance and convenience maximise your budget

This slim, compact 170S6 pumps up productivity with great performance and convenience while business-friendly features like SmartManage deliver the best total cost of ownership and lead-free design safeguards our environment.

Best total cost of ownership solution

- Power consumption below the industry average
- Kensington anti-theft lock-ready for added security
- Lead-free design safeguards our environment
- SmartManage compatibility enables LAN-based asset management
- Environmentally responsible Energy Star partner
- TCO'03 guarantees the highest safety and ergonomic standards

Outstanding front of screen performance

- SXGA 1280 x 1024 resolution for sharper display
- sRGB ensures colour matching between display and printouts
- 12ms On/off response time: Superior text and graphics display

Great convenience

- Easy, user friendly plug-and-play installation
- Embedded power supply eliminates external power adaptors
- Convenient, built in holder for notes, cards or photos

PHILIPS
sense and simplicity

Specifications

Picture/Display

- **LCD panel type:** 1280 x 1024 pixels, Anti-glare polarizer, RGB vertical stripe
- **Panel Size:** 17"/ 43 cm
- **Effective viewing area:** 337.9 x 270.3 mm
- **Pixel pitch:** 0.264 x 0.264 mm
- **Brightness (nits):** 250 nit
- **Contrast ratio (typical):** 500:1
- **Display colours:** 16.2 M
- **Viewing angle:** @ C/R > 5
- **Viewing Angle (H / V):** 160 / 155 degree
- **Response time (typical):** 12 ms
- **White Chromaticity, 6500K:** x = 0.313 / y = 0.329
- **White Chromaticity, 9300K:** x = 0.283 / y = 0.297
- **Maximum Resolution:** 1280 x 1024 @ 75 Hz
- **Recommended Resolution:** 1280 x 1024 @ 60 Hz
- **Factory Preset Modes:** 15 modes
- **User definable modes:** 50 modes
- **Video Dot Rate:** 140 MHz
- **Horizontal Scanning Frequency:** 30 - 83 kHz
- **Vertical Scanning Frequency:** 56 - 76 Hz
- **sRGB**

Connectivity

- **Signal Input:** Analogue (VGA)
- **Video Sync Input Signal:** Separate Sync, Composite Sync, Sync on Green

Convenience

- **Convenience Enhancements:** On-screen Display, SmartManage enabled
- **Monitor Controls:** Auto, Brightness Control, Left/Right, Menu (OK), Power On/Off, Up/Down
- **OSD Languages:** English, French, German, Italian,

Simplified Chinese, Spanish

- **Other convenience:** Kensington lock compatible, FlexiHolder
- **Plug & Play Compatibility:** DDC/CI, sRGB, Windows 98/ME/2000/XP
- **Regulatory Approvals:** CE Mark, E2000, EMC, Energy Star, FCC-B, UL, CSA, SEMKO, TCO '03, TÜV/GS, TÜV Ergo
- **Tilt:** -5° to 25°
- **VESA Mount:** 100 x 100 mm

Accessories

- **Included Accessories:** AC Power Cord, VGA cable
- **Optional accessories:** Super Ergo Base
- User Manual

Dimensions

- **Dimensions (with base) (W x H x D):** 375 x 390 x 200 mm
- **MTBF:** 50,000 hrs
- **Relative Humidity:** 20% - 80%
- **Temperature range (operation):** 5°C to 40°C
- **Temperature range (storage):** -20°C to 60°C
- **Weight:** 3.9 kg

Power

- **Complies with:** E2000, Energy Star, NUTEK
- **Consumption:** 30W (Typical)
- **Off Mode:** < 1 W
- **Power LED indicator:** Operation - green, Stand by/sleep - Amber
- **Power supply:** Built-in, 90-264 VAC, 50/60 Hz

Product highlights

SmartManage enabled

SmartManage is a system for monitoring, managing and checking status of display devices as well as delivering remote support to users who experience difficulties - all accomplished over a LAN.

Lead-free

Lead-free display products are designed and produced in compliance with strict European Community Restriction of Hazardous Substances (RoHS) standards that restrict lead and other toxic substances that can harm the environment.

Lower power consumption

Reduction of the electrical power required to operate a device.

TCO '03 compliance

A TCO (Swedish Confederation of Professional Employees) standard even more stringent than MPR-II for safety and ergonomics, especially concerning alternating electric fields (AEF).

Kensington lock compatible

Small apertures built into a display's frame for use with a locking device that secures a display to a fixed object for added protection against theft.

12ms response time (On-Off)

On-Off response time is the period required for a liquid crystal cell to go from active (black) to inactive (white) and back to active (black) again. It is measured in milliseconds. Faster is better: Lower response time means faster transitions and, therefore, results in fewer visible image artefacts in the display of transition of text and graphics. On-Off response time is a more important measure in the display of business content like documents, graphs and photos.

sRGB ready

sRGB is an industry standard that ensures the best possible match between the colours displayed on your screen and those in your printouts.

Embedded power supply

An embedded power supply is a power adaptor built into the body of a display device that replaces a bulky external power adaptor.

Easy plug-and-play

Plug-and-play is a peripheral connectivity standard. A plug and play display device can be connected to a PC and operate without requiring user intervention to adjust complicated settings.

FlexiHolder

FlexiHolder is a slim groove on the top of monitor that neatly and conveniently stores favourite photos, reminders, to-do lists or phone numbers in your line of sight.



Issue date 2007-12-07

Version: 3.0

12 NC: 8639 000 16148
EAN: 87 10895 88977 3

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com