



Philips Signage Solutions  
E-Line Display

**46"**

Edge LED Backlight  
Full HD  
OPS Slot

**Signage**Solutions

**BDL4652EL**

## Deliver your marketing messages in style

with this sleek LED display

Maximising your content delivery whilst lowering your TCO has never been so easy or stunning. This 46" display offers gorgeous full HD picture quality with lower power consumption thanks to the edge LED backlight.

### **Optimized for public viewing**

- Full HD LED technology for brilliant images
- AMVA for wide-view super-high contrast, vivid images

### **Lower total cost of ownership**

- SmartPower for energy saving

### **Operational flexibility**

- Portrait mode operability
- Smart Control Software Suite
- Open Pluggable Specification Slot
- Smart insert in the backcover to place a small pc
- Keep your content up and running with FailOver
- Designed for 24/7 operation
- IR Passthrough
- Enhanced zoom feature supports tiled matrix applications
- Many Functions. One Wire

# PHILIPS

# Highlights

## AMVA Display Technology

Philips AMVA LED display uses an advanced multi-domain vertical alignment technology which gives you super-high static contrast ratios for extra vivid and bright images. While standard applications are handled with ease, it is especially suitable for graphical demanding applications. It's optimized pixel management technology gives you 178/178 degree extra wide viewing angle, resulting in crisp images even in portrait mode.

## Smart Control

Control and manage all of the signage displays on your network with this powerful software tool which allows you to change the settings of your display centrally via an RJ45 or RS232 connection. Smart Control allows you to set the video input, modify the color settings, set the display's ID when creating video walls and even diagnose each display's status, giving you all the power you need to manage your displays from one central location.

## OPS Slot

Developed for the Digital Signage market, the Open Pluggable Specification (OPS) slot is

designed to make changing or upgrading your media player mere child's play. Simply plug your media player in to the display - and you're ready. No matter whether you have an entry level, mid-range or high-end media player, OPS is fully compatible bringing you a lower TCO over the longer term.

## SmartPower

The backlight intensity can be controlled and pre-set by the system to reduce the power consumption by up to 50%, which saves substantially on energy costs.

## FailOver

Keeping your content up and running is critical for demanding commercial applications. While it is unlikely you will face a content disaster, FailOver provides content protection with a revolutionary technology that plays back-up content on screen in the event of a media player failure. FailOver automatically kicks in when the primary input fails. Simply select a primary input connection and a FailOver connection and your ready for instant protection.

## Smart Insert

Professional PC's are part of most public signage installations. Quite often they increase the overall depth to the display and cause a lot of cable clutter. So we have designed this display with Smart insert in the back cover which is ideal for the integration of a professional small form factor PC. On top of that, the cable management system offers a great solution to keep your cables neat and professional looking.

## IR Passthrough

Control all displays in your signage network through one single remote control, via the primary display. Simple and convenient, this means you don't have to worry about other displays changing configuration settings when using your remote control unit.

## Zoom function for tiled matrix

The internal zoom function enables easy implementation of a video wall matrix, without the need for expensive external equipment. Capable of many different configurations, creating a stunning video wall has become simplicity itself.



# Specifications

## Picture/Display

- Diagonal screen size: 46 inch / 117 cm
- Panel resolution: 1920x1080p
- Optimum resolution: 1920 x 1080 @ 60Hz
- Brightness: 500 cd/m<sup>2</sup>
- Contrast ratio (typical): 4000:1
- Aspect ratio: 16:9
- Response time (typical): 6.5 ms
- Pixel pitch: 0.17675 x 0.53025 mm
- Display colors: 1.07 billion
- Viewing angle (H / V): 178 / 178 degree
- Picture enhancement: 3/2 - 2/2 motion pull down, 3D Combfilter, Motion compens. deinterlacing, 3D MA deinterlacing, Dynamic contrast enhancement

## Connectivity

- PC: RJ45, VGA-in D-Sub 15HD, RS232 D-Sub9, RS232 D-sub9 output, 3.5 mm PC audio input x1, VGA-out (via DVI-I)
- AV input: DVI-D x1, Component (BNC) x1, Composite (BNC) x1
- Other connections: OPS, Display Port, DVI Out, HDMI, AC-out, External loudspeaker connector, IR out
- AV output: Audio (L/R) x1

## Supported Display Resolution

### Computer formats

Resolution	Refresh rate
1920 x 1200	60Hz
1920 x 1080	60Hz
1600 x 1200	60Hz
1440 x 900	60Hz
1366 x 768	60Hz
1360 x 768	60Hz
1280 x 1024	60Hz
1280 x 800	60Hz
1280 x 768	60Hz
1024 x 768	60Hz
800 x 600	60, 72, 75Hz
640 x 480	60, 67, 72, 75Hz

### Video formats

Resolution	Refresh rate
480i	60Hz
480p	60Hz
576p	50Hz
576i	50Hz
720p	50, 60Hz
1080i	50, 60Hz
1080p	50, 60Hz

## Dimensions

- Set dimensions (W x H x D): 1052.7 x 607.3 x 69 mm
- Bezel width: 15.8 mm
- Product weight: 22.0 kg
- VESA Mount: 400 x 400 mm, 400 x 200 mm, 200 x 200 mm
- Smart Insert mount: 100 x 100 mm, 100 x 200 mm

## Convenience

- Signal loop through: DVI, VGA, RS232
- Network controllable: RJ45, RS232, HDMI (One Wire)
- Placement: Landscape, Portrait
- Picture in picture: PBP, PIP, POP
- Energy saving functions: Smart Power
- Ease of installation: AC Out, Smart Insert
- Keyboard control: Hidden, Lockable
- Other convenience: Carrying handles
- Packaging: Reusable box
- Tiled Matrix: Up to 5 x 5

## Power

- Standby power consumption: <0.5W
- Consumption (On mode): 66.89 W (EnergyStar 6.0 test method)
- Mains power: 100 ~ 240 VAC, 50 ~ 60 Hz

## Sound

- Built-in speakers: 2 x 10W RMS

## Operating conditions

- Temperature range (operation): 5 ~ 40 °C
- Temperature range (storage): -20 ~ 60 °C
- Relative humidity: 20 ~ 80 %
- Altitude: 0 ~ 3000 m
- MTBF: 50,000 hour(s)

## Accessories

- Included accessories: Remote Control, Batteries for remote control, AC Power Cord, VGA cable, User manual on CD-ROM, Quick start guide
- Stand: BM05462 (Optional)

## Miscellaneous

- On-Screen Display Languages: English, French, German, Spanish, Polish, Turkish, Russian, Simplified Chinese, Italian
- Regulatory approvals: CE, FCC, Class B, UL/cUL, CCC, C-Tick, RoHS, GOST
- Warranty: 3 year warranty



Issue date 2022-05-17

Version: 1.0.1

12 NC: 8670 001 10189  
EAN: 87 12581 70504 6

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)