



Philips Momentum
Wired mechanical gaming
keyboard

Rainbow backlight

Mechanical switches
Conflict free
Magnetic wrist rest

SPK8605



Brighten up your gaming

The new G600 series gaming keyboard features high speed mechanical keys for the dialed-in performance and magnetic wrist rest. Dual mode switchable, quickly adapt backlight and volume to any atmosphere.

Unique Design

- Dual-mode switchable
- Detachable palm rest

Cool looks to match your mod

- Rainbow backlight

Performance to dominate

- Dialed-in mechanical cyan switches for fast reaction
- Full-key roll over anti-ghosting for complex fast inputs

Philips reliability

- Aluminum alloy frame

PHILIPS

Wired mechanical gaming keyboard
Rainbow backlight Mechanical switches, Conflict free, Magnetic wrist rest

SPK8605/01

Highlights

Full n-key rollover



Fast complex gaming key strokes demand advanced performance. With full N-key rollover every key is registered independently without confusion so that each keystroke is correctly registered regardless of how many other keys are being pressed or held down at the time.

Fast mechanical switches



The most popular mechanical switches for gaming keyboards, Cyan mechanical switches offer gamers a light tactile clicky key for rapid activation and performance.

Aluminum alloy frame



The high-quality and durable aluminum alloy structure ensures the long-term service life of the keyboard.

Dual-mode switchable

Cool rotary controller, you can easily switch between gaming and work modes. Quickly adapt backlight and volume to any atmosphere.

Detachable palm rest



This magnetic palm rest can be easily connected to or detached from the keyboard as needed. It gently protects your wrists, so that you are free of exhaustion even after a long time gaming.

Rainbow backlight



Cool rainbow backlight gives you more immersive gaming experience, secure your victory every time.

Specifications

Technical specifications

- Product Type: High performance mechanical gaming keyboard
- Design Type: Ergonomic design
- Connectivity: USB 2.0 wired
- Front Panel Material: Alloy front-panel
- Front Panel Color: Black
- Keys: 104 Keys
- Key Rollover Type: Full Keys N-roller
- Key Lifespan: 50 million keystroke lifespan
- Travel Distance Type Of Key: Medium key travel
- Lighting Effect Type: Multi Color LED backlight
- Water Resistant: NO

Physical Dimensions

- Dimensions (LxWxH): 438*132*39mm
- Weight: 860g

OS/System Requirements

- System Requirements: Microsoft Windows XP, Windows Vista, Windows 7, Windows 8, Windows 10 or later



Issue date 2021-12-09

Version: 2.0.1

12 NC: 8670 001 72665
EAN: 87 12581 77380 9

© 2021 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com