



Philips
LCD monitor with HDMI,
Audio, SmartTouch

61 cm (24") w E-line
1920 x 1080 Full HD

244E1SB

Big HDMI display for Full HD entertainment

Entertain yourself with 16:9 Full HD 1080p performance! Combined with HDMI and DVI inputs, invisible stereo audio and attractive Glossy finish, the 244E1 is ready to entertain you

Great picture quality

- Full HD LCD display, 1920 x 1080p resolution
- 16:9 display for best widescreen gaming and video
- 5 ms fast response time
- SmartContrast 25000:1 for incredible rich black details

Design that complements any interior

- Glossy finish to enhance your decor

Experience true multimedia

- HDMI-ready for top quality, multimedia experience
- Built in stereo audio for multimedia experience

Great convenience

- Dual input accepts both analogue VGA and digital DVI signals
- Stylish SmartTouch controls
- Easy picture format control switching between wide and 4:3 formats

PHILIPS

Highlights

Full HD 1920 x 1080p LCD display

Enjoy crisp and crystal clear picture quality to give your audience a truly memorable visual experience. Your viewers will be treated to unsurpassed video, with an amazing colour gamut and the sharpest pictures around.

16:9 widescreen aspect ratio

An aspect ratio is an expression of a video image's width compared to its height. The 16:9 widescreen aspect ratio is standard for universal to high-definition television and European digital television. A native 16:9 aspect ratio means outstanding game and video display without bars at top and bottom of the picture and without the quality loss than comes from scaling, altering an image to fit on a different screen size.

Built-in stereo audio

A pair of high-quality stereo speakers built into a display device. They may be visible front firing, or invisible down firing, top firing, rear firing etc. depending on model and design.

SmartContrast ratio 25000:1



With SmartContrast



Without SmartContrast

You want the LCD flat display with the highest contrast and most vibrant images. Philips advanced video processing combined with unique extreme dimming and backlight-boosting technology results in vibrant images. SmartContrast will increase the contrast with excellent black level and accurate rendition of dark shades and colours. It gives a bright, lifelike picture with high contrast and vibrant colours.

HDMI Ready



HDMI-ready

An HDMI-ready device has all the required hardware to accept High-Definition Multimedia Interface (HDMI) input. An HDMI cable enables high-quality digital video and audio to be transmitted over a single cable from a PC or any number of AV sources (including set-top boxes, DVD players, A/V receivers and video cameras).

Dual input



VGA connector



DVI connector

Dual input provides connectors to accommodate input of both analogue VGA and digital DVI signals.

Easy picture format control



Widescreen format



4:3 format

Philips easy picture format control on OSD switches from the 4:3 aspect ratio to the widescreen mode and back again to match the display's aspect ratio with your content; it allows you to work with wide documents without scrolling or viewing widescreen media in the widescreen mode and gives you distortion-free, native mode display of 4:3 ratio content.

Specifications

Picture/Display

- LCD panel type: TFT-LCD
- Panel Size: 23.6 inch/59.95 cm
- Aspect ratio: 16:9
- Pixel pitch: 0.272 x 0.272 mm
- Viewing angle: 176° (H)/170° (V), @ C/R > 5
- Brightness: 300 cd/m²
- SmartContrast: 25000:1
- Response time (typical): 5 ms
- Optimum resolution: 1920 x 1080 @ 60 Hz
- Display colours: 16.7 M
- Scanning Frequency: 30–83 kHz (H)/56–75 Hz (V)
- sRGB

Connectivity

- Signal Input: VGA (Analogue), DVI-D, HDMI
- Sync Input: Separate Sync, Sync on Green

Convenience

- Built-in Audio: 2 W x 2
- User convenience: Input, Volume, Menu, Auto, Power On/Off
- OSD Languages: English, French, German, Spanish, Italian, Russian, Simplified Chinese, Portuguese, Turkish
- Other convenience: VESA mount (100 x 100 mm), Kensington lock
- Plug and Play Compatibility: DDC/CI, Mac OS X, Windows 7/Vista/XP/2000/98, sRGB

Stand

- Tilt: -5/20 degree

Power

- Power LED indicator: Operation - White, Standby/sleep-white (flashing)
- On mode: < 30.9 W (EnergyStar 5.0 test method)
- Power supply: Built-in, 100-240 VAC, 50/60 Hz
- Off mode: < 0.5 W

Dimensions

- Product with stand (mm): 400 x 561 x 210 mm
- Product without stand (mm): 336 x 561 x 68 mm
- Packaging in mm (W x H x D): 404 x 620 x 168 mm

Weight

- Product with stand (kg): 5.4 kg
- Product without stand (kg): 5.0 kg
- Product with packaging (kg): 7.2 kg

Operating conditions

- Temperature range (operation): 0°C to 40°C °C
- Temperature range (storage): -20°C to 60°C °C
- Relative humidity: 20%–80% %
- MTBF: 50,000 hour(s)

Sustainability

- Environmental and energy: EPEAT Silver, RoHS, EnergyStar 5.0

Compliance and standards

- Regulatory Approvals: CE Mark, FCC, Class B, SEMKO, UL/cUL

Cabinet

- Colour: Black
- Finish: Glossy



Issue date 2019-05-10

Version: 5.0.4

12 NC: 8670 000 53764
EAN: 87 12581 48900 7

© 2019 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com