



LCD monitor with SmartControl Lite

- V Line
- 22 (21.5" / 54.6 cm diag.)

223V5LHSB2/89

## Great LED images in vivid colors

Enjoy vivid LED pictures on this Philips display. Equipped with HDMI and SmartControl lite, it's a great choice!

### Benefits

#### Vivid pictures every time

- LED technology for vivid colors
- SmartContrast for rich black details
- 16:9 Full HD display for crisp detailed images
- Easy display performance tuning with SmartControl Lite

#### Experience multimedia

- HDMI-ready for Full HD entertainment

### Features

#### LED technology

White LED's are solid state devices which light up to full, consistent brightness faster saving startup time. LED's are free from mercury content which allows for eco-friendly recycling and disposal process. LED's allow for better dimming control of LCD backlight, resulting in super high contrast ratio. It also gives superior color reproduction thanks to consistent brightness across the screen.

#### Great choice

- Mercury Free eco-friendly display
- Compact design saves space
- VESA mount allows for flexibility

#### SmartContrast



SmartContrast is a Philips technology that analyzes the contents you are displaying, automatically adjusting colors and controlling backlight intensity to dynamically enhance contrast for the best digital images and videos or when

# PHILIPS

playing games where dark hues are displayed. When Economy mode is selected, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.

### 16:9 Full HD display



Picture quality matters. Regular displays deliver quality, but you expect more. This display features enhanced Full HD 1920 x 1080 resolution. With Full HD for crisp detail paired with high brightness, incredible contrast and realistic colors expect a true to life picture.

### SmartControl Lite

SmartControl Lite is the next generation 3D icon based GUI monitor control software. This allows user to fine-tune most parameters of the monitor like

## Specifications

[field not found 'disclaimer\_text']

### Picture/Display

|                          |                                       |
|--------------------------|---------------------------------------|
| LCD panel type           | TFT-LCD                               |
| Backlight type           | W-LED system                          |
| Panel Size               | 21.5 inch / 54.6 cm                   |
| Effective viewing area   | 476.64 (H) x 268.11 (V)               |
| Aspect ratio             | 16:9                                  |
| Optimum resolution       | 1920 x 1080 @ 60 Hz                   |
| Response time (typical)  | 5 ms                                  |
| Brightness               | 200 cd/m <sup>2</sup>                 |
| SmartContrast            | 10,000,000:1                          |
| Contrast ratio (typical) | 600:1                                 |
| Pixel pitch              | 0.248x 0.248 mm                       |
| Viewing angle            | 90° (H) / 65° (V)<br>@ C/R > 10       |
| Display colors           | 16.7 M                                |
| Scanning Frequency sRGB  | 30 -83 kHz (H) / 56 -76 Hz (V)<br>Yes |

### Connectivity

|              |                                      |
|--------------|--------------------------------------|
| Signal Input | HDMI (digital, HDCP)<br>VGA (Analog) |
| Sync Input   | Separate Sync<br>Sync on Green       |

### Convenience

|                  |                                                                                                                                                                                      |
|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| User convenience | Auto/Down<br>4:3 Wide/Up<br>Brightness/Back<br>Menu/OK<br>Power On/Off                                                                                                               |
| OSD Languages    | Brazil Portuguese<br>Czech<br>Dutch<br>English<br>Finnish<br>French<br>German<br>Hungarian<br>Italian<br>Japanese<br>Korean<br>Polish<br>Portuguese<br>Russian<br>Simplified Chinese |

Color, Brightness, screen calibration, Multi-media, ID management, etc with the mouse.

### HDMI Ready



An HDMI-ready device has all the required hardware to accept High-Definition Multimedia Interface (HDMI) input. A HDMI cable enables high-quality digital video and audio all transmitted over a single cable from a PC or any number of AV sources (including set-top boxes, DVD players, A/V receivers and video cameras).

### Mercury Free

Philips monitors with LED backlighting are free of Mercury content, one of the most toxic natural substances, which affects humans and animals. This reduces the environmental impact of the display throughout its life-cycle, from manufacturing to disposal.

|                           |                                                                                                                         |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------|
| Other convenience         | Spanish<br>Swedish<br>Turkish<br>Ukrainian<br>Greek<br>Traditional Chinese<br>Kensington lock<br>VESA mount (100x100mm) |
| Plug & Play Compatibility | DDC/CI<br>Mac OS X<br>sRGB<br>Windows 7<br>Windows 8                                                                    |

### Stand

|      |              |
|------|--------------|
| Tilt | -5/20 degree |
|------|--------------|

### Power

|                     |                                                     |
|---------------------|-----------------------------------------------------|
| On mode             | 15.3 W (typ.) (EnergyStar 7.0 test method)          |
| Standby mode        | 0.5 W                                               |
| Off mode            | 0.5 W                                               |
| Power LED indicator | Operation - White<br>Standby mode- White (blinking) |
| Power supply        | Built-in<br>100-240VAC, 50-60Hz                     |

### Dimensions

|                            |                    |
|----------------------------|--------------------|
| Product with stand (mm)    | 503 x 376 x 213 mm |
| Product without stand (mm) | 503 x 316 x 50 mm  |
| Packaging in mm (WxHxD)    | 555 x 414 x 107 mm |

### Weight

|                             |         |
|-----------------------------|---------|
| Product with stand (kg)     | 2.61 kg |
| Product without stand (kg)  | 2.35 kg |
| Product with packaging (kg) | 3.87 kg |

### Operating conditions

|                               |                                                                   |
|-------------------------------|-------------------------------------------------------------------|
| Temperature range (operation) | 0°C to 40°C °C                                                    |
| Temperature range (storage)   | -20°C to 60°C °C                                                  |
| Relative humidity             | 20%-80 %                                                          |
| Altitude                      | Operation: +12,000ft (3,658m), Non-operation: +40,000ft (12,192m) |
| MTBF                          | 30,000 hour(s)                                                    |

### Sustainability

|                               |                       |
|-------------------------------|-----------------------|
| Environmental and energy      | RoHS                  |
| Recyclable packaging material | Mercury Free<br>100 % |

### Compliance and standards

|                      |                                                                                        |
|----------------------|----------------------------------------------------------------------------------------|
| Regulatory Approvals | BSMI<br>CE Mark<br>FCC Class B<br>SEMKO<br>TUV/ISO9241-307<br>cETLus<br>EAC<br>INMETRO |
|----------------------|----------------------------------------------------------------------------------------|

### Cabinet

|        |                                               |
|--------|-----------------------------------------------|
| Color  | Black                                         |
| Finish | Hairline (front bezel) / Texture (rear cover) |



data subject to change  
2023, June 18

Version: 5.0.1  
EAN: 8712581747107

© 2023 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)