



Philips PerfectCare Azur Steam iron

Steam 50 g/min; 210 g steam
boost

T-ionicGlide soleplate
Safety Auto off + Anti-calc
Safe for all ironable garments



GC4928/30

Fastest Philips steam iron*

From jeans to silk in one go

Iron any ironable garment from jeans to silk, from linen to cashmere safely in one go; in any order without temperature adjustment. PerfectCare Azur delivers perfect results with no risk of burn or shine. Ironing is now easier and faster.

Fast and powerful ironing

- Steam boost up to 210 g
- 3000 W iron for fast heat-up
- Steam output of up to 50 g/min for better crease removal

Comfortable ironing

- Innovative CordGuide
- T-ionicGlide: our best 5-star rated soleplate
- Suitable for tap water with Double Active Calc Clean system
- Iron switches off automatically when left unattended

One perfect setting for all your clothes

- 100% safe on all ironable garments
- 100% easy to use, no adjustment required

One perfect setting for all your clothes

- 100% fast on all fabrics; no other steam iron is faster
- OptimalTemp technology: perfect combination of temperature

PHILIPS

Steam iron

Steam 50 g/min; 210 g steam boost T-ionicGlide soleplate, Safety Auto off + Anti-calc, Safe for all ironable garments

Highlights

OptimalTemp technology



The latest revolution in ironing to deliver the perfect combination of steam and temperature. It's made to ensure you get speedy ironing and great results on tough creases, with no setting required, and is safe on all ironable fabrics. The perfect combination of steam and temperature because: 1) the Smart Control Processor sets the right temperature 2) the HeatFlow technology enables an even steam and temperature balance.

100% safe



100% safe on all fabrics even the most delicate like silk, cashmere, wool, polyester. Independent iron testing institutes have used PerfectCare on the most sensitive ironable garments and they confirmed excellent ironing results.

100% fast

100% fast to iron, no sorting required. Iron all your garments with more effective steam.

100% easy to use



100% easy to use, no adjustment required. You can now iron all ironable garments one after the other, without having to wait or to adjust the iron's temperature dial.

T-ionicGlide soleplate



T-ionicGlide is Philips' premium soleplate. Delivering a new standard in glide and scratch-resistance for OptimalTemp irons. The patented new coating will secure excellent results. The carefully designed shape and vent holes provide even steam distribution for easy crease removal with the steam iron.

Suitable for tap water



PerfectCare Azur steam iron is designed to be used with tap water. Double Active Calc

GC4928/30

Clean: A smart combination of Calc Pills and a regular Self Clean reduce the scale built-up. For better ironing results we recommend to use demineralised water. This ensures a consistent steam flow from your iron.

Safety auto off



The iron shuts off automatically when left unattended. If left on it's heelrest the steam iron will switch off in 3 minutes, when left resting on the soleplate it will take 2 minutes before the iron shuts off.

CordGuide



The innovative CordGuide simply clicks onto your ironing board and guides the cord away while you iron.

Steam iron

Steam 50 g/min; 210 g steam boost T-ionicGlide soleplate, Safety Auto off + Anti-calc, Safe for all ironable garments

GC4928/30

Specifications

Calc management

- Suitable for tap water
- Calc clean reminder: Yellow flashing
- Calc clean solution: Double active calc clean

Accessories

- CordGuide
- Filling cup

Technical specifications

- Weight of iron: 1.75 kg

Easy to use

- Water tank capacity: 350 ml
- Safety auto off
- Soft grip
- Drip-stop
- Cord freedom (swivel): 180 degree cord freedom

- Cord storage: Cord clip
- Power cord length: 2.5 m
- Fast and easy filling
- CordGuide: Keep your cord out of the way

Comfortable ironing

- Cord length: 2.5 m

Sustainability

- Energy saving: 10% energy reduction

Fast and powerful crease removal

- Soleplate: T-ionicGlide
- OptimalTEMP technology
- Continuous steam output: Up to 50 g/min
- Power: 3000 W
- Steam boost: 210 g
- Spray



Issue date 2023-10-10

Version: 1.0.2

EAN: 87 10103 73974 6

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Tested against Philips steam irons