



Philips MiniVac
Stick vacuum cleaner

2-in-1
14.4 V

FC6095/71

The first anti-allergy Mini Vac by Philips

Most powerful cordless 2-in-1

The Philips MiniVac 2-in-1 14.4 V is the first MiniVac that has a HEPA filter to trap even the finest dust. Moreover, it is the most powerful 2-in-1 cordless cleaner that tackles every spot and floor.

Clean air in your home

- HEPA filter to trap the fine dust

Lasting cleaning performance

- Cyclonic airflow and 2-stage filtration system

Cleaning in comfort

- Exceptionally quiet

Environmentally friendly, longer-lasting power

- Green NiMH battery, longer-lasting performance

Easy to empty and hygienic to clean

- One-step click-off nozzle, dishwasher safe

PHILIPS

Stick vacuum cleaner
2-in-1 14.4 V

Highlights

Exceptionally quiet



The Philips Mini Vac, with its powerful motor, is exceptionally quiet thanks to its special streamlined design. The comfortable noise level allows you to tidy up your home any time you want to.

Green NiMH battery, longer-lasting performance

Nickel-Metalhydride (NiMH) batteries are green batteries. This means they do not have highly toxic elements, which makes them better for the environment. Furthermore NiMH batteries have longer-lasting power that ensures performance over time.

HEPA filter to trap the fine dust

The HEPA filter ensures the fine dust and microscopic vermin stay inside the dirt chamber.

One-step click-off nozzle, dishwasher safe

The Philips Mini Vac is easy and quick to empty and hygienic to clean. The Philips Mini Vac has a nozzle that easily clicks off in just one step, so you can empty the Mini Vac without touching the dirt. When the nozzle needs cleaning, you simply put it in the dishwasher. That way you've always got a spotless, dirt-free Mini Vac at hand.

Cyclonic and 2-stage filter



The Philips MiniVac's cyclonic airflow keeps the dirt inside rotating to ensure optimal, high suction power and lasting cleaning performance. Its 2-stage filtration system ensures that, once inside, the dirt cannot escape. The first filter blocks most dirt, while the pleated, second filter traps the finer dust particles.

Telescopic stick, self-standing, direct charge



The FC6094/11 is a real 2-in1, it is used as handheld or handstick. With the telescopic stick and floor nozzle it cleans comfortably spills and messes even across larger areas. After use the FC6094/11 can be parked in between cleaning jobs and directly charged when needed.

FC6095/71

Specifications

Nozzles and accessories

- Other accessories: Charging base
- Standard nozzle: Floor nozzle

Design

- Design features: Translucent dust chamber
- Color: Titanium and fresh red

Weight and dimensions

- Dimensions of packaging (LxWxH): 195 x 190 x 528 mm
- Appliances per A-box: 4
- Weight of product: 1.6 kg
- Dimensions of A-box (LxWxH): 403 x 393 x 546 mm

Performance

- Battery type: NiMH
- Battery voltage: 14.4 V
- Charging time: 16-18 hour(s)
- Vacuum (max): 5 kPa
- Runtime: 11 minute(s)
- Input power (max): 130 W
- Suction power (max): 26 W
- Noise level (Lc IEC): 80 dB
- Airflow (max): 900 l/min

Filtration

- Dust capacity: 0.5 L
- Filter system: 2-stage HEPA

Usability

- Special features: Charging indication, Soft touch handle, Direct charging plug
- Tube type: Telescopic tube



Issue date 2023-08-19

Version: 1.1.1

EAN: 87 10103 57575 7

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com