

Philips PerfectCare Viva
Steam generator iron

Max 6 bar pump pressure

Up to 340 g steam boost
2-l water tank capacity
Compact design



GC7057/20

Iron faster with 2 x more steam *

no temperature setting required

Philips steam generator iron delivers a faster and easier ironing experience. Iron your garments with no temperature adjustment needed thanks to the revolutionary OptimalTEMP technology.

Compact technology

- Lightweight and compact size for easy storage
- Large water tank for longer continuous use
- Safe and secure carry lock
- Automatic switch-off for safety and energy saving

No temperature setting needed; no burning, guaranteed

- Go from ironing jeans to silk; no need to change temperature setting
- Safe to leave the hot soleplate on the ironing board

Fast ironing with continuous powerful steam

- Powerful steam for ultimate crease removal
- Integrated easy-clean system for long-lasting performance
- Philips' best gliding with increased scratch resistance
- Save energy with ECO mode

PHILIPS

Highlights

Ultra-powerful steam



An ultra-fast ironing experience can be yours with revolutionary technology. The powerful and continuous steam tackles even tough creases, and thicker fabrics are smoothed out with ease and speed. Plus there's an extra steam boost if needed, perfect for vertical steaming or stubborn creases.

OptimalTEMP technology



With OptimalTEMP technology you'll no longer have to waste time changing temperature settings, waiting for the temperature to adjust or pre-sorting clothes. Iron all fabrics, from jeans to silk, with no burning guaranteed thanks to the perfect combination of temperature and continuous powerful steam.

Safe rest



Innovative OptimalTEMP technology guarantees no burning on any ironable fabric. As well as the reassurance this provides whilst ironing, it also means you can leave the hot iron soleplate directly on your cotton ironing board without causing any damage. This helps to reduce any discomfort to your wrists, as you won't need to lift the iron to and from its base as often.

2-l water tank



The water tank has an extra-large 2-l capacity, so you get the convenience of up to 2 hours of continuous use with no need to top up the tank. It's also transparent, so you can get a 360° view of the tank to easily see how much water you have left to continue creating steam efficiently. When you do need to refill, your steam generator iron has a large filling hole that allows you to easily fill the water tank under the tap, or alternatively with a jug or bottle at any time during ironing.

Smart Calc clean



Regular descaling protects your iron and maintains steam performance. The Smart Calc-Clean system is an integrated descaling and cleaning function to extend the lifespan of your steam generator iron. The iron will remind you with both light and sound that cleaning and descaling is needed. Simply place your iron onto the Smart Calc-Clean container and start the process. It takes approx. 2 minutes for the dirty water and scale to be collected; your steam generator will beep once it's finished and ready to use again.

Lightweight and compact size



Thanks to revolutionary ProVelocity technology, we've been able to make a steam generator more compact than ever before. The smaller size fits perfectly on your ironing board for convenience, and carrying it around is made far easier. Plus your steam generator iron will take up much less storage space.

Steam generator iron
Max 6 bar pump pressure Up to 340 g steam boost, 2-l water tank capacity, Compact design

GC7057/20

Specifications

Storage

- Carry lock: For transportation and safety
- Cord storage: Velcro fix
- Hose storage: Hose storage compartment

Easy to use

- Heat-up time: 2 min
- Safe on all ironable fabrics: Even delicates like silk
- Soleplate gliding performance: 5 stars
- Soleplate name: SteamGlide Plus
- Safety auto off
- Cord freedom (swivel): 360 degree cord freedom
- Refill anytime during use
- Tap water suitable
- Power cord length: 1.8 m
- Hose length: 1.6 m
- Ready to use: Light indicator, Sound indicator
- Soleplate scratch resistance: 4 stars
- Extra-large filling hole

Accessories included

- Calc clean container

Technology

- OptimalTEMP technology
- For all ironable fabrics
- No burns

- No temperature settings needed
- ProVelocity steam engine
- Smart Control Processor

Fast crease removal

- Pressure: Max 6 bar pump
- Power: 2400 W
- Steam boost: up to 340 g
- Continuous steam: up to 120 g/min
- Vertical steam
- Voltage: 220 - 240 V
- Ready to use: 2 min
- Variable steam levels
- Steam-on-demand

Scale management

- Descaling and cleaning: Smart Calc Clean
- Descaling reminder: Light, Sound, Yes, no cartridges needed, no extra

Size and weight

- Weight of iron: 1.2 kg
- Packaging dimensions (W x H x D): 42.7 x 23.8 x 33.5 cm
- Product dimensions (W x H x D): 32.2 x 19.4 x 23.6 cm
- Weight of iron + base: 4.1 kg



Issue date 2023-08-21

Version: 1.0.2

EAN: 87 10103 81065 0

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Compared to Philips steam iron EasySpeed