



Saeco Xelsis Evo Super-automatic espresso machine

- Brews 8 coffee varieties
- Integrated milk jug & frother
- Stainless steel
- 8 step adjustable grinder



HD8954/01

Multi-beverage, multi user with full automated dual cleaning milk carafe

With Xelsis Evo espresso machine every family member can enjoy his or her favorite coffee. Thanks to the unique multi-user function up to 6 personal user profiles can be created and for each profile up to 9 beverages can be personalized.

A variety of coffees customized to your taste

- Enjoy a crema layer as you like it with a twist of a knob
- Fine-tune the coffee's richness with 8 grinder settings
- Save your favorite coffee with 6 user profiles

High comfort is part of the experience

- The fully removable brewing group can be cleaned in no time

Advanced technology designed for coffee perfection

- 20,000 cups of finest coffee with durable ceramic grinders

 **Saeco**

Highlights

100% Ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma, delivering a superior coffee taste for at least 20,000 cups.

Removable brewing group



Efficiency and ease of use were key inspirations when Saeco invented the first brewing group 30 years ago. And to this day, it still proves to be an inspired, resolute piece of technology. As always, it's so simple to clean – just remove it and wash it under the tap for a few seconds, then re-insert it just as easily.

Fine-tune the coffee's flavor



When it comes to the fineness of the grind, this machine never fails to satisfy. Different coffee blends

require different levels of granularity for the full flavor to unfold. So the grind granularity of this machine has eight adjustable settings – from the finest grind for a full-bodied espresso, to the coarsest for a lighter coffee

Refine crema and body quality



Enjoy a crema layer just the way you like it and discover a wide spectrum of tastes, all with the twist of a knob! You control the coffee flow and brew pressure to vary the body and thickness of the crema with one easy move. Turn it left for a luxurious, thick crema layer and an intense and full bodied espresso; Or turn it right for a smooth, lighter tasting coffee with less crema.

Customize and save your cup



Each cup will be shaped exactly to your taste. The ultimate customisation feature lets you personalise and memorise all your drinks down to the finest detail. And as there's 6 user profiles to fill, everyone using the machine can claim their cup of perfection.

Specifications

Country of origin

- Made in: Italy

Technical data

- Voltage: 230 V
- Power: 1500 W
- Pump Pressure: 15 bar
- Frequency: 50 Hz

Technical specifications

- Capacity bean container: 350 g
- Cord length: 0.8 m
- Voltage: 230 V
- Frequency: 50 Hz
- Brewing time one cup: 45 (espresso) to 100 (long coffee) s
- Capacity milk carafe: 500 L
- Capacity waste container: 14 servings
- Capacity water tank: 1.6 L
- Pump pressure: 15 bar
- Max. cup height: 150 mm
- Water boilers: 2

Design

- Colour: Stainless Steel
- Color: Stainless steel
- Materials and finishing: Full stainless steel

Weight and dimensions

- Waste container capacity: 14 servings
- Weight: 16,5 kg
- Product dimensions (L x D x H): 280x370x420 mm
- Coffee bean capacity: 350 g
- Dimensions of product (WxDxH): 280 x 420 x 375 mm
- Weight of product: 16.1 kg
- Milk carafe capacity: 0.5 L
- Water tank capacity: 1.6 L

General specifications

- Cups at the same time: 2
- Suitable for: Whole coffee beans, ground coffee powder
- Coffee strength settings: 3
- Ease of cleaning & maintenance: Automatic de-scaling cycle, Automatic rinse cycle, Automatic carafe cleaning, Removable brewing group
- Customizing per drink: Adjustable milk foam amount, Adjustable coffee strength, Adjustable cup volume, Adjustable temperature
- Grinder settings: 8
- Ease of use and comfort: Automatic shut-off, Display, Removable drip-tray, Removable spout, Automatic stand-by, Removable water tank
- One touch variety: 9
- Temperature settings: 3
- Special functions: Ceramic grinder, Integrated carafe, Ground coffee option, Pre-brewing, Crema adjustment knob
- Type of carafe: Basic carafe
- Type of display: TFT

Finishing

- Material of main body: Stainless steel
- Material boiler: Stainless steel (Inox)
- Material drip tray: Stainless steel
- Material water tank: Plastic

Service

- 2-year guarantee

Sustainability

- Power consumption brewing: 1500 W