

Philips PerfectCare
Performer
Steam generator iron

Max 6.5-bar pump pressure

Up to 410 g steam boost
SoftGrip
1.8 l detachable water tank

GC8733/20



Powerful continuous steam for ultra-fast ironing

Quiet technology and 1.8-l detachable water tank

The Philips PerfectCare Performer steam generator iron ensures a truly simple, powerful and burn-free ironing experience. The powerful continuous steam penetrates deeply and continuously into the fibre to remove creases easily.

Fast and powerful ironing

- Compact ProVelocity Steam Engine: continuous steam, all the time
- Continuous steam up to 120 g/min
- 1.8-l detachable water tank, up to 2 hours of ironing
- Tap water-friendly, refill any time during ironing
- Smart Calc cleaning system with a sound and light cleaning reminder
- Ready to use in 2 minutes with unlimited refill
- Saving energy with ECO mode
- Lighter weight steam generator from Philips
- SoftGrip: Amazingly comfortable handle
- Max 6.5-bar pump pressure

Carefree ironing, no temperature setting required

- Iron everything from jeans to silk with no temperature setting required
- Safe to leave the hot soleplate on the ironing board
- Enjoy powerful ironing with minimal sound

PHILIPS

Steam generator iron
Max 6.5-bar pump pressure Up to 410 g steam boost, SoftGrip, 1.8 l detachable water tank

GC8733/20

Highlights

1.8 l detachable water tank



The water tank can be removed to be refilled easily under the tap. The large filling hole makes refilling fast. Thanks to the 1.8-l water tank capacity, you can iron for up to 2 hours continuously without any refills.

ProVelocity Steam Engine

Water is transferred from the water tank to the iron by a high-pressure pump. A lot of water travels inside the steam chamber at very high speed. This causes very powerful and constant steam to come out from the soleplate all the time, without water condensation.

Continuous steam



The more steam, the faster the ironing. The unique technology in a Philips steam generator iron generates powerful steam making ironing easier, better and faster.

Energy saving



By using ECO mode and a reduced amount of steam, you can save energy without compromising on the ironing results.

Lighter weight steam generator

Thanks to the revolutionary ProVelocity technology, we made your steam generator iron more compact than ever before. The compact steam generator fits easily on your ironing board making your ironing more convenient. In addition, your steam generator takes much less storage space.

OptimalTEMP technology



"Now you can iron from jeans to silk with no temperature setting required. Guaranteed not to burn any ironable fabrics. Revolutionary technology with the 1) Advanced Smart Control Processor which controls precisely the soleplate temperature. You do not need to

adjust the temperature 2) Compact ProVelocity steam engine delivers more steam for faster ironing. It features a compact design for easier storage"

Refill with tap water any time



Your steam generator iron is designed to use tap water. While ironing, when the water tank runs out of water, you can easily refill it without having to wait or turn off your appliance.

Safe rest



The innovative Philips OptimalTEMP technology guarantees no burns on all ironable fabrics. During ironing, there is no need to put your iron back on the base station; just leave the hot iron soleplate directly on the garments or cotton ironing board cover without an additional resting accessory. It will not damage any of your ironable garments, or the board. This makes your ironing easier, with less wrist effort.

Specifications

Storage

- Carry lock: For transportation and safety
- Cord storage: Velcro fix, Yes
- Hose storage: Hose storage compartment

Easy to use

- Safe on all ironable fabrics: Even delicates like silk
- Soleplate gliding performance: 5 stars
- Soleplate name: SteamGlide Plus
- Safety auto off
- Soft grip
- Detachable water tank
- Refill anytime during use
- Power cord length: 1.8 m
- Hose length: 1.6 m
- Precision steam tip
- Ready to use: Light indicator, Sound indicator
- Soleplate scratch resistance: 4 stars

Guarantee

- 2 year worldwide guarantee

Technology

- OptimalTEMP technology
- For all ironable fabrics
- No burns
- ProVelocity steam engine

- Smart Control Processor
- Quiet pump

Fast crease removal

- Pressure: Max 6.5-bar pump
- Power: 2600 W
- Steam boost: Up to 410 g
- Continuous steam: Up to 120 g/min
- Vertical steam
- Ready to use: 2 min
- Variable steam levels
- Steam-on-demand

Green efficiency

- Energy saving mode
- Product packaging: 100% recyclable
- User manual: 100% recycled paper

Scale management

- Descaling and cleaning: Smart Calc Clean
- Descaling reminder: Light, Sound, Yes

Size and weight

- Weight of iron: 1.22 kg
- Product dimensions (W x H x D): 22 x 24 x 37 cm
- Weight of iron + base: 3.2 kg



Issue date 2023-08-21

Version: 1.0.2

EAN: 87 10103 78985 7

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com