



Saeco Via Venezia Manual Espresso machine

- Classic Milk Frother
- Black

R19366/47

The Authentic Italian Espresso

With a professional quality

Professional Coffee quality in your kitchen. Thanks to high capacities combined with the patented pressurized filter Crema, you can delight your guests as a professional barista. Enjoy your espresso since its preparation

Authentic Italian Espresso

- Pressurized Crema filter holder
- 15 bar pump


Simplicity and speed of use

- Ergonomic in day by day operations
- Suitable for ground coffee and pads
- Delicious milk froth thanks to the classic milk frother

High espresso capacity

- 2,9 liter water tank for high capacity

 **Saeco**



Highlights

Pressurized Crema filter



This special Crema filter guarantees a long-lasting, delicious Crema – whatever coffee blend you may choose.

15 bar pump



High pressure ensures that the ground coffee entire aroma is always fully extracted

2,9 liter water tank



The extra large water tank permits many coffee brewings and steam uses with less refilling.

Ground coffee and pads



For your convenience you can choose between ground coffee pads

Ergonomic in day by day



Refilling coffee powder or water, emptying the filter or the drip tray. All compartments are directly accessible for maximum convenience.

Classic milk frother



This Saeco espresso machine comes with the classic milk frother that baristas call a “Pannarello”. It dispenses steam and is immersed in milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

Specifications

Country of origin

- Made in: China

Technical specifications

- Voltage: 120 V
- Cord length: 0.8 m
- Frequency: 60 Hz
- Capacity water tank: 2 L
- Pump pressure: 15 bar
- Max. cup height: 75 mm
- Water boilers: 1

Design

- Color: Black

Weight and dimensions

- Dimensions of product (WxDxH): 270 x 375 x 345 mm
- Weight of product: 8.2 kg

General specifications

- Cups at the same time: 2
- Suitable for: Ground coffee powder
- Ease of use and comfort: Cup warmer
- Special functions: Steam option, Hot water option, Manual milk frother Pannarello
- Coffee drinks: Espresso

Finishing

- Material of main body: Stainless steel
- Material boiler: Stainless steel (Inox)
- Material drip tray: Stainless steel
- Material filter holder: Stainless steel & plastic
- Material water tank: Plastic
- Material panarello: Plastic

Service

- 1-year guarantee

Sustainability

- Power consumption brewing: 950 W



Issue date 2023-08-22

Version: 1.1.1

UPC: 7 08461 10414 4

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com