



Saeco Odea
Super-automatic
espresso machine

- Classic Milk Frother
- Black

R19755/47

Espresso in a trendy and functional design

The Odea line of super-automatic espresso machines

Saeco Odea espresso machines offer you great tasting espresso from your favorite coffee beans with the touch of a single button.

Authentic Italian coffee perfection

- Delicious milk froth thanks to the classic milk frother
- Coffee without waiting thanks to the quick heat boiler
- Every bean ground perfectly with our metal grinders

Ease of cleaning and maintaining

- Always a clean machine thanks to automatic circuit cleaning
- Easy cleaning thanks to removable brewing group


Set the beverages to suit your taste

- Save your favorite coffee length and strength

Set the beverages to suit your taste

- Play with the coffee's richness with our adjustable grinders

 **Saeco**



Highlights

Automatic circuit cleaning



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee.

Quick heat boiler



The Saeco quick heat boiler technology ensures your machine is always ready. Now you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

Classic milk frother



This Saeco espresso machine comes with the classic milk frother that baristas call a "Pannarello". It dispenses steam and is immersed in milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

Metal grinders



Our metal grinders always guarantee impeccable grinding.

Saves coffee length & strength



You will always get a perfect cup of espresso brewed according to your personal preference, thanks to our memo function which allows you to adjust the coffee length and strength to suit your taste. Enjoy a superb coffee drink in your favorite cup with just the press of a button.

5 step adjustable grinders



Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full bodied espresso, to the coarsest, for a lighter coffee.

Specifications

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

Technical specifications

- Voltage: 120 V
- Cord length: 80 cm
- Supported coffee types: Whole coffee beans
- Boiler material: Stainless steel (Inox)
- Power: 1400 W
- Country of origin: Designed in Italy, Made in Europe
- Frequency: 60 Hz
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 1 boiler
- Removable brewing group

Design

- Colour: Black
- Materials and finishing: Plastic

Weight and dimensions

- Coffee bean capacity: 180 g
- Product dimensions (L x D x H): 292 x 381 x 368 mm
- Product weight: 8.5 kg
- Waste container capacity: 14 servings
- Maximum cup height: 150 mm
- Water tank capacity: 1.5 L

Service

- 1-year guarantee



Issue date 2023-08-22

Version: 1.1.1

UPC: 7 08461 00019 4

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com