

Saeco Syntia  
Super-automatic  
espresso machine

- Digital
- Stainless steel

R19837/01



# Cafe enjoyment in perfect style

## Compact and high performing

With the Saeco Syntia the enjoyment starts right when you unwrap it from its packaging. Thanks to its puristic design and its stainless steel surface it will become a true jewel in your family kitchen.

### **Ease of cleaning and maintaining**

- Always a clean machine thanks to auto-clean and descaling

### **Perfect espresso**

- Ceramic grinders for Aroma preserving
- Pre-brewing function for flavor enhancing

### **Easy to use**

- Frontal access for easy filling and emptying
- Intuitive user colour interface


### **Easy to use**

- Easy cleaning thanks to removable brewing group

### **Family friendly**

- Energy efficient
- Sound demping system

 **Saeco**



# Highlights

## Intuitive user interface

Short or long coffee with one touch, your favourite length easily stored with the memo option – it's all easy with the wide display and its self explanatory icons.

## Easy frontal access

All machine elements you need to reach during your day-by-day enjoyment (water, coffeebeans and coffee grounds container, drip tray, removable brewing group) are completely independent and reachable either from the front or from the top.

## Energy efficient

This feature keeps the power consumption to a minimum. In fact, less than 1 Watt per hour is needed in stand-by mode, automatic after 1hour, saving resources and money

## Sound demping system

Special insulation and super-silent ceramic grinders preserve the peaceful kitchen atmosphere

## Ceramic grinders

The high-tech grinders of this coffee machine beat the competition's steel grinders on many levels: always perfectly Italian taste because of consistently accurate grinding without overheating, supreme longevity, super-silent operation.

## Pre-brewing system

Pre-brewing for even more enjoyment. Thanks to the Pre-brewing Technology, the coffee grounds are moistened before the actual brewing process – ensuring that the aroma can unfold even better.

## Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.

## Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

# Specifications

## Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

## Multi-Beverage

- Milk Variations: Pannarello: milk frothing

## Technical data

- Voltage: 230 V
- Boiler: Stainless steel
- Power: 1400 W
- Pump Pressure: 15 bar
- Frequency: 50 Hz

## Weight and dimensions

- Coffee bean capacity: 250 g
- Waste container capacity: 8 servings
- Water tank capacity: 1,2 L

## Easy to use

- Cleaning and maintenance: Automatic coffee circuit rinse, Descaling cycle
- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Rapid steam, Removable brewing group, Removable watertank