

Philips LCD TV with Perfect Pixel HD Engine

Full HD 1080p

digital TV

52PFL7704D



Be part of the action

Experience brilliant performance with a breathtaking full HD 1080p, 120Hz display. Combined with a powerful Perfect Pixel HD engine, Perfect Natural Motion and exciting invisible sound, this Flat TV ensures you're always part of the action.

See every detail of the action

- 120Hz Clear LCD, 2ms performance for superb motion sharpness
- Full HD LCD display, with a 1920x1080p resolution
- Perfect Natural Motion for ultra smooth Full HD movies
- · Perfect Pixel HD Engine for unrivalled sharpness and clarity
- Dynamic contrast 55000:1 for incredible rich black details

Hear exciting and powerful sound

- Dolby Digital output for connection to a home theatre system
- Invisible speakers with incredible surround

Easy to connect and enjoy

- 4 HDMI inputs with Easylink for a full HD connection
- USB for fantastic multimedia playback
- Settings assistant for effortless personalized TV settings

Ready for digital

• ATSC & QAM tuner receives over the air and unscrambled cable



Highlights

Perfect Pixel HD Engine

Experience unrivalled sharpness and clarity with Perfect Pixel HD Engine. Each pixel of the picture is enhanced to better match the surrounding pixels, resulting in a more natural picture. The result is a unique combination of sharpness, natural detail, vivid colors superior contrast and smooth natural motion whatever you are watching. Clean and razor sharp images result from artifact and noise detection and reduction in all content sources - from multimedia to standard TV.

Full HD LCD display 1920x1080p

The Full HD screen has the widescreen resolution of $1920 \times 1080p$. This is the highest resolution of HD sources for the best possible picture quality. It is fully future proof as it supports 1080p signals from all sources, including the most recent like Blu-ray and advanced HD game consoles. The signal processing is extensively upgraded to support this much higher signal quality and resolution. It produces brilliant flicker-free progressive scan pictures with superb brightness and colors.

Perfect Natural Motion

Enjoy the action without any judder. Perfect Natural Motion estimates motion in the picture and corrects juddering movements in both broadcast and pre-recorded movie material (including 1080p movies and 24p True Cinema on Blu-ray and DVD). The result is even smoother and quieter pictures with excellent sharpness. Enjoy motion performance that surpasses cinema quality!

120Hz Clear LCD (2ms)

120Hz Clear LCD creates extreme motion sharpness for clear and vibrant images even with fast on-screen motion. The Double Frame Rate Insertion works with a high 120Hz refresh rate. It increases the sharpness of motion reproduction to more than twice that of conventional LCD, resulting in a response time of 2 milliseconds (measured in Perceived Blur-Edge-Width; BEW). This unique Philips technology brings motion sharpness of LCD displays to an unprecedented level.

USB (multimedia)

The USB connector allows access to jpeg photos, mp3 music and video files of most

USB-sticks (USB memory-class device). Plug the USB into the slot at the side of the TV and access the multimedia content using the easy on screen content browser. You can now view and share your videos, photos and music.

4 HDMI inputs with EasyLink

EasyLink uses the HDMI CEC industry standard protocol to share functionality between connected devices and the TV. With Easylink only one remote control is needed to operate main functionalities on your TV and connected devices. HDMI makes an uncompressed digital RGB connection from the source to the screen for the ultimate picture quality. HDMI uses HDCP copy protection. With 3 HDMI inputs on the back and 1 HDMI on the side of the TV you can connect multiple HD sources, for instance an HD settop box, a Blu-ray player, and Game Console or Digital Camcorder.

Dolby Digital output

Dolby Digital output for connection to a home theatre system

















Included accessories: Tabletop swivel stand, Power

cord, Quick start guide, User Manual, Registration

Accessories

card, Remote Control

Specifications

Picture/Display

- Aspect ratio: Widescreen
- Brightness: 500 cd/m²
- Dynamic screen contrast: 55000:1
- Response time (typical): 2 ms
 Viewing angle: 170° (H) / 170° (V)
- Diagonal screen size: 52 inch / 132 cm
- · Visible screen diagonal (inch): 52.04 inch
- Panel resolution: 1920x1080p
- Picture enhancement: Perfect Pixel HD Engine, Perfect Natural Motion, 3/2 - 2/2 motion pull down, 3D Combfilter, Active Control + Light sensor, Dynamic contrast enhancement, Progressive scan, 120Hz LCD

Supported Display Resolution

Computer formats

Resolution	Refresh rate
640×480	60Hz
800×600	60Hz
1024×768	60Hz
1280×768	60Hz
1280 x 1024	60Hz
1360×768	60Hz
1920 x 1080	60Hz

Video formats

Resolution	Refresh rat
480i	60Hz
480p	60Hz
720p	60Hz
1080i	60Hz
1080 _P	60Hz

Sound

- · Equalizer: 5-bands
- Output power (RMS): 20W
- Sound Enhancement: Incredible Surround
- Sound System: Dolby Digital (AC-3), Stereo, SAP

Loudspeakers

· Built-in speakers: 2

Convenience

- Child Protection: Child Lock+Parental Control
- Clock: On main display, Sleep Timer
- · Ease of Installation: Autostore
- Ease of Use: 4 favorite lists, Auto Volume Leveller (AVL), Channel list, Settings assistant Wizard, Side Control

- Remote Control: TV
- Screen Format Adjustments: 4:3, Auto Format, Movie expand 14:9, Movie expand 16:9, Super Zoom, Widescreen, unscaled (1080p dot by dot)

Multimedia Applications

- Multimedia connections: USB memory class device
- Playback Formats: MP3, JPEG Still pictures, DivX 3.11, DivX 5, MPEG2, XviD, H.264/MPEG-4 AVC

Tuner/Reception/Transmission

- Aerial Input: 75 ohm F-type
- TV system: ATSC, NTSC
- Video Playback: NTSC
- · Cable: Unscrambled Digital Cable -QAM
- Tuner bands: Hyperband, S-Channel, UHF, VHF

Connectivity

- AV 1: Audio L/R in, YPbPr
- AV 2: Audio L/R in, YPbPr
- AV 3: Audio L/R in, CVBS in, S-Video in
- Front / Side connections: HDMI v1.3, S-video in, CVBS in, Audio L/R in, Headphone Out, USB
- · Audio Output Digital: Coaxial (cinch)
- HDMI 1: HDMI v1.3
- HDMI 2: HDMI v1.3
- HDMI 3: HDMI v1.3, Analog audio L/R in
- · EasyLink (HDMI-CEC): One touch play, Power status, System info (menu language), Remote control pass-through, System audio control, System standby

- Ambient temperature: 0°C to 35°C (32°F to 95°F)
- Mains power: 110-240V, 50-60Hz
- Power consumption: 350 W
- Standby power consumption: < 0.15 W

Dimensions

- Set dimensions in inch (W \times H \times D): 51.26 x 31.40 x 4.55 inch
- Set dimensions with stand in inch (W x H x D): $51.26 \times 34.17 \times 12.80$ inch
- Weight incl. Packaging (lb): 116.84
- Product weight (lb): 83.78
- Product weight (+stand) (lb): 95.9 lb
- Box dimensions in inch (W x H x D): $55.71 \times 37.56 \times 15.79$ inch
- VESA wall mount compatible: 400 x 400 mm





Issue date 2012-01-20

© 2012 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 2.8.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 47475 UPC: 6 09585 16277 8

www.philips.com