

flat HI Pixel H	9000 series DTV with Perfect HD Engine and ight 2 channel
• 119 cr • LCD • integr	n (47") ated digital

-

47PFL9732D



Turn up your viewing experience

with Perfect Pixel HD and Ambilight

Enjoy the ultimate viewing experience of this Philips Flat TV with Perfect Pixel HD Engine, 120Hz Clear LCD, Ambilight 2 Channel and Full HD 1080p display. Enjoy your multimedia content with the built in USB.

Immersive viewing experience

- Full HD LCD display, 1920x1080p
- Enjoy HDTV that's truer than anything you've seen before
- Perfect Pixel HD Engine for unrivalled sharpness and clarity
- 120Hz Clear LCD for extreme motion sharpness

Be an eyewitness

• 2-channel active Ambilight enhances the viewing experience

Perfect picture quality from your digital photos

• USB Connector for easy, instant multimedia playing

For advanced performance

• 3 HDMI inputs for full digital HD connection in one cable

PHILIPS

Highlights

Full HD LCD display 1920x1080p

This display has a resolution that is referred to as Full HD. The state-of-the-art LCD screen technology has the full high-definition widescreen resolution of 1080 progressive lines, each with 1920 pixels. This allows the best possible picture quality for HD input signals with up to 1080 lines. It produces brilliant flicker-free progressive scan pictures with optimum brightness and superb colors. This vibrant and sharp image will provide you with an enhanced viewing experience.

HDTV

HDTV delivers exceptional picture quality and real movie-viewing experience that makes television more dynamic, truer than anything you've seen before. It is the latest and best television signal available. It features picture quality more than twice that of traditional analog broadcasts. In order to effectively maximize the HDTV signal, a television must incorporate advanced signal input connectivity and circuitry design.

Perfect Pixel HD Engine

Experience unrivalled sharpness and clarity with Perfect Pixel HD Engine. Each pixel of the picture is enhanced to better match the surrounding pixels, resulting in a more natural picture. The result is a unique combination of sharpness, natural detail, vivid colors superior contrast and smooth natural motion whatever you are watching. Clean and razor sharp images result from artifact and noise detection and reduction in all content sources - from multimedia to standard TV.

120Hz Clear LCD

120Hz Clear LCD creates extreme motion sharpness for clear and vibrant images even with fast on-screen motion. The Double Frame Rate Insertion works with a high 120Hz refresh rate. It increases the sharpness of motion reproduction to more than twice that of conventional LCD, resulting in a response time of 3 milliseconds (measured in Perceived Blurr-Edge-Width; BEW). This unique Philips technology brings motion sharpness of LCD displays to an unprecedented level.

Ambilight 2 channel

Ambilight makes an impressive contribution to the overall viewing experience by producing ambient light to complement the colors and light intensity of the on-screen image. It adds a new dimension to the viewing experience, completely immersing you into the content you are watching. It creates ambiance, stimulates more relaxed viewing, and improves perceived picture detail, contrast and color. Ambilight automatically and independently adapts its colors according to the changing content on the screen.

USB Multimedia Connector

The USB connector allows access to multimedia jpg, mp3 and alb files of most USBsticks and most digital cameras (USB 1.1 memory-class device). Plug the USB into the slot at the side of the TV and access your photos or music files. This makes you easily viewing and sharing your photos and music.

3 HDMI inputs

HDMI makes an uncompressed digital RGB connection from the source to the screen. By eliminating conversion to an analog signal, it delivers an unblemished image. The nondegraded signal reduces flicker and leads to a clearer picture. HDMI intelligently communicates the highest output resolution with the source device. The HDMI input is fully backward compatible with DVI sources but includes digital audio. HDMI uses HDCP copy protection. With 3 HDMI inputs you can connect multiple HD sources, for instance an HD settop box, and a Blu-ray player. Your TV is fully prepared for the HD future.











Specifications

Picture/Display

- · Color cabinet: High Gloss Black
- Aspect ratio: Widescreen
- Brightness: 500 cd/m²
- Dynamic screen contrast: 8000:1
- Response time (typical): 4 (BEW equiv.) ms
- Viewing angle: 176° (H) / 176° (V)
- · Diagonal screen size (inch): 47 inch Display screen type: LCD Full HD W-UXGA Act. matrix
- Panel resolution: 1920x1080p
- Color processing: 4 trillion colors (14bit RGB)
- · Picture enhancement: Perfect Pixel HD Engine, Dynamic contrast enhancement, 1080p 50/60Hz processing, 1080p 24/25/30Hz processing, 3/2 - 2/ 2 motion pull down, 3D Combfilter, Active Control + Light sensor, Jagged Line Suppression, Progressive scan, Widescreen Plus, 120Hz Clear LCD, Double frame rate
- · Screen enhancement: Anti-Reflection coated screen

Ambilight

- · Ambilight Features: Ambilight 2 Channel, Auto adaptive to video content
- · Ambilight light system: LED wide color
- Color Settings: Full Multi Color
- Dimming Function: Manual and via Light Sensor
- Preset modes: 4 Active Adaptive modes

Supported Display Resolution

 Computer formats 		
Resolution	Refresh rate	
640 x 480	60Hz	
800 x 600	60Hz	
1024 x 768	60Hz	
1280 x 768	60Hz	
1360 x 768	60Hz	
1920 x 1080i	60Hz	
1920 x 1080p	60Hz	
 Video formats 		
Resolution	Refresh rate	
480i	60Hz	
480p	60Hz	
576i	50Hz	
576p	50Hz	
720p	50, 60Hz	
1080i	50, 60Hz	

1080p Sound

1080_D

- Output power (RMS): 2x8W
- Sound Enhancement: Digital Signal Processing, Graphic Equaliser, Dynamic Bass Enhancement
- Sound System: Virtual Dolby Digital, BBE

Loudspeakers

- Built-in speakers: 4
- Loudspeaker types: Front Speakers, Dome tweeter

Convenience

- Child Protection: Child Lock+Parental Control
- Clock: Smart Clock
- · Ease of Installation: Auto Program Naming, Automatic Tuning System (ATS), Autostore, PLL Digital Tuning, Plug & Play
- Ease of Use: 4 favorite lists, Auto Volume Leveller (AVL), Channel list, Delta Volume per preset, Graphical User Interface, On Screen Display, Settings assistant Wizard, Side Control, Smart Picture, Smart Sound
- Electronic Program Guide: Now + Next EPG • Remote Control: Amp, DVD, STB (Set-Top Box),
- VCR, Multi-functional
- Remote control type: RC4451
- Screen Format Adjustments: unscaled (1080p dot by dot), 4:3, 6 Widescreen Modes, Auto Format, Full screen, Movie expand 14:9, Movie expand 16:9, Super Zoom
- Teletext: Closed Captioning Full Text
- Firmware upgradeable: Firmware auto upgrade wizard, Firmware upgradeable via USB
- Multimedia: Digital media reader (browser), USB autobreak-in

Multimedia Applications

- Multimedia connections: USB
- Playback Formats: MP3, Slideshow files (.alb), JPEG Still pictures

Tuner/Reception/Transmission

- Aerial Input: 75 ohm F-type
- TV system: ATSC, NTSC
- Video Playback: NTSC
- Cable: Unscrambled Digital Cable QAM




- AV 1: (1, 2, 3Fh autoranging), Audio L/R in, CVBS in, S-Video, YPbPr
- AV 2: Audio L/R in, CVBS
- AV 3: (1, 2, 3Fh autoranging), Audio L/R in, YPbPr
- AV 4: HDMI, Audio L/R in
- AV 5: HDMI
- · AV 6: HDMI
- Front / Side connections: Audio L/R in, CVBS in, Headphone Out, S-video in, USB
- Other connections: Monitor out L/R (Cinch), S/ PDIF in (coaxial), S/PDIF out (coaxial)

Power

- Ambient temperature: 5 °C to 35 °C
- Mains power: AC 110 +/- 10%
- Power consumption: 310 W
- Standby power consumption: 0.60 W (tbc)
- Accessories
 - · Included accessories: Tabletop swivel stand

Dimensions

- Set dimensions in inch (W x H x D): 45.6 x 29.6 x 4.6 inch
- Set dimensions with stand in inch (H x D): 32.3 x 12.0 inch
- Product weight (lb): 70.5 lb
- Product weight (+stand) (lb): 90.4 lb
- Box dimensions in inch (W x H x D): 49.2 x 32.9 x 10.9 inch
- Weight incl. Packaging (lb): 107.6 lb
- VESA wall mount compatible: 600 x 400 mm





Issue date 2013-06-22

© 2013 Koninklijke Philips N.V. All Rights reserved.

www.philips.com

Version: 3.0.15

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 25104 UPC: 6 09585 12153 9

24, 25, 30Hz 24, 50, 60Hz PFL9732D/37