

Philips  
Blu-ray Disc player

BDP5320



## Play your Blu-ray Discs

with high definition picture and superior sound

Enjoy the thrill of full high definition pictures delivered by the BDP5320. Indulge in every detail, silky smooth action and vivid colors with Deep Color. Current DVD favorites can also be enjoyed, with upconversion to 1080p via HDMI.

### See more

- Blu-ray Disc playback for sharp images in full HD 1080p
- Full HD 1080p for razor sharp images
- CinemaNow, over 1500 titles at your fingertips
- Now play BLOCKBUSTER movies direct on your TV
- Netflix-Streaming TV Episodes and Movies over the Internet
- 1080p at 24 fps for cinema-like images

### Hear more

- Dolby TrueHD for high fidelity 7.1 surround sound

### Engage more

- Online content directly on your TV whenever you like
- EasyLink to control all HDMI CEC devices via a single remote
- BD-Live (Profile 2.0) to enjoy online Blu-ray bonus content
- Ethernet port for convenient software upgrades

# PHILIPS

# Highlights

## Blu-ray Disc playback

Blu-ray Discs have the capacity to carry high definition data, along with pictures in the 1920 x 1080 resolution that defines full high definition images. Scenes come to life as details leap at you, movements smoothen and images turn crystal clear. Blu-ray also delivers uncompressed surround sound - so your audio experience becomes unbelievably real. The high storage capacity of Blu-ray Discs also allow a host of interactive possibilities to be built in. Seamless navigation during playback and other exciting features like pop-up menus bring a whole new dimension to home entertainment.

## Full HD 1080p

Blu-ray Discs have the capacity to carry high definition data, along with pictures in the 1920 x 1080 resolution that defines full high definition images. This can only mean you get

the best possible TV picture quality available today - so prepare to feast your eyes.

## 1080p at 24 fps

Bring true cinema experience into your living room with 24 frames-per-second video. Original films are all recorded at this frame rate, providing an ambience and image texture that is so unique. Philips Blu-ray Disc players are equipped to bring you 24fps directly from Blu-ray Discs - thus giving you sensational cinema-like high definition images that will astound you.-

## EasyLink

EasyLink lets you control multiple devices like DVD players, Blu-ray players, TV's etc. with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled

equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

## BD-Live (Profile 2.0)

BD-Live opens up your world of high definition even further. Receive up-to-date content just by connecting your Blu-ray Disc player to the internet. Exciting new things like exclusive downloadable content, live events, live chats, gaming and on-line shopping all await you. Ride the high definition wave with Blu-ray Disc playback and BD-Live

## Dolby TrueHD

Dolby TrueHD delivers 7.1 channels of the finest sound from your Blu-ray Discs. Audio reproduced is virtually indistinguishable from the studio master, so you hear what the creators intended for you to hear. Dolby TrueHD completes your high definition entertainment experience.



# Specifications

## Picture/Display

- D/A converter: 12 bit / 150MHz
- Picture enhancement: Progressive scan, Video upscaling, High Def (720p, 1080i, 1080p), Noise Reduction
- Aspect ratio: 16:9, 4:3

## Sound

- D/A converter: 24 bit, 192 kHz
- Dynamic Range (1kHz): 100 dB
- Frequency response: (20kHz)  $\pm 0.5$ dB (Max./Min. 2ch, DVD) Hz
- Signal to noise ratio: 120 dB
- Sound System: DTS, Dolby Digital Plus, Dolby True HD

## Video Playback

- Playback Media: CD-R/CD-RW, DVD-Video, DVD-R/-RW, CD, DivX, DVD, BD Video, BD-R/RE 2.0, BD-ROM
- Compression formats: MPEG2, H.264, VC-1, DivX 6.0
- Video disc playback system: NTSC
- Disc Playback Modes: Angle, Disc Menu, Pause, Repeat, Resume Playback from Stop, Skip, Search forward/reverse, Slow Forward, Standard Play
- DVD Region.: 1
- Picture Quality Enhancements: Video upscaling
- Video Enhancement: Progressive Scan, Video Upscaling

## Audio Playback

- Playback Media: MP3-CD, CD-R/RW, CD, MP3-DVD
- Compression format: MP3, PCM, Dolby Digital, DTS
- Multichannel decoding: Dolby Digital

## Still Picture Playback

- Playback Media: CD-R/RW, DVD-R/-RW
- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow, Rotate, Zoom, High Definition Resolution

## Multimedia Applications

- Playback Formats: JPEG Still pictures, MP3

## Connectivity

- Rear Connections: Analog audio Left/Right out, Analog audio Multi-channel out, Component Video output, Composite video (CVBS) output, Digital coaxial out, HDMI output, Ethernet

## Convenience

- Child Protection: Parental Control
- OSD Languages: English, French, Spanish

## Accessories

- Included accessories: Audio Cable, Quick start guide, IFU / User Manual, Product Registration Card, Remote Control, 2 x AAA Batteries, USB Wireless LAN adaptor
- User Manual: English, French, Spanish

## Power

- Power supply: 120V, 60Hz
- Power consumption: 29 W
- Standby power consumption: 0.8W

## Dimensions

- Set dimensions (W x H x D): 435 x 50 x 215 mm
- Packaging dimensions (W x H x D): 543 x 153 x 343 mm
- Weight incl. Packaging: 3.4 kg
- Set weight: 2.3 kg



Issue date 2019-03-05

Version: 6.2.2

12 NC: 8670 000 60553  
UPC: 6 09585 18632 3

© 2019 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)