

# PHILIPS

Smart lever door  
lock

6000 series

Slim body design

IP65-certified

C-grade lock cylinder

DDL608LKKSW

 Product Picture

## 43mm\* minimalist body

Suitable for narrow frame doors

Enjoy the safety and convenience brought by DDL608-5HWS! The 43mm minimalist body design allows it to fit narrow frame doors, such as aluminum alloy doors, bridge-cut-off doors, sliding doors, push-pull doors, framed doors, etc.

### **Craftsmanship ensures high quality**

- Fit for multiple narrow frame doors
- Ready for preventing dust and water

### **Smart life "locked" with excellence**

- Say goodbye to the key-only era

### **Secure protection, smart embedded**

- Instantly push notifications to the App
- Instantly protect home security at all times

# Highlights

## Slim lock body design

Designed with a 43mm narrow lock body, DDL608-5HWS can be installed on doors with a thickness of 35-120mm \*, such as aluminum alloy doors, bridge-cut-off doors, sliding doors, push-pull doors, framed doors, etc. It is suitable for a variety of scenarios.

## IP65-certified

DDL608-5HWS has passed the IP65 dustproof and waterproof test, effectively preventing dust and low-pressure water from damaging the door lock, which helps stabilize the product performance and extend the product life span.

## Various ways of unlocking

Fingerprints, PIN codes, key tags, and mechanical keys are available unlocking methods, which can meet the need of different users, perfect for the whole family.

## Duress access methods to unlock

When encountering an abnormal condition, you can use the preset duress access methods (fingerprint, PIN code, and key tag available) to unlock. Then the lock will push the duress alarm information to the user and the user sharing the device in real-time, and the mobile App will synchronize the pop-up alarm to give security warning to help reduce the hidden danger of home security.

## Multiple alerting

Featured with multiple alerts such as anti-dismantling, system locking, and low battery level, Philips DDL608-5HWS instantly safeguards your family and reminds you of the lock status, making you feel assured and secure.

# Specifications

## Access Solution

Fingerprint  
Password/PIN Code  
Temporary PIN code  
Card/Key Tag  
Mechanical Key

## Design & Appearance

Handle: Lever handle  
Color: Silver  
Main Material: Aluminium alloy

## Easy Operation

Voice Guide: Human voice guide

## Installation

Door Opening Direction: Left inward opening, Left outward opening, Right inward opening, Right outward opening  
Door Thickness: 35-60mm, 45-70 mm, 55-80 mm, Other range\*

## Power Specification

Battery Type: Alkaline Batteries  
Power Supply: 4 AAA batteries  
Emergency Power Supply: 5V power bank  
Time of Use: 10 months\*

## Smart Lock Functions

Mortise: C grade lock cylinder



\* 43mm: data from actual measured size, and the tolerance should be less than  $\pm 2$ mm.  
\* 35-120mm: the attached installation kit is suitable for thickness of 35-60mm doors; if the door thickness is 60-120mm, please consult the Philips smart lock authorized consumer care centers or designated offline dealers.  
\* May be less depending on the actual usage.  
\* The effect of the digital keypad showed in the photos of this product may be inconsistent with the actual display effect. Please be subject to the digital keypad displaying status under the actual usage scenarios.