



Philips Welcome Eye View  
Home security connected  
camera

Auto-tracking and motorized

2k image quality  
Embedded siren  
Back-up battery



DES8500OSC

## Home security outdoor motorized camera

### Use with WelcomeEye app

Choose Philips WelcomeEye View to protect the outside of your home. This connected, motorised outdoor camera offers an innovative combination of features. Monitor the situation at home with your smartphone.

#### Made for your security

- Made for your security
- Wide field of view
- 2K image quality
- Works with the Welcome Eye app

#### Unique combination of features

- Embedded siren
- Back-up Battery
- Triple connectivity, IP66, memory card included

#### Connected camera

- Connected home security camera
- Compatible with voice assistants

#### Eco-friendly product

- Eco-friendly product and packaging



# PHILIPS

# Highlights

## Designed for your security

Thanks to Philips WelcomeEye View motion detection and human detection, you can detect and track a moving intruder. You receive a notification on your phone, and you can follow the video from your smartphone, while the camera motor moves on its own. You will also be able to view a full recording, stored in the camera memory card.

## Connected home security camera

At home or far away from home, from your camera's Philips app, receive a notification when a motion is detected. Wherever you are, live or recorded: View and listen to events Trigger the siren Control the motor to move the camera Playback videos made in your absence

## Other informations

Easy connection thanks to the compatibility with 2,4 and 5 GHz wifi and bluetooth. The camera's materials allow it to withstand harsh weather conditions without specific precautions. IP66 certified against dust and rain. 32G SD card included to record pictures and videos.

## Connected home security camera

Philips Welcome Eye View works with Google and Alexa. You can ask your smart speaker to display the live image and sound on its screen (Amazon Echo Show, Google Nest Hub, Google Chromecast...). If you have connected a 230Vac light on your camera on the corresponding terminals, you can also ask your smart speaker to switch it on or off.

## Embedded siren

The Philips Welcome Eye View has an embedded siren of 105 dBa. It can be launched automatically or manually from the app if you see a movement. The sound power is a total deterrent and allows you to discourage the intruder BEFORE he breaks in your home.

## Back-up Battery

In the event of an accidental or deliberate power cut, the camera's built-in battery backup guarantees 4 hours of autonomy. Your camera continues to function even if it has been damaged by intruders or a power failure.

## Designed for your security

Philips guarantees a smooth image on your smartphone when viewing a recording or live video. The camera offers a 2K image resolution which allows you to zoom in clearly. You can also enjoy night vision thanks to the presence of infrared LEDs. You can control access to your home day and night.

## Designed for your security

The motorised camera moves on a 110 degree horizontal axis. In addition to this range, the wide field of view of 130 degrees offers a protection without any blind spot. Thanks to the motor and the autotracking feature, the camera follows the action.

## Eco-friendly product

Philips WelcomeEye View is an environmentally friendly camera. It is made of 100% recycled aluminium and 70% recycled plastic. Its packaging is made with recycled materials and is 100% recyclable : cardboard handle, wedging of cardboard and paper products, screw packaging in cardboard.

## Works with the Welcome Eye app

If you also own a Philips Welcome Eye Connect 2 videophone, thanks to the app a combination of the videophone and the camera is possible. When at work : A delivery man rings my Philips connected video phone to drop off my package. My office phone alerts me to his arrival. I can remotely see who is in the picture, communicate with the driver and open the gate for him to drop the package off at my front door. My camera takes over. I can check that the deliveryman arrives at the door, drops the parcel and leaves. I can, still remotely, close my gate.

# Specifications

## Marketing specifications

- Expected Benefits: Piece of mind surveillance

## Product description

- Product highlight: Connected home security camera
- Designation: DES8500OSC/10
- Color: Silver and black
- Certification: CE
- Sensor resolution: 2K 1920x1080px
- Network connection: 2,4GHz + 5GHz + Bluetooth
- Power: 100 to 240Vac 50Hz input W
- Materials: Aluminum alloy + plastic
- Recyclability: Aluminum 100%, plastic 70%
- Waterproof level: IP66
- Power back-up: Integrated Li-ion battery

## Performance

- Microphone
- Speaker
- Alarm: yes, 105dBa @1m
- Image quality: 2K 2560 x 1440 px
- Night vision: Infrared leds, 20m range
- Motor: 110° horizontal axis
- Event detection: Motion and/or human detection
- Record: yes, on included 32GB Sdcard
- Lens angle: 130°
- Autotracking: Yes, human shape
- External light connection&ctrl: Yes, 100 to 230Vac 5A max
- Compatibility: Android iOS GoogleHome Alexa
- Smartphone app: Philips WelcomeEye
- Battery autonomy: up to 4h

## Accessories in the box

- Screws and anchors: 4 PCS
- Unlocking tool: 1 PC

## Weight and dimensions

- Product dimensions (LxWxH)(mm): 160x60x135mm
- Product weight (g): 800g
- Box dimensions (LxWxH)(mm): 220x115x205mm
- Box weight (g): 1000g

## Logistic data

- Reference (Order entry): 531050
- Quantity in box: 1
- EAN1 (Europe): 3345115310505



Issue date 2023-07-20

Version: 2.0.1

12 NC: 8670 001 87918  
EAN: 33 45115 31050 5

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)