



Philips  
DVD/VCR Player

Direct Dubbing

Progressive Scan

DVP3345V

## DVD and VHS Combo

The ultimate all-in-one player that plays your movie collections in DVDs & VHS tapes. This combination is the only player that maximizes convenience and enhances your movie experience. One player plays it all.

### Play all your movies and music

- Plays MP3 and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL, VHS

### Bring audio and video to life

- Hi-Fi stereo VHS enhances audio playback
- Progressive Scan component video for optimized image quality

### Easy to set up and use

- Direct Dubbing for easy transfer of videos from DVD to VCR

**PHILIPS**  
sense and simplicity

# Specifications

## Picture/Display

- D/A converter: 10 bit / 54MHz
- Picture enhancement: Progressive scan

## Sound

- D/A converter: 24 bit, 192 kHz
- Frequency response: 20 - 20 000 Hz
- Signal to noise ratio: 90
- Dynamic Range (1kHz): >80 dB
- THD: -80dB

## Video Playback

- Playback Media: CD-R/CD-RW, DVD-R/-RW, DVD+R/+RW, DVD-Video, Video CD/SVCD, VHS Tapes
- Compression formats: MPEG1
- Video disc playback system: NTSC
- Number of Video Heads: 4
- Video tape playback system: NTSC

## Audio Playback

- Playback Media: Audio CD, CD-R/RW, DVD-R/-RW, DVD+R/+RW
- Compression format: MP3, WMA, Dolby Digital, PCM
- Number of Audio Heads: 2 Hi-Fi

## Still Picture Playback

- Playback Media: CD-R/RW
- Picture Compression Format: JPEG
- Picture Enhancement: Rotate, Slideshow, Zoom

## Connectivity

- Front / Side connections: Audio L/R in, CVBS in
- Rear Connections: Analog audio Left/Right out, Component Video output, Composite video (CVBS) output, Digital coaxial out, S-Video out, Analog audio Left/Right in, Composite video (CVBS) input

## Convenience

- Programming/Timer Enhancements: Daily/Weekly Repeat Program, One Touch Recording

## Power

- Power supply: 120V, 60Hz
- Power consumption: 21 W
- Standby power consumption: 3.8 W

## Accessories

- Included accessories: 2 x AA Batteries, Audio/Video cable, Quick start guide, Remote Control, User Manual, Warranty Leaflet

## Dimensions

- Set dimensions (W x H x D): 435 x 94 x 233 mm
- Set weight: 2.7 kg
- Packaging dimensions (W x H x D): 539 x 182 x 342 mm
- Weight incl. Packaging: 3.4 kg

## Container Loading

- Container 20 feet: 900
- Container 40 feet: 1800
- Container 40 feet (HC): 2000

# Highlights

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## Hi-Fi stereo VHS

Hi-Fi Stereo VHS plays back true stereo VHS



Issue date 2013-01-26

Version: 1.0.3

12 NC: 8670 000 53186  
UPC: 6 09585 17230 2

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)