



Philips 9000 series  
Full-auto push pull smart  
door lock

**Intuitive push-pull use**  
System wake-up by manual touch  
Auto Locking Function

**DDL192LAGBB**

# Only one step to lock or unlock

Full auto, full smart life

Everything starts here: The convenience brought by one-touch unlock and auto lock;  
Solid security ensured by dual verification and Bluetooth unlock; Sense of sci&tech  
presented by ergonomic design and streamlined body.

## **Easy life doesn't stop there**

- Patented full auto mortise: Unlock and open at one go
- Auto locking: Enjoy the reassurance after you close the door
- Intuitive fingerprinting: Unlock swiftly at one go
- Multiple alarming: Protect home security at all times

## **Multiple protection in one for overall home safety**

- Dual verification unlocking: Security is never forgotten
- C grade lock cylinder: Better reliability and security
- Fake PIN code: Protect your password security in real time
- Outside forced lock: Instant alarm upon inside unlocking
- Safe handle: Eliminates safety risks and keep you reassured

# PHILIPS

# Highlights

## Patented full auto mortise



The upgraded full automatic mortise makes it possible for instant unlocking right after a successful verification. Once you are recognized, you can directly push or pull the handle to open the door, which greatly simplifies the use of your door lock and brings you a fast and convenient in and out experience.

## Auto locking function



The push-pull smart door lock employs full automatic mortise. Without the need for any extra action, the deadbolt will spontaneously pop out after you close the door. If the door is not locked properly, the mortise will give an alarm to remind you of the door lock status.

## Intuitive fingerprinting



The fingerprint sensor is integrated in the push-pull handle so that when you hold the handle, your finger will naturally fall on the sensor. You can simply reach out and

intuitively touch the sensor, then push to open after a successful fingerprint verification. The one-step unlocking feature will definitely bring you a fast and convenient door opening experience.

## Multiple alarming function



Philips 9200 series is featured with all-around alarm functions which not only improves the anti-theft level of your home and safeguard you and your family in real time, but also reminds you of the door lock status to create convenience for use.

## Dual verification unlocking



In dual verification mode, you can use a combination of any two factors (fingerprint, password and card) as the unlocking solution to ensure doubled security for your home.

## C grade lock cylinder



Lock cylinder is the key component that controls the opening of the lock and is

compared to the heart of a lock. C grade lock cylinder employs multiple anti-theft technologies with unique design of the pin tumbler and vane structure, and is able to give high performance on preventing technical lockpicking.

## Fake PIN code



Philips EasyKey comes with the feature of Fake PIN Code technology which allows you to enter random number combinations to successfully get identified as long as there is consecutive input of the real password. This feature can effectively prevent peeping and safeguard your real password.

## One-key outside forced lock



Before leaving home, you can touch the outside forced lock key to enable the function so that opening the door from inside the room will trigger an alarm. This feature can effectively warn you of security risks and upgrade the level of home security.

# Specifications

## Design & Appearance

- Color: Obsidian black
- Handle: Push-pull handle
- Surface Processing: Electroplating
- Fingerprint Sensor: Semiconductor
- Emergency Escape Design: Indoor fast opening mortise
- Ergonomic Design: Push-pull handle design

## Access Solution

- Fingerprint
- Password/PIN Code
- Card/Key Tag
- Mechanical Key
- Bluetooth

## Lock Capacity

- Card/Key Tag: Up to 100
- Master PIN Code: 1
- One-time PIN Code: 1

## Power Specification

- Power Supply: 4 AA batteries
- Battery Type: Alkaline Batteries
- Time of Use: 10 months\*
- Maximum Batteries Capacity: 8 batteries
- Emergency Power Supply: 5V power bank
- Working Voltage: 4.5-6V

## Easy Operation

- Indicator: Door locks status prompt, Low battery prompt, Mute status prompt, Outside forced lock prompt, System locking prompt
- Voice Guide: Human voice guide

## Smart Lock Functions

- Mortise: Full auto mortise
- Locking Function: Electronic deadlock, System locking
- Safety Function: Dual verification, Fake PIN code, Outside forced lock function, Safe handle function
- Alarm Function: Anti-prying alarm, Outside forced lock alarm

## Mode

- Operating Mode: Auto mode, Manual mode
- System Setup Mode: Dual verification mode, Normal mode

## Installation

- Door Thickness: 38-60 mm, 60-90 mm, 90-120 mm, Other range\*
- Door Opening Direction: Left inward opening, Left outward opening, Right inward opening, Right outward opening
- Door Type: Antitheft door, Copper door, Wooden door
- Multi-lock Point: No

## Accessory Parts

- Accessorial Battery: 4 AA alkaline batteries
- Mechanical Key: 2 keys
- Smart Key Tag: 2 cards
- Installation Accessories
- Mortise
- Mounting Plate
- Drilling Template
- Certificate
- Cleaning Pad
- User Manual
- Warranty Card



Issue date 2024-07-08

Version: 2.0.2

EAN: 69 71318 50066 4

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* May be less depending on the actual usage.

\* Please contact our service agents or authorized dealers for other door range.