

Smart rim lock

5000 series

Auto locking

Hidden PIN code

One-time PIN code



DDL151Z00BB



Simple and compact design

Allow easy installation

Simple design, which is also compact and thin, allows easy installation of different types of doors. Automatic locking, etc. provide you with a better smart life.

Smart life locked with excellence

- Say goodbye to the key-only era
- Eliminate the hassle of manually locking

Easy life doesn't stop here

- Convenient for the visitors
- Easy installation in different scenario

Intensive protection for home security

• Protect your password from being peeping

Highlights

Various ways of unlocking



Multiple choices as fingerprint, PIN code, key tag, and app meet different unlocking needs and allow users to enjoy a smart and convenient door opening experience.

Fully auto mortise

Fully auto



Philips 5100-6HBS employs fully automatic mortise. Without the need for any extra action, the deadbolt will spontaneously pop up after closing the door. If the door is not locked properly, the mortise will give an alert

to remind you of the door lock status.

One-time PIN code



When visitors or cleaners come while you are not at home, you can set a one-time password in advance, and it will become

invalid after being used. There is no need to change the master PIN code frequently, which eliminates the hassle of resetting the PIN code(s).

Compact design



The simple and compact design allows easy installation for home, studio, office, etc., which is widely suitable for installation on both inside and outside doors, which could also ensure a private space.

Hidden PIN code



Featured 32-digit hidden PIN code technology, Philips 5100-6HBS allows you to enter any random number combination to get identified and unlock the door as long as there is a consecutive input of the real password. This feature can effectively prevent peeping and safeguard your real password.

Specifications

Access Solution

Card/Key Tag **Fingerprint** Password/PIN Code

Design & Appearance

Color: Champagne gold, Obsidian black Fingerprint Sensor: Semiconductor

Easy Operation

Indicator: Door locks status prompt, Low battery prompt, Mute status prompt, Outside forced lock prompt, System locking prompt Voice Guide: Human voice guide

Installation

Door Opening Direction: Left inward opening, Left outward opening, Right inward opening, Right outward oepning Door Thickness: 30-50 mm, 50-90 mm, Other range*

Door Type: Antitheft door, Copper door,

Wooden door

Lock Capacity

Master PIN Code: 1 One-time PIN Code: 1

Mode

Operationg Mode: Auto mode, Manual mode

Power Specification

Emergency Power Supply: 5V power bank Maximum Batteries Capacity: 4 batteries

© 2022 Koninklijke Philips N.V. All Rights reserved

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2022-11-19

12 NC: 8670 001 77655 EAN: 69 71318 50279 8

www.philips.com



- * May be less depending on the actual usage.
- * The effect of the digital keypad showed in the photos of this product may be inconsistent with the actual display effect. Please be subject to the digital keypad displaying status under the actual usage scenarios.
- * Other door thickness range: If the thickness of the door is out of the mentioned range, please contact our local dealers or consumer care center.