

Philips  
Blu-ray home theater  
system

HTS5506



## Limitless possibilities

3D Playback, certified Wi-Fi, MediaConnect.

Enjoy Blu-ray Home Theater technology. From 3D playback to Wireless access to Video on Demand favorites and social networking. Surf the web, view any content from your PC, and wirelessly share it on your TV with Philips MediaConnect.

### Bring audio and video to life

- Full HD 1080p for razor sharp images
- 1080p at 24 fps for cinema-like images
- BD-Live (Profile 2.0) to enjoy online Blu-ray bonus content
- Full HD 3D for a truly immersive 3D movie playback

### Connect and enjoy all your entertainment

- Wirelessly connect to the internet right out of the box
- NetTV with Wireless access to online services on your TV

### Play all your movies and music

- Netflix-Streaming TV Episodes and Movies over the Internet

# PHILIPS

# Highlights

## 3D



Be enthralled by 3D movies in your own living room on a Full HD 3D TV. Active 3D uses the latest generation of fast switching displays for real life depth and realism in full 1080x1920 HD resolution. By watching these images through special glasses that are timed to open and close the left and right lenses in synchronization with the alternating images, the Full HD 3D viewing experience is created. Premium 3D movie releases on Blu-ray offer a wide and high quality content selection.

## NetTV



Experience a rich selection of online services with Net TV wirelessly. Enjoy movies, pictures, infotainment and other online content directly on your TV whenever you like. Wirelessly navigate and select what you want to watch with the TV remote control. The Philips menu gives

you access to popular Net TV services fitted for your TV screen.

## Online Premium video on Demand

Enjoy Premium movies wirelessly to your TV from Vudu and Netflix. From the greatest romantic classics to fast action movies, it's all there at a push of a button from the comfort of your sofa. Free yourselves from fixed program timeslots, and watch what you like, when you like.

## Full HD 1080p



Blu-ray Discs have the capacity to carry high definition data, along with pictures in the 1920 x 1080 resolution that defines full high definition images. This can only mean you get the best possible TV picture quality available today - so prepare to feast your eyes.

## BD-Live (Profile 2.0)



BD-Live opens up your world of high definition even further. Receive up-to-date content just by connecting your Blu-ray Disc player to the internet. Exciting new things like exclusive downloadable content, live events, live chats, gaming and on-line shopping all await you. Ride the high definition wave with Blu-ray Disc playback and BD-Live

## 1080p at 24 fps



Bring true cinema experience into your living room with 24 frames-per-second video. Original films are all recorded at this frame rate, providing an ambience and image texture that is so unique. Philips Blu-ray Disc players are equipped to bring you 24fps directly from Blu-ray Discs - thus giving you sensational cinema-like high definition images that will astound you.-



# Specifications

## Picture/Display

- Aspect ratio: 16:9, 4:3
- Picture enhancement: High Def (720p, 1080i, 1080p), Progressive scan

## Sound

- Sound enhancement: Dolby Digital, Dolby Digital Plus, Dolby Pro Logic II, Dolby TrueHD, DTS, DTS-HD High Resolution Audio, DTS-HD Master Audio, Multi channel LPCM Output
- Total Power (RMS): 1000 W
- Sound effect: Audio Sync, Equalizer Settings

## Loudspeakers

- Center freq range: 160-20000 Hz
- Satellite speaker impedance: 4 ohm
- Satellite speaker drivers: 3" full range woofer
- Subwoofer type: Passive
- Subwoofer driver: 6.5" high efficiency woofer
- Subwoofer freq range: 50-150 Hz
- Subwoofer impedance: 4 ohm

## Connectivity

- Front / Side connections: USB
- Rear Connections: HDMI output, Composite video (CVBS) output, FM Antenna, Easy-Fit Speaker Connectors, Digital coaxial in, Aux in x2, Ethernet

## Power

- Power supply: 120V, 60Hz

## Dimensions

- Set Height: 59 mm
- Set Width: 435 mm
- Set Depth: 281 mm
- Packaging Depth: 370 mm
- Weight incl. Packaging: 12.75 kg
- Packaging Height: 452 mm
- Packaging Width: 512 mm
- Set weight (with stand): 3.7 kg

## Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, Product Registration Card, Quick start guide, User Manual, CVBS video cable

## Video Playback

- Playback Media: BD 3D, BD, DVD, USB
- Compression formats: BD-Video, DVD-Video, AVCHD
- Video disc playback system: NTSC

## Audio Playback

- Compression format: MP3, WMA, DTS
- Playback Media: BD, CD, DVD, USB

## Still Picture Playback

- Picture Compression Format: JPEG
- Playback Media: BD, CD, DVD, Kodak Picture CD, USB
- Picture Enhancement: Rotate



Issue date 2024-08-10

Version: 3.3.2

UPC: 6 09585 21056 1

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* In order to enjoy viewing 3D content, the following is required: a Blu-Ray 3D compatible television with a 3D emitter; a pair of television compliant 3D glasses; a HDMI cable connection; and a Blu-Ray Disc with 3D content.

\* In order to enjoy Internet services and content on your television, broadband internet service is required Internet services and content, picture quality and picture size may vary depending on your broadband speed. For best results, your broadband speed should be at least 2.5 Mbps for SD content

\* Internet content displayed on your television is made available by Third Party Providers who reserve the right to change and/or terminate such content at any time with or without notice. Additional fees and/or PC registration may be required in order to receive Premium content.