

Philips SoundBar  
Home theater

300W RMS power

HSB2313A



## Complete your HD TV experience

with a powerful subwoofer

Bring your movies and games to life with great surround sound. With 300w of sound power, Integrated HDMI hub and subwoofer, you can now enjoy them in high quality sound and picture, without the clutter!

### Great listening experience

- Dolby Virtual Speaker for realistic surround sound
- Subwoofer for powerful bass

### HD cinematic viewing experience

- Integrated HDMI Hub connects devices to the TV conveniently

### Connect and enjoy all your entertainment

- 300W RMS total output power
- EasyLink to control all HDMI CEC devices via a single remote
- MP3 Link plays music from portable media players
- USB Link plays photos and music from USB flash drives

### Designed to enhance your living space

- Flexible placement on the wall or tabletop
- SoundBar design with optimal fit for 32" flat TV or larger

**PHILIPS**  
sense and simplicity

# Specifications

## Accessories

- Included accessories: Remote Control, User Manual, Wall mounting bracket, Batteries for remote control, Power cord, Quick start guide

## Audio Playback

- Playback Media: USB flash drive
- MP3 bit rates: 32-256 kbps and VBR

## Connectivity

- Front / Side connections: Audio L/R in, CVBS in, USB, MP3 Line-in
- Rear Connections: Composite video (CVBS) output, Digital coaxial in 2x, Analog audio Left/Right in 2x, Component Video output, Composite video (CVBS) input, HDMI V1.3 in 2x, HDMI V1.3 output
- AV 1: Audio L/R in, CVBS in
- AV 2: Audio L/R in, CVBS in
- Subwoofer (Power Box): Interconnect (to Main Unit)

## Dimensions

- Set dimensions with stand (H x D): 91.5 x 104 mm
- Set Width: 800 mm
- Subwoofer dimensions (W x H x D): 180 x 330 x 340 mm

## Loudspeakers

- Subwoofer type: Active
- Speaker impedance: 6ohm
- Subwoofer driver: 1 x 6.5" Long Throw woofer
- Subwoofer freq range: 35-200Hz
- Subwoofer impedance: 3ohm

## Outer Carton

- Gross weight: 9.5 kg
- Outer carton (L x W x H): 39.7 x 37.5 x 35 cm
- Nett weight: 8 kg
- Number of consumer packagings: 1
- Tare weight: 1.5 kg
- Gross weight: 20.944 lb
- Outer carton (L x W x H): 15.6 x 14.8 x 13.8 inch

- Nett weight: 17.637 lb
- Tare weight: 3.307 lb
- UPC: 6 09585 19375 8

## Packaging dimensions

- Packaging dimensions (W x H x D): 39.7 x 37.5 x 35 cm
- Gross weight: 9.5 kg
- Nett weight: 8 kg
- Number of products included: 1
- Packaging type: Carton
- Tare weight: 1.5 kg
- Packaging dimensions (W x H x D): 15.6 x 14.8 x 13.8 inch
- Gross weight: 20.944 lb
- Nett weight: 17.637 lb
- Tare weight: 3.307 lb
- UPC: 6 09585 19375 8
- Type of shelf placement: Laying

## Power

- Power supply: 120V, 60Hz

## Sound

- Output power (RMS): Total 300W RMS
- Sound System: Dolby Prologic II, Dolby Virtual speaker, Dolby Digital, Stereo
- Equalizer settings: Action, Classic, Concert, Drama, Gaming, Jazz, News, Party, Rock, Sports

## Sound Enhancement

- Game mode: Arcade, Racing, Shooting, Sport
- Movie mode: Action, Concert, Drama, Science Fiction

## Product dimensions

- Product dimensions with stand (W x H x D): 36.2 x 8.1 x 9.6 cm
- Product dimensions with stand (W x H x D): 14.3 x 3.2 x 3.8 inch
- Weight (with stand): 0.9 kg
- Weight (with stand): 1.984 lb

# Highlights

## Dolby Virtual Speaker

Dolby Virtual Speaker is a sophisticated audio virtualization technology that produces rich and immersive surround sound from a two-speaker system. Highly advanced spatial algorithms faithfully replicate the sonic characteristics that occur in an ideal 5.1-channel environment. DVD playback is enhanced by expanding the 2-channel environment. When combined with Dolby Pro Logic II processing, any high quality stereo source is transformed into true-to-life, multi-channel surround sound. No need to purchase extra speakers, wires or speaker stands to appreciate room-filling sound.

## EasyLink

EasyLink lets you control multiple devices with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

## USB Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. With USB Link, all you have to do is plug in your USB device, select the photo or music, and play away.

## Integrated HDMI Hub

The HDMI Hub gives you the ease of connecting all your devices to the TV without too many wires. It provides you the convenience of enjoying the best possible sound quality while watching different contents on your flat TV. You can connect all your HDMI devices directly into the home theater system's HDMI hub and using only one cable to connect to your flat TV. With this setup, you can easily enjoy your movies or TV programs in HD picture and sound and not have to deal with messy wires!



Issue date 2011-03-24

Version: 3.0.3

12 NC: 8670 000 66245  
UPC: 6 09585 19375 8

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

www.philips.com