

Philips digital widescreen flat TV with Digital Crystal Clear

94 cm (37")

LCD integrated digital

37PFL5322D



Turn up your viewing experience

with Digital Crystal Clear

Here is a wonderful new TV that not only gives you great picture and sound but also modern styling and quality finish. It features Digital Crystal Clear for natural, vivid images and Dolby Digital sound for superb audio.

Vivid, natural and razor sharp images

- HD LCD WXGA display, with a 1366 x 768p resolution
- Integrated HDTV to receive digital HDTV and cable signals
- Digital Crystal Clear provides vivid cinema-like images
- · Dynamic contrast enhancer delivering rich black details

Unrivalled audio performance

• Dolby Digital for movies or concerts in full surround sound

Slim, stylish design to complement your interior

• Compact and slim design that fits in every room

Designed for your convenience

- · Auto Picture to personalize your viewing
- Auto Sound uses pre-defined sound settings for better sound

For advanced performance

• 2 HDMI inputs for full digital HD connection in one cable



Highlights

LCD WXGA display, 1366 x 768p

This WXGA display with state-of-the-art LCD screen technology gives you widescreen HD resolution of $1366 \times 768p$ pixels. It produces brilliant flicker-free progressive scan pictures with optimum brightness and superb colors. This vibrant and sharp image will provide you with an enhanced viewing experience.

Integrated HDTV Cable Ready

The built-in HDTV tuner that receives and displays terrestrial ATSC and unscrambled cable signals

Digital Crystal Clear

Digital Crystal Clear is a package of picture innovations that digitally adjusts and optimizes picture quality to optimal contrast, color and sharpness levels. It's like watching vivid cinemalike images.

Dynamic contrast enhancer

You want the LCD flat display with the highest contrast and most vibrant images even at wide viewing angle. The Philips dynamic contrast enhancer uses video processing and unique dimming backlight technology. This delivers deep rich black levels with increased detail. The dimming backlight increases the contrast up to 5 times*, and at the same time improves the viewing angle. It gives a bright, lifelike picture with high contrast and vibrant colors, (* factor between 2 and 5, screen type and picture content dependant).

Dolby Digital Surround

Because Dolby Digital and DTS, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.

Compact and slim design

This design style emphasizes a slim, compact look that saves space and fits in anywhere.

Auto Picture

Auto Picture button on the remote control enables one-touch selection of various preset

optimized image settings to suit different TV program.

Auto Sound

Auto Sound provides pre-defined sound settings for ultra bass, bass, treble and balance for the optimum entertainment experience.

2 HDMI inputs

HDMI makes an uncompressed digital RGB connection from the source to the screen. By eliminating conversion to an analog signal, it delivers an unblemished image. The non-degraded signal reduces flicker and leads to a clearer picture. HDMI intelligently communicates the highest output resolution with the source device. The HDMI input is fully backward compatible with DVI sources but includes digital audio. HDMI uses HDCP copy protection. With 2 HDMI inputs you can connect multiple HD sources, for instance an HD settop box, and a Blu-ray player. Your TV is fully prepared for the HD future.

















Specifications

Picture/Display

- · Color cabinet: black, high gloss black strip
- Aspect ratio: 16:9
- Brightness: 500 cd/m²
- Contrast ratio (typical): 1200:1
- Response time (typical): 8 (grey to grey) ms
- Display screen type: LCD WXGA Active Matrix
- Panel resolution: 1366 x 768p
- Picture enhancement: 3/2 2/2 motion pull down, 3D Combfilter, 3D MA deinterlacing, Blue stretch, Black stretch, White stretch, Green enhancement, Progressive scan, Automatic skin tone correction, 2D/3D noise reduction
- Screen enhancement: Anti-Reflection coated screen
- Viewing angle (H / V): 176 / 176 degree

Supported Display Resolution

Computer formats

Resolution	Refresh rate
640×480	60Hz
720×480	60Hz
800×600	60Hz
1024×768	60Hz
1280×768	60Hz

Video formats

Resolution	Refresh rate
480i	60Hz
480p	60Hz
720p	60Hz
1080i	60Hz

- Output power (RMS): 2 speakers @ 10w each
- Sound Enhancement: Incredible Surround
- Sound System: Dolby Digital (AC-3), Mono, Stereo, SAP

Convenience

- Child Protection: Child Lock+Parental Control
- · Clock: Sleep Timer
- Ease of Installation: Autostore, Fine Tuning, PLL Digital Tuning, Plug & Play
- Ease of Use: Auto Volume Leveller (AVL), AutoPicture, AutoSound, On Screen Display,

Closed Captioning Full Text

- Remote control type: RC2023609/01 B
- · Screen Format Adjustments: 4:3, Auto Format, Movie expand 14:9, Movie expand 16:9, Subtitle Zoom, Super Zoom, Widescreen

Tuner/Reception/Transmission

- Aerial Input: 75 ohm F-type
- TV system: ATSC, NTSC
- Video Playback: NTSC
- Cable: Unscrambled Digital Cable -QAM
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- Number of Preset Channels: 125

Connectivity

- AV 1: Audio L/R in, YPbPr
- AV 2: Audio L/R in, YPbPr
- AV 3: Audio L/R in, CVBS in, S-Video in
- Front / Side connections: Audio L/R in, CVBS in, Headphone Out, S-video in
- Other connections: PC Audio in, PC-In VGA, S/ PDIF out (coaxial), HDMI in 2x

Power


- Ambient temperature: 5 °C to 40 °C
 Mains power: 90-240 VAC, 50/60 Hz
- Power consumption: 175 W
- Standby power consumption: < 1 W


Accessories

· Included accessories: Table top stand, Power cord, Quick start guide, User Manual, Registration card, Remote Control, Batteries for remote control

Dimensions

- Set dimensions in inch (W \times H \times D): $36.38 \times 26.37 \times 3.74$ inch
- Set dimensions with stand in inch (W x H x D): $36.38 \times 27.11 \times 11.02$ inch
- Product weight (lb): 50.1
- Product weight (+stand) (lb): 55.1 lb
- Box dimensions in inch (W x H x D): $44.25 \times 26.85 \times 12.91$ inch
- Weight incl. Packaging (lb): 68.2
- VESA wall mount compatible: 400 x 200 mm







Issue date 2012-01-20

© 2012 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 2.2.6

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 32665 UPC: 6 09585 13981 7

www.philips.com