



Philips 9000 series  
widescreen flat TV with  
Pixel Plus and Ambilight

**81 cm (32")**  
LCD

**32PF9966**

## The ultimate viewing experience

with Pixel Plus and Ambilight

The ultimate viewing experience of Ambilight and Pixel Plus pushes Picture Quality to new levels. The unprecedented viewing comfort of Ambilight, LCD technology and Plasma technology culminate in a daring and innovative design.

### **Better quality images that reveal more detail**

- Pixel Plus for detail, depth and clarity
- 3D combfilter separates colors for a razor-sharp image
- Active Control with Light Sensor optimizes picture quality

### **Add a new dimension to your viewing**

- Full-color ambient lighting enhances the viewing experience
- Digital Natural Motion for smooth moving images

### **Impressive sound**

- Virtual Dolby Surround for a cinema-like audio experience

### **Connects to your premium audio/video products**

- HDMI input for full digital HD connection in one cable

**PHILIPS**  
sense and simplicity

# Highlights

## Pixel Plus

Pixel Plus is a digital picture processing technology that increases the number of lines and the number of pixels. The result is razor sharp pictures with incredible detail and depth, every time from any source.

## 3D Combfilter

The 3D comb filter separates brightness and color signals better in 3D domain to eliminate cross-color, cross-luminance and dot-crawl distortion - all of which detract from your viewing pleasure. The 3D digital comb filter performs field-by-field comparisons of the television image to accurately separate the color from the black-and-white information and remove both horizontally and vertically hanging dots, as well as dot crawl. The result is a razor sharp image.

## Active Control + Light Sensor

Active Control is a unique and intelligent way of optimizing picture quality by measuring and analyzing the incoming signal to automatically adjust picture quality settings. Active Control

with Light Sensor uses a sensor to adjust the picture brightness depending on the room light conditions.

## Ambilight

The full-color ambient lights offers you relaxed viewing and a unique ambiance via a soft light glow on the walls surrounding the TV.

Research has shown that watching television with adapted ambient lighting promotes more relaxed TV viewing. the Ambilight colors automatically adapt to the images on the screen to add a new sensation to the viewing experience. The light can also be switched to fixed colors or various shades of white. In standby mode, the lights can be operated to any color and create a unique ambiance in the room.

## Digital Natural Motion

Philips invented Digital Natural Motion to eliminate juddering effects that are visible with moving picture content. Digital Natural Motion estimates motion in the picture and corrects juddering movements in both broadcast and

recorded movie material (such as DVD). The resulting smooth motion reproduction and excellent sharpness take the viewing experience to a higher level.

## Virtual Dolby Surround

Virtual Dolby Surround is a processing technology for enhancing surround sound effects. It will create the sensation of Dolby Pro Logic without the necessity of additional rear speakers. You become totally immersed in your television experience.

## HDMI input

HDMI makes an uncompressed digital RGB connection from the source to the screen. By eliminating conversion to an analog signal, it delivers an unblemished image. The non-degraded signal reduces flicker and leads to a clearer picture. HDMI intelligently communicates the highest output resolution with the source device. The HDMI input is fully backward compatible with DVI sources but includes digital audio. HDMI uses HDCP copy protection.



# Specifications

## Picture/Display

- Aspect ratio: 16:9
- Brightness: 450 cd/m<sup>2</sup>
- Contrast ratio (typical): 800:1
- Color cabinet: Pearl - White Silver (11092)
- Diagonal screen size: 32 inch / 80 cm
- Display screen type: LCD WXGA Active Matrix TFT
- Picture enhancement: Pixel Plus, Digital Crystal Clear, Progressive scan, 3D Combfilter, Active Control + Light sensor, Digital Natural Motion, Jagged Line Suppression, Movie Plus, Widescreen Plus
- Screen enhancement: Anti-Reflection coated screen
- Viewing angle (H / V): 160 / 160 degree
- Panel resolution: 1366 x 768p
- Response time (typical): 12 ms

## Ambilight

- Ambilight Features: Auto adaptive to video content, Full operation in stand-by
- Color Settings: Full Multi Color
- Dimming Function: Manual and via Light Sensor
- Preset modes: 2 Active Adaptive preset modes, 6 Preset modes and user preset

## Supported Display Resolution

### Computer formats

Resolution	Refresh rate
640 x 480	60Hz
800 x 600	60Hz
1024 x 768	60Hz

### Video Formats

Resolution	Refresh rate
640 x 480i	1Fh
640 x 480p	2Fh
720 x 576i	1Fh
720 x 576p	2Fh
1280 x 720p	3Fh
1920 x 1080i	2Fh

## Sound

- Sound Enhancement: Auto Volume Leveller, Digital Signal Processing, Dynamic Bass Enhancement, Graphic Equaliser, Smart Sound
- Sound System: Virtual Dolby Surround
- Output power (RMS): 2x15W

## Loudspeakers

- Built-in speakers: 4
- Loudspeaker types: Dome tweeter, Integrated

woofers with wOOx

## Convenience

- Ease of Installation: Automatic Tuning System (ATS), PLL Digital Tuning, Plug & Play
- Ease of Use: 9-channel smart surf list, Backlighted side controls, Channel list, Delta Volume per preset, Smart Picture, Smart Sound
- Remote control type: RC4307
- Teletext: Closed Captioning Full Text
- Remote Control: Universal
- Remote control: TV, VCR, DVD/R, SAT, CBL, AMP
- Screen Format Adjustments: 6 Widescreen Modes, Auto Format, Subtitle and Heading Shift
- Clock: Smart Clock
- Child Protection: Child Lock+Parental Control
- Picture in Picture: 2 tuner PIP, Mozaic

## Tuner/Reception/Transmission

- TV system: NTSC
- Video Playback: NTSC
- Aerial Input: 75 ohm F-type

## Connectivity

- Other connections: Analog audio Left/Right out, Centre Speaker connection in, Monitor out, CVBS, L/R (cinch), Subwoofer out
- AV 1: (1, 2, 3Fh autoranging), Audio L/R in, Component Video in, Y/C, YPbPr
- AV 2: (1, 2, 3Fh autoranging), Audio L/R in, Component Video in, CVBS, RGB+H/V, Y/C, YPbPr
- AV 3: Audio L/R in, HDCP, HDMI (Digital Stream & S/PDIF)

## Power

- Power consumption: 185 (tbc) W
- Standby power consumption: <2
- Mains power: AC 110-120V (+/-10%)
- Ambient temperature: 5 °C to 40 °C

## Dimensions

- Product weight: 20 kg
- Weight incl. Packaging: 32 kg

## Accessories

- Included accessories: HDMI-DVI adapter cable, Table top stand, Wall mounting bracket



Issue date 2012-01-20

Version: 4.0.5

12 NC: 8670 000 20641  
UPC: 0 37849 94597 1

© 2012 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)