



Philips  
LCD TV with Pixel Plus  
HD

**81cm/32"**

digital TV



**32PFL4505D**

## The green choice

Slim LED LCD Eco TV™

Philips selected for you the best performance and connectivity for the right price, today and tomorrow. This TV delivers Full HD pictures with incredible surround sound experience, which let's you live the moment as if you were there...

### See brilliant picture quality

- LED technology ensures natural color and thin design
- Pixel Plus HD for better details, depth and clarity
- Full HD LCD display, with a 1920x1080p resolution

### Hear crisp and clear sound

- SRS TruSurround HD®
- Dolby Digital output for connection to a home theatre system

### Easy to connect and enjoy

- 3 HDMI inputs with Easylink for HD connection
- PC input (HDMI)
- Enjoy photo and music playback via USB

### Greener every day

- Energy Star rated for low power consumption

# PHILIPS

sense and simplicity

# Highlights

## LED

LED lighting technology is the most advanced available. In this TV it combines an eye-catching minimalistic design with stunning image quality, as well as being the lowest power consumption in its category. Another environmental benefit is that LED lighting technology does not contain hazardous materials. With an LED backlight you can enjoy low power consumption, high brightness, incredible contrast and sharpness and vibrant colors.

## Pixel Plus HD



Pixel Plus HD is a picture processing technology that enables viewers to watch content that is vivid, natural, and real. The result means superbly life-like pictures with incredible details and depth from any HD source.

## Full HD LCD display 1920x1080p



The Full HD screen has the widescreen resolution of 1920 x 1080p. This is the highest resolution of HD sources for the best possible picture quality. It is fully future proof as it supports 1080p signals from all sources, including the most recent like Blu-ray and advanced HD game consoles. The signal processing is extensively upgraded to support this much higher signal quality and resolution. It produces brilliant flicker-free progressive scan pictures with superb brightness and colors.

## SRS TruSurround HD®

SRS TruSurround HD® creates an immersive, feature-rich surround sound experience from two speakers, complete with rich bass, high frequency detail and clear dialog.

## Dolby Digital output

Dolby Digital output for connection to a home theatre system

## 3 HDMI inputs with EasyLink

EasyLink uses the HDMI CEC industry standard protocol to share functionality between connected devices and the TV. With EasyLink only one remote control is needed to operate

main functionalities on your TV and connected devices. HDMI makes an uncompressed digital RGB connection from the source to the screen for the ultimate picture quality. HDMI uses HDCP copy protection. With 2 HDMI input on the back and 1 HDMI on the side of the TV you can connect multiple HD sources, for instance an HD settop box, a Blu-ray player, and Game Console or Digital Camcorder.

## USB for photo & music playback

The USB connector allows access to jpeg photos and mp3 music of most USB-sticks (USB memory-class device). Plug the USB into the slot at the side of the TV and access the multimedia content using the easy on screen content browser. You can now view and share your photos and music.

## PC input (HDMI)

With PC input you can use your TV as a PC monitor via a HDMI-DVI cable/converter.

## Energy Star

Energy Star-labeled home electrical products are designed to use less energy - saving you money while reducing environmental pollution. In fact, Energy Star-compliant products consume less than 1 watt of power while in standby mode. As an Energy Star partner, Philips develops products that meet the Energy Star guidelines for energy efficiency. This is achieved by having low standby power consumption through innovatively designed standby circuitry and stringent selection of components made with high efficiency materials.



# Specifications

## Picture/Display

- Aspect ratio: Widescreen
- Display screen type: LED Full HD Display
- Panel resolution: 1920x1080p
- Brightness: 450 cd/m<sup>2</sup>
- Response time (typical): 8 ms
- Contrast ratio (typical): 4000:1
- Dynamic screen contrast: 25,000:1
- Diagonal screen size: 32 inch / 81 cm
- Visible screen diagonal (inch): 31.5 inch
- Viewing angle (typical): 170° (H) / 170° (V)
- Picture enhancement: Pixel Plus HD, 3D Combfilter, Digital Noise Reduction, Dynamic contrast enhancement, Progressive scan

## Supported Display Resolution

### Computer formats

Resolution	Refresh rate
640 x 480	60Hz
720 x 480	60Hz
800 x 600	60Hz
1024 x 768	60Hz
1280 x 768	60Hz
1360 x 768	60Hz
1920 x 1080	60Hz

### Video formats

Resolution	Refresh rate
480i	60Hz
480p	60Hz
720p	60Hz
1080i	60Hz
1080p	60Hz

## Sound

- Equalizer: 5-bands
- Output power (RMS): 2 x 3W
- Sound System: SRS TruSurround HD, Dolby Digital (AC-3), Stereo, SAP

## Loudspeakers

- Built-in speakers: 2

## Convenience

- Child Protection: Child Lock+Parental Control
- Clock: Sleep Timer

- Ease of Installation: Autostore
- Ease of Use: Auto Volume Leveller (AVL), AutoPicture, AutoSound, Settings assistant Wizard, Side Control
- Remote Control: TV
- Screen Format Adjustments: 16:9, Normal, Zoom, 4:3, Full, Movie Expand, Wide
- Multimedia: auto slideshow

## Multimedia Applications

- Multimedia connections: USB memory class device
- Playback Formats: JPEG Still pictures, MP3

## Tuner/Reception/Transmission

- Aerial Input: 75 ohm F-type
- TV system: ATSC, NTSC
- Video Playback: NTSC
- Tuner bands: UHF, VHF

## Connectivity

- AV 1: Audio L/R in, YPbPr
- AV 2: Audio L/R in, CVBS in, S-Video
- AV 3: Audio L/R in, CVBS in, S-Video in
- HDMI 1: Analog audio L/R in, HDMI
- HDMI 2: HDMI
- HDMI 3: HDMI
- Audio Output - Digital: Coaxial (cinch)
- Other connections: Analog audio Left/Right out
- USB: USB
- EasyLink (HDMI-CEC): One touch play, Power status, System info (menu language), System audio control, System standby

## Power

- Mains power: 120V/60Hz
- Power consumption: 128 W
- Standby power consumption: < 0.15 W
- Ambient temperature: 5°C to 35°C (41°F to 95°F)


## Dimensions

- Set dimensions in inch (W x H x D): 30.91 x 18.98 x 1.93 inch
- Set dimensions with stand in inch (W x H x D): 30.91 x 20.93 x 8.66 inch
- Product weight (lb): 19.18

- Product weight (+stand) (lb): 20.72 lb
- Box dimensions in inch (W x H x D): 35.83 x 24.76 x 8.98 inch
- Weight incl. Packaging (lb): 26.01
- VESA wall mount compatible: 200 x 200 mm

## Accessories

- Included accessories: Table top stand, Power cord, Quick start guide, User Manual, Registration card, Remote Control, Batteries for remote control



Issue date 2012-02-03

Version: 1.1.1

12 NC: 8670 000 63325  
UPC: 6 09585 19116 7

© 2012 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)

