

Philips Matchline Flat TV with Digital Crystal Clear

76 cm (30")



30PF9946D

Superior picture quality

With latest high definition LCD display

An elegantly designed TV that you can hang on the wall is now a reality. This Flat TV delivers best-in-class picture quality for your home entertainment set-up.

Enhanced video performance

- Digital Crystal Clear provides vivid cinema-like images
- 3D combfilter separates colors for a razor-sharp image
- · Active Control with Light Sensor optimizes picture quality

Impressive sound

• Virtual Dolby Surround for a cinema-like audio experience

Design that blends into your interior(s)

• New Arch Design for elegance and style



Specifications

Picture/Display

- Aspect ratio: 15:9
- Brightness: 450 cd/m²
- Contrast ratio (typical): 350:1
- Diagonal screen size: 30 inch / 76 cm
- Display screen type: LCD WXGA Active Matrix
 TET
- Picture enhancement: 3/2 2/2 motion pull down, Active Control + Light sensor, Comb Filter Digital, Digital Crystal Clear, Progressive scan, Widescreen Plus
- Screen enhancement: Anti ageing circuit, Anti-Reflection coated screen
- Viewing angle (horizontal): 176 degree
- Panel resolution: 1280 x 768p
- Response time (typical): 12 ms

Supported Display Resolution

Computer formats

Resolution Refresh rate 640 x 480 60, 67, 72, 75Hz 800 x 600 56, 60, 72, 75Hz 1024 x 768 60, 70, 75Hz

Video Formats
 Resolution

Resolution Refresh rate 640 x 480p 2Fh

Sound

- Sound Enhancement: Smart Sound
- Sound System: Virtual Dolby Surround
- Output power (RMS): 2 x 15W

Loudspeakers

• Built-in speakers: 2

Convenience

• Ease of Installation: Auto Volume Leveler, Autostore, PLL Digital Tuning, Plug & Play

- Ease of Use: On Screen Display, Smart Picture, Top Controls
- Remote control type: RC4334/01
- Picture in Picture: Picture in graphics, Twin page text, 1 tuner PIP
- Remote Control: Multi-functional, Universal
- Screen Format Adjustments: 6 Widescreen Modes, Auto Format, Subtitle and Heading Shift

Tuner/Reception/Transmission

- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: NTSC
- Video Playback: NTSC, PAL, SECAM
- Aerial Input: 75 ohm coaxial (IEC75)

Connectivity

- AV 1: Audio L/R in, CVBS in, YPbPr(1Fh)
- AV 2: Audio L/R in, CVBS, S-Video Y/C
- Side: Audio L/R in, CVBS in, S-Video Y/C, Headphones out
- Audio output: Stereo Out (2 cinch)

Davis

- Power consumption: 135 W
- Standby power consumption: < 3 W
- Mains power: AC 100 240 V, 50/60 Hz
- Ambient temperature: 5 $^{\circ}$ C to 40 $^{\circ}$ C

Dimensions

- Weight incl. Packaging: 23 kg
- Set dimensions (W x H x D): 895 x 490 x 110 mm
- Set weight: 18 kg

Accessories

- Included accessories: Table top stand, Wall mounting bracket, Mini-jack to CVBS-L/R cable, VGA to YPbPr-Cinch cable
- Optional accessories: Floor stand

Highlights

Digital Crystal Clear

Digital Crystal Clear is a package of picture innovations that digitally adjusts and optimizes picture quality to optimal contrast, color and sharpness levels. It's like watching vivid cinema-like images.

3D Combfilter

The 3D comb filter separates brightness and color signals better in 3D domain to eliminate cross-color, cross-luminance and dot-crawl distortion - all of which detract from your viewing pleasure. The 3D digital comb filter performs field-by-field comparisons of the television image to accurately separate the color from the black-and-white information and remove both horizontally and vertically hanging dots, as well as dot crawl. The result is a razor sharp image.

Active Control + Light Sensor

Active Control is a unique and intelligent way of optimizing picture quality by measuring and analyzing the incoming signal to automatically adjust picture quality settings. Active Control with Light Sensor uses a sensor to adjust the picture brightness depending on the room light conditions.

Virtual Dolby Surround

Virtual Dolby Surround is a processing technology for enhancing surround sound effects. It will create the sensation of Dolby Pro Logic without the necessity of additional rear speakers. You become totally immersed in your television experience.

New Arch Design

New Arch Design for elegance and style











Issue date 2014-02-07

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 4.0.5

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 21089 UPC: 0 37849 94802 6

www.philips.com