

Philips  
Digital video recorder



HDR5710



# Smart HD Digital Video Recorder

with built-in 500GB HDD

Record your favorite shows anytime

## Engage more

- Smart TV for popular services like Netflix, Vudu and YouTube
- Dolby Digital Plus for full-range sound
- Digital Video Recorder with built-in ATSC Tuner
- Records up to 50 hours of storage
- Certified wireless connection to the internet
- Direct remote Netflix and Vudu
- Full HD 1920x1080p output

# PHILIPS

# Highlights

## Digital video recording

Record programming from your over-the-air TV antenna. The recorder will only record unencrypted signals. Please contact your cable provider for more information regarding signals.

## Net TV

Experience a rich selection of online services with Net TV. Enjoy movies, pictures, infotainment and other online content directly on your TV whenever you like. Wirelessly navigate and select what you want to watch with the remote control. The Philips menu gives you access to popular Net TV services fitted for your TV screen.

## Dolby Digital Plus

Dolby Digital Plus gives you access to more content and lets you experience all of the

enveloping sound. You will follow the action with your eyes and your ears with this premium-quality sound. When listening to your music or watching movies, you will feel the explosive power of dazzling special effects and hear every sound as the artist or director intended.

## 500GB HDD

Enjoy up to 50 hours of video playback it's that simple. You can now plan in advance to record your favorite programs you may miss without having to connect to any other devices.

## Certified Wi-Fi

Certified Wi-Fi, also known as IEEE 802.11n, is the new wireless network standard. It includes many new options to improve the quality of the wireless link, offering faster speed and wider range compared to previous Wi-Fi

standards. Wi-Fi also features backward compatibility, which makes it possible for this DVR to transmit to and receive from routers that operate on older Wi-Fi standards.

## Direct remote Netflix and Vudu

To speed up the process, and make it more user-friendly, there are Netflix and VUDU shortcut buttons on remote control that allow you to do the basic commands necessary both for watching your video and for controlling the general interface.

## Full HD 1920x1080p output

This is the highest resolution of HD sources for the best possible picture quality. It is fully future proof as it supports 1080p signals from all sources. The signals processing is extensively upgraded to support this much higher signal quality and resolution.



# Specifications

## Connectivity

- Rear Connections: HDMI Out, Composite Video (CVBS) Out, Analog Audio Left/Right Out, RF In, RF Out, USB (for External HDD), Ethernet
- Wireless connections: Wi-Fi (Built-in)

## Convenience

- Built-in HDD: 500GB
- OSD Languages: English, French, Spanish
- Child Protection: Parental Control

## Network Services

- Streaming Service: NETFLIX, VUDU, YouTube, CinemaNow

## Sound

- Sound enhancement: Dolby Digital Plus

## Tuner/Reception/Transmission

- TV system: ATSC

## Power

- Power supply: 120V, 60Hz
- Power consumption: 18 W
- Standby power consumption: 0.35W

## Accessories

- User Manual: English, French, Spanish
- Included accessories: User Manual, Quick start guide, Remote Control, 2 x AAA Batteries, Audio/Video cable, RF antenna cable

## Dimensions

- Set dimensions in inch (W x H x D): 11.1 x 2.0 x 8 inch
- Product weight (lb): 2.96 lb
- Packaging (W x H x D): 13.4x4.4x12 inch
- Weight incl. Packaging: 4.74 lb



Issue date 2016-05-12

Version: 2.3.2

12 NC: 8670 001 08111  
UPC: 6 09585 23813 8

© 2016 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Unit only records content from over-the-air broadcasts.  
\* External hard drive not included.