

PHILIPS

Smart lever door
lock

6000 series

Intuitive fingerprint unlock

Mute by "0" button

Safehandle function



DDL603LKABW



Unlock new joy in life

Wi-Fi connection, smart life under control

Wi-Fi-enabled DDL603E-5HWS supports you to distribute one-time PIN code and check the access records remotely, etc. With the fingerprint sensor integrated into the handle, unlocking is conveniently in one grip, adding more fun to your life.

Smart life locked with excellence

- Allow one grip to unlock

Caring designs comes with high quality of life

- Leave a quiet place for the family
- Ensure home secure and eliminate risk while away
- Voice prompt makes operation easier

Highlights

Intuitive fingerprint



Adopted the integrated handle design with an FPC semiconductor fingerprint, the fingerprint recognition speed of Philips DDL603E-5HWS is less than 0.5 s. Pressing down the handle allows one grip to unlock and brings you a fast and intuitive opening experience.

Mute by "0" button



The "0" button is used both as a digit button and a mute button. Long press the "0" button for 2 seconds to enable the mute mode no matter you are in or out. Without disturbing your family at night, the thoughtful design allows you to get back home in a quiet manner, which leaves a quiet place for the family.

Safehandle function



You can enable the safehandle feature before leaving home. After the door is locked, the indoor handle will be frozen so that nobody could open the door by pressing down the inside handle. This feature can prevent children and pets from accidentally opening the door, thus eliminating security risks.

Low battery level alert



When the door lock's battery level is less than 20%, it will trigger an alert. The Philips DDL603E-5HWS has an emergency power supply Micro-USB interface, which allows charging by the output voltage of 5V power bank. The operation is simple, and the working state of the smart lock is fully assured, allowing you to use it with peace of mind every day.

Specifications

Access Solution

Card/Key Tag
Fingerprint
Mechanical Key
Password/PIN Code

Design & Appearance

Color: Obsidian black
Fingerprint Sensor: Semiconductor
Handle: Lever handle

Easy Operation

Indicator: Door locks status prompt, Low battery prompt, Mute status prompt, System locking prompt
Voice Guide: Human voice guide

Installation

Door Opening Direction: Left inward opening, Left outward opening, Right inward opening, Right outward opening
Door Thickness: 38-60 mm, 60-90 mm, 90-120 mm, Other range*
Door Type: Antitheft door, Copper door, Wooden door

Lock Capacity

Card/Key Tag: Up to 100
Master PIN Code: 1
One-time PIN Code: 1
User PIN Code: Up to 20

Power Specification

Emergency Power Supply: 5V power bank
Power Supply: 4 AA batteries
Time of Use: 10 months*

Smart Lock Functions

Locking Function: Indoor deadlock
Mortise: C grade lock cylinder
Safety Function: Dual verification, Fake PIN code



* May be less depending on the actual usage.

* The effect of the digital keypad showed in the photos of this product may be inconsistent with the actual display effect. Please be subject to the digital keypad displaying status under the actual usage scenarios.

* Other door thickness range: If the thickness of the door is out of the mentioned range, please contact our local dealers or consumer care center.