

Philips Ultinon LED  
Fog light bulb

LED-FOG [~H8/H11/H16]

6000K  
+160% brighter light  
Compact design for better fit

11366ULX2



# The next level of white light

## Compact and bright white LED

Philips Ultinon LED fog lights let you experience the next level of brightness: stylish white light with 6000 Kelvin and good headlight beam performance. Enhanced fit through compact design thanks to integrated electronics.

### Reliable Philips quality

- Philips automotive lighting at the highest quality level
- Easy installation and compatible with many car models

### Enhanced fit with compact design

- Easy installation thanks to integrated electronics

### Long lasting LED fog lights

- Durable LED bulbs for cars that last longer

### Crisp white beam

- 6000 Kelvin color temperature for crisp white light

### Bright LED headlights for cars

- Get 160% brighter light for superior visibility

# PHILIPS

Fog light bulb  
LED-FOG [~H8/H11/H16] 6000K, +160% brighter light, Compact design for better fit

11366ULX2

## Highlights

### Automotive grade quality



The technologically advanced Philips lighting is renowned in the automotive industry, and has been for over 100 years. The Philips Automotive Grade Quality products are designed and developed following strict quality control processes (including applicable ISO norms), leading to consistently high production standards. Major car manufacturers choose Philips lamps, because when you buy Philips, you buy quality. You get powerful bright light, and precise beam performance. You get high-end style. Enjoy a safer and smoother drive.

### Brightness for improved vision

Driving in the dark is demanding, so you rely on your headlights. Forward and peripheral vision are both important to enhance your driving ability for a safer drive. With a bright beam, Philips Ultinon LED headlights for cars improve your visibility by up to 160%. Once you experience this daylight-like effect, you'll always prefer LED. The more you can see, the better you perform, the faster you react and the safer you are. So don't let darkness win, choose Philips and start driving at night with greater confidence and control.

### Compact design

Philips Ultinon LED uses a brand new bulb design integrating driver box electronics in the body. A driver box is the brain of an LED: it manages performance aspects such as wattage and light output. Many other LED Upgrades solutions in the market have the driver box exterior to the LED body. Philips Ultinon LED integrates it directly in the body to create an optimized design using minimal space. Optimized LED size is key because several optics are very small. Philips Ultinon LED with its compact design fits a wide range of car models and can be easily installed by specialist mechanics.

### Durable LED fog light bulbs

You want bright and stylish fog lights. But you don't want to keep replacing failed lamps. That's a major weakness of conventional fog lights; the more powerful the light, the shorter its lifespan. LEDs last much longer, and Philips Ultinon LED products show superior durability: they last up to 8 years.

### Pure bright white light

With a high color temperature of up to 6000 Kelvin, the Philips Ultinon LED fog lights produces a bright white, daylight-like beam. With clearer vision you're better able to spot obstacles and take the perfect driving line. And as you don't have to strain to see the terrain ahead, brighter lights make for a more comfortable and exciting night-time drive.

### Ready - steady - installed!

Designed to be easily installed in compatible vehicles, drivers with maintenance experience will be able to upgrade compatible headlights with ease. However, it's recommended that you get your new Philips LED headlights installed by specialist mechanics – they will make sure you're ready to go. While these headlights are compatible with a wide range of existing car models, not all car types are supported.

## Specifications

### Marketing specifications

- Expected benefits: Compact design for better fit
- Product highlight: The next level of white light

### Product description

- Application: Front fog
- Base: PGJ19-1, PGJ19-2, PGJ19-3
- Designation LED Type: LED-FOG [~H8/H11/H16]
- Homologation ECE: NO
- Range: Ultinon LED
- Technical features: Inbuilt Electronic driver
- Technology: LED
- Type: H8; H11; H16

### Lifetime

- Life time: Up to 8 years

### Light characteristics

- Lumens: 820
- Color temperature: Up to 6000K

### Electrical characteristics

- Wattage: 10 W
- Voltage: 12 V

### Ordering information

- Order entry: 11366ULX2
- Ordering code: 39850231

### Packaging Data

- Packaging type: X2
- EAN1: 8727900398502
- EAN3: 8727900398519



Issue date 2023-09-14

Version: 5.1.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* It is your own responsibility to ensure that the use of the LED retrofit lights complies with applicable local legal requirements.