

H1
55 W
12 V



12258PRB1

# Safety you can see

Up to 30% more vision

Producing up to 30% more vision,\* Philips Vision headlights deliver a longer light-beam projections for increased safety and comfort. \*Compared to standard minimum legal requirements in low beam tests results.

## Very high quality and ultra resistant car lamp

- Philips car lamps are made of high-quality quartz glass
- · Philips car lamps are highly resistant against humidity

### localizer1

• Philips is the choice of all major car manufacturers.

### A better performance than a standard car head lamp

 $\bullet$  Up to 30% more vision on the road\*


# **Original Equipment manufacturer**

• Philips is the choice of major car manufacturers



# Highlights

# **Greater safety and comfort**



Our Vision upgrade headlight bulbs produce a longer light-beam projection for greater safety and comfort.

### Car manufactuer choice



For 100 years, Philips has been on the forefront of the automotive lighting industry, introducing technological innovations that have become standard on modern automobiles. Today, one in two cars in Europe and one in three worldwide is equipped with Philips lighting

## High quality quartz glass



UV-Quartz glass is stronger than hard glass and highly resistant to temperature extremes and vibrations, which eliminates the risk of explosion. Philips quartzglass lamps (filament 2 650° C and glass  $800^{\circ}$  C) are able to withstand severe thermal shock. With the capability of increased pressure inside the lamp, UVquartz glass is able to produce a more powerful light

### Resistance against humidity



Only a burning bulb made of quartz glass (filament 2650°c, glass 800°c) can resist thermal shocks : if a drop of cold water touches the hot bulb, which can happen when you drive through water with a broken headlight unit.

### Original equipment quality

For over 100 years, Philips has been on the forefront of the automotive lighting industry, introducing technological innovations that have become standard on modern cars. Today, one in three cars worldwide is equipped with a Philips light source.

# Specifications

### **Marketing specifications**

- · Expected benefits: More light
- Product highlight: Up to 30% more vision

### **Product description**

- · Application: High beam, Front fog light, Low beam
- Base: P14,5s
- Designation: H1 Vision
- Homologation ECE
- Marking ECE: E1 21P
- Range: Vision
- Technology: Halogen
- Type: H1

#### Lifetime

· Life time: 400h

# **Light characteristics**

- Lumens: 1690 +5% -7% Im
- Color temperature: Up to 3200 K

#### **Electrical characteristics**

- Wattage: 55 W
- Voltage: 12 V

# **Ordering information**

- Order entry: 12258PRB1
- Ordering code: 47516930

### **Packaging Data**

- Packaging type: B1
- EAN1: 8711500475169
- EAN3: 8711500475176

### **Packed product information**

- Width: 9.5 cm
- Height: 13.5 cm
- Net weight per piece: 6.255 g
- Gross weight per piece: 22 g
- Length: 2.568 cm
- Pack Quantity / MOQ: 10
- Pack Quantity: 1
- MOQ (for professionals): 10

### **Outerpack information**

- Length: 19.5 cm
- Width: 15.3 cm
- · Height: 11 cm
- · Gross weight per piece: 0.22 kg



Issue date 2023-09-14

Version: 11.0.2

© 2023 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com